

**PARSUN OUTBOARD ENGINE
SERVICE MANUAL**

F15/F9.9BM(F15/F9.9W)

SUZHOU PARSUN POWER MACHINE CO., LTD.

NOTICE

This manual includes service instructions for F9.9, F15 and has been prepared by Parsun Power primarily for use by the dealers when performing maintenance and repair to Parsun outboard engines. Before performing maintenance, please read the manual carefully. When performing maintenance and repair to Parsun outboard engines, please use the service procedure and tools recommended by the manual. If you use other service procedure and tools, please follow guidance from experienced maintenance people, to avoid damage to people and outboard engines.

The manual is based on the sample machines that are produced at the time of printing, so the model being actual purchased may differ a little from the descriptions and illustrations given in this manual. If necessary, our company will distribute the manual revision to dealers.

In this Service Manual, particularly important information is distinguished in the following ways, please read the manual carefully, and perform the instructions correctly and carefully.

WARNING:

Failure to follow WARNING instructions could result in severe injury or death to the machine operator and bystander.

CAUTION:

A CAUTION indicates special precautions that must be taken to avoid damage to the outboard motor.

NOTE:

A NOTE provides key information to make procedures easier or clearer.

The common troubles and solutions are given in the end of the manual, please read carefully. When performing maintenance and repair to Parsun outboard engines, they will help you judge the outboard engine's status quickly and improve the work efficiency.

All rights reserved.

This manual cannot be reproduced or transmitted in any form or by any means without the written approval of our company.

Suzhou Parsun Power Machine Co., Ltd.

INDEX

| | |
|---|----|
| GENERAL INFORMATION | 1 |
| IDENTIFICATION | 1 |
| PROPELLER SELECTION | 1 |
| EMERGENCY START | 1 |
| SAFETY WHILE WORKING | 2 |
| DISASSEMBLY AND ASSEMBLY | 3 |
| ONE-TIME USE PARTS | 4 |
| PRE-DELIVERY CHECK | 4 |
| SPECIAL TOOLS AND DETECTION DEVICE | 6 |
| EXPLOSIVE DRAWING AND SYMBOL | 8 |
| | |
| SPECIFICATIONS | 9 |
| OUTBOARD ENGINE SPECIFICATIONS | 9 |
| MAINTENANCE INFORMATION | 10 |
| Power unit | 10 |
| Lower unit | 11 |
| Ignition system | 11 |
| Charge system | 12 |
| TIGHTENING TORQUE | 12 |
| Specified torque | 12 |
| General torque | 13 |
| | |
| PERIODIC SERVICE | 14 |
| MAINTENANCE TIME TABLE | 14 |
| FUEL SYSTEM | 15 |
| POWER UNIT | 15 |
| Engine oil level | 15 |
| Changing engine oil | 16 |
| Valve clearance | 16 |
| Spark plug | 17 |
| CONTROL SYSTEM | 17 |
| Throttle grip | 17 |
| Idling speed | 18 |
| Start-in-gear protection | 19 |
| LOWER UNIT | 19 |
| Gear oil | 19 |
| Changing gear oil | 19 |
| Lower unit leakage check | 20 |
| GENERAL INSPECTION | 20 |

| | |
|---|-----------|
| Anode..... | 20 |
| Grease points..... | 20 |
| Cooling water passage..... | 21 |
| Thermostat..... | 22 |
| RECOIL STARTER..... | 22 |
| NOTICE..... | 22 |
| EXPLOSIVE DRAWING..... | 23 |
| DISASSEMBLING..... | 27 |
| START ROPE REPLACEMENT..... | 27 |
| DISASSEMBLING AND INSPECTION..... | 28 |
| ASSEMBLING..... | 29 |
| INSTALLATION..... | 29 |
| IGNITION SYSTEM..... | 29 |
| NOTICE..... | 29 |
| EXPLOSIVE DRAWING..... | 30 |
| WIRING DIAGRAM..... | 35 |
| SPARK PLUG IGNITION..... | 35 |
| SPARK PLUG CAP..... | 36 |
| FLYWHEEL MAINTENANCE..... | 36 |
| CDI INSPECTION..... | 36 |
| IGNITION COIL INSPECTION..... | 36 |
| PULSED COIL INSPECTION..... | 37 |
| CHARGE COIL INSPECTION..... | 37 |
| FUEL SYSTEM..... | 38 |
| NOTICE..... | 38 |
| EXPLOSIVE DRAWING..... | 38 |
| THROTTLE CONNECTING ROD ADJUSTMENT..... | 44 |
| FUEL JOINT REMOVAL AND INSPECTION..... | 44 |
| FUEL PUMP REMOVAL AND INSPECTION..... | 44 |
| FILTER INSPECTION..... | 45 |
| POWER UNIT..... | 46 |
| NOTICE..... | 46 |
| EXPLOSIVE DRAWING..... | 46 |
| SPECIAL TOOLS..... | 54 |
| COMPRESSION PRESSURE INSPECTION..... | 54 |
| OIL PRESSURE INSPECTION..... | 55 |
| OIL PRESSURE SWITCH INSPECTION..... | 55 |

| | |
|---|-----------|
| DISASSEMBLING POWER UNIT | 55 |
| BELT PULLEY AND TIMING BELT | 56 |
| DISASSEMBLING AND INSPECTION | 57 |
| CYLINDER COVER | 57 |
| Disassembling..... | 57 |
| Valve and valve guide bush..... | 58 |
| Valve spring..... | 58 |
| Valve rocker arm and rocker shaft..... | 58 |
| Camshaft..... | 58 |
| Oil pump check..... | 59 |
| Valve guide bush replacement..... | 59 |
| Valve seat inspection..... | 60 |
| Valve seat cutting..... | 61 |
| Valve installation..... | 61 |
| Assembling cylinder cover..... | 61 |
| CRANKCASE | 61 |
| Disassembling..... | 61 |
| Piston..... | 62 |
| Cylinder bore..... | 62 |
| Piston pin diameter..... | 63 |
| Piston ring..... | 63 |
| Crankshaft..... | 63 |
| Crankpin oil clearance..... | 63 |
| Main journal oil clearance..... | 64 |
| Cylinder body and crankcase..... | 64 |
| FULL INSTALLATION | 64 |
| Piston connecting rod installation..... | 64 |
| Piston ring installation..... | 65 |
| Piston installation..... | 65 |
| Crankshaft installation..... | 65 |
| Assembling power unit..... | 66 |
| UPPER UNIT | 68 |
| TOP COWLING | 68 |
| Explosive drawing..... | 68 |
| Disassembling and inspection..... | 69 |
| BOTTOM COWLING | 70 |
| Explosive drawing..... | 70 |
| Disassembling and inspection..... | 74 |
| STEERING HANDLE | 75 |
| Explosive drawing..... | 75 |


| | |
|---|-----------|
| Disassembling and inspection | 78 |
| BRACKET | 79 |
| Explosive drawing | 79 |
| Disassembling and inspection | 83 |
| UPPER UNIT | 85 |
| Explosive drawing | 85 |
| Disassembling and inspection | 86 |
| LOWER UNIT | 87 |
| WATER PUMP ASSEMBLY | 87 |
| Explosive drawing | 87 |
| Disassembling and inspection | 88 |
| LOWER UNIT | 89 |
| Explosive Drawing | 89 |
| Disassembling and inspection | 94 |
| Propeller shaft and clutch block | 94 |
| Dog clutch installation | 95 |
| Lower casing cover | 95 |
| Lower casing cover oil seal and bearing installation | 95 |
| Drive shaft | 96 |
| Shift rod cam | 96 |
| Gear | 96 |
| Forward gear bearing | 96 |
| Lower casing inspection | 96 |
| Assembling lower casing | 96 |
| Lower unit installation | 97 |
| Shim selection | 98 |
| COMMON TROUBLES AND SOLUTIONS | 99 |

items far away. Don't touch flywheel or other moving parts.

- When starting and operating, don't touch ignition coil, spark plug cap or other electric parts.


The procedure is as follows:

1. Remove the top cowling.
2. Remove the start-in-gear protection device cable.




1. Start-in-gear protection device cable

3. Demount three bolts and remove starter.



4. Insert the knot of the cable in the notch of flywheel rotor, and wind the cable around flywheel several rounds in clockwise direction..

5. Pull the manual starter handle slowly until you feel resistance.



6. Give a strong pull to start the engine. Repeat if necessary.

SAFETY WHILE WORKING

To prevent the danger or accidents when performing maintenance and repair, and improve the work efficiency, please obey the following safety procedures.

1. FIRE PREVENTION

Gasoline (petrol), lubricant and grease are highly flammable. While working, keep away from heat, sparks and open flames.

2. VENTILATION

Petroleum vapor and engine exhaust gases are violent in toxicity. They are harmful to breathe and deadly if inhaled in large quantities. When test-running an engine indoors, maintain good ventilation.

3. SELF-PROTECTION

Protect your eyes with suitable safety glasses or safety goggles, when drilling, grinding or operating air compressor. Protect hands and feet by wearing protective work clothes, safety gloves and shoes if necessary.

4. LUBRICANTS AND SEALING FLUIDS

When performing maintenance procedures and repair to Parsun outboards, use only products provided or recommended by our Company.

Under normal conditions of use, there should be no hazards from the use of the lubricants mentioned in this manual, but safety is all-important, and by adopting good safety practices, any risk is minimized.

- 1 To protect the skin, the application of a suitable barrier cream to the hands before working is recommended.
- 2 Clothing which has become contaminated with lubricants should be changed as soon as practicable, and washed before further use.
- 3 Avoid skin contact with lubricants.
- 4 Hands and any other part of the body which have been in contact with lubricants or lubricant-contaminated clothing, should be thoroughly washed with hot water and soap as soon as practicable.
- 5 A supply of clean lint-free cloths should be available for wiping run-off lubricants or grease.

5. GOOD WORKING PRACTICES

- 1 Follow the tightening torque instruction. When tightening bolts, nuts and screws, tighten the large sizes first, and tighten inner-positioned fixings before outer-positioned ones.
- 2 Use the recommended special tools to protect parts from damage. Use the right tool in the right manner.

DISASSEMBLY AND ASSEMBLY

When disassembly and assembly, please follow the following principles :

1. Use special tools when disassembling and assembling.
2. Clean dirt before disassembling the parts.
3. Oil the contact surfaces of moving parts before assembly.
4. Install bearing with the manufacturer's markings on the side exposed to view and liberally oil the bearing.

5. When installing oil seals, apply a light coating of water-resistant grease to the ledge and outside diameter.
6. After assembly, check if the moving parts operate normally.

ONE-TIME USE PARTS

One-time use parts are gasket, oil seal, O-ring, cotter pin and spring, ring, and etc.. When re-assembling outboard engine, you must change the one-time use parts.

PRE-DELIVERY CHECK

To ensure the using, please inspect the following before delivery.

1. CHECKING FUEL SYSTEM

Check if the fuel pipe is connected firmly, and if the fuel tank is filled with fuel.



CAUTION:

Do not use pre-mixed fuel for this 4-stroke outboard engine.

2. CHECKING OIL LEVEL

- 1 Check the engine oil level

Remove oil cap, check engine oil level..



1. Oil cap 2. High position mark 3. Low position mark

Ensure the oil level between the marks of upper and lower. If above upper level, drain engine oil; if below lower mark, add engine oil up to upper level.

- 2 Check the gear oil level

Remove the oil level plug. Check if the gear oil overflows at the oil level checking hole. If so, install the oil level plug and tighten it according to specified torque. Otherwise please add gear oil.



1. Oil level plug


3. CHECK STEERING SYSTEM

Check if steering is stable.

Check if steering friction is adjusted correctly.

Turn clamp handle screw clockwise to increase resistance.

Turn clamp handle screw counter clockwise to lower resistance.



1. Clamp handle screw

4. CHECK SHIFT LEVER AND THROTTLE

Check if the shift lever is operated smoothly.

Check if the throttle grip is turned smoothly from full closed position to full open position.

5. CHECK ENGINE STOP SWITCH ASSY

Check if the engine stops when pushing the engine stop switch assembly or pulling out the stopper hang rope.

6. CHECK COOLING WATER CHECKING HOLE.

When the engine is running, check if cooling water overflows at the cooling water checking hole.



1. Cooling water checking hole

7. BREAKING-IN RUNNING

1 Initial 1 hour: operate the engine at 2000 r/min or about a half throttle.

The second hour: operate the engine at 3000 r/min or about 3/4 throttle.

The following 8 hours: operate the engine at full throttle continuously. Each operation time doesn't exceed 5 minutes.

8. INSPECTION AFTER BREAKING-IN RUNNING

1 Check if gear oil contains water..

Check if the fuel line leaks.

After breaking-in running, operate the engine at idling speed. Use cleaning tool to wash over the cooling water passage by fresh water.

9. AFTER BREAKING-IN RUNNING, INSPECT IDLING SPEED.


Preheating engine for 5 minutes.

Using the tachometer to measure idling speed RPM.

If out of specification, adjust it. Idling speed: 900~1000 r/min.

Turn the throttle stop screw clockwise or counter clockwise until the specified idling speed is attained.

After adjusting idling speed, picking up RPM several times to check the engine's stability.



SPECIAL TOOLS AND DETECTION DEVICE

When performing maintenance and repair, you need to use all kinds of special tools and detection device. The use of correct tools will improve the work efficiency and avoid of the damage to the people and outboard engines.


SPECIAL TOOLS:



Piston slider



Flywheel gripper and puller



Bearing puller



Valve spring compressor



Housing oil seal installer




Lower casing cover bearing installer



Lower casing cover barrel bearing installer,



Lower casing cover oil seal installer



Space gage



Needle bearing installer



Oil cleaner spanner



Bearing block copper sleeve installer




Bearing block oil seal installer



Forward gear bearing installer

DETECTION DEVICE :



Digital tachometer




Digital circuit tester



Peak voltage adaptor

EXPLOSIVE DRAWING AND SYMBOL

EXPLOSIVE DRAWING



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|----------------------------------|-----------|---------------|
| 1 | F15-06000007 | 外挡板 OUTER PLATE | 1 | |
| 2 | JASO F404-96 | 水泵壳O型密封圈1-45 O-RING | 1 | |
| 3 | F15-06050000 | 水泵叶轮组件 IMPELLER | 1 | |
| 4 | F15-06060002 | 水泵内壳 INNER SHELL, WATER PUMP | 1 | |
| 5 | F15-00000013 | 定位销 4X12 PIN, DOWEL | 2 | |
| 6 | F15-06060001 | 水泵壳体 WATER PUMP HOUSING | 1 | |
| 7 | F15-02000004 | 水管密封圈上 UPPER SEAL, WATER PIPE | 1 | |
| 8 | F15-06060004 | 泵壳水管密封圈 SEAL | 1 | |
| 9 | F15-06000014 | 泵壳固定板 FIXED PLATE, WATER PUMP | 2 | |
| 10 | GB/T5783-2000 | 六角螺栓 M8X45 BOLT, HEXAGON | 4 | |

Parts explosive drawing.

Screw specification and specified torque.

Oil, fluid sealant or locking substance daubing point.

Spare parts details.

SYMBOL

| | | | | |
|-----------------|------------------------|-----------------------------------|-----------------------------------|--------------------|
| | | | | |
| Daub engine oil | Daub waterproof grease | Daub screw locking substance 1277 | Daub screw locking substance 1243 | Daub fluid sealant |

SPECIFICATIONS

OUTBOARD ENGINE SPECIFICATIONS

| Item | | Description | Item | Description | | |
|------------------------|---------------------------|--------------------------|----------------------|---------------------------|---|---------------------|
| Dimension | Overall length | 1001mm | Power Unit | Ignition system | C.D.I | |
| | Overall width | 427mm | | Starting enrichment | Choke valve | |
| | Overall height | S | | 1080mm | Spark plug | DPR7HS |
| | | L | | 1207mm | Exhaust system | Under water |
| Weight | S | 49kg | | Lubrication system | Pressure lubrication | |
| | L | 51kg | Fuel type | Unleaded regular gasoline | | |
| Performance | Max output | 7.3Kw(9.9hp)@5000r/min | Fuel and Oil | Fuel standard | PON86、RON91 | |
| | | 9.9Kw(13.5hp)@5000r/min | | Fuel tank capacity | | |
| | | 11Kw(15hp) @5000r/min | | Recommended engine oil | API SE, SF, SG, SH, SJ SAE 10W30, 10W40 | |
| | Full throttle operation | 4500 ~ 5500 r/min | | Engine oil quantity | 1.2L | |
| | Max fuel consumption | 3.5L/h@5500 r/min(7.3Kw) | | Recommended gear oil | Hypoid gear oil SAE # 90 | |
| | | 5.3L/h@5500 r/min(11Kw) | | | Gear oil quantity | 250 cm ³ |
| Idle speed (Neutral) | 950±50 r/min | Tilt angle | 8° , 12° , 16° , 20° | | | |
| Power Unit | Type | 4 stroke, OHV | Bracket | Tilt-up angle | 63° | |
| | Number of cylinders | 2 | | Steering angle | 45° +40° | |
| | Displacement | 323cm ³ | | Gear positions | F-N-R | |
| | Bore×Stroke | 59mm × 59mm | Drive Unit | Gear ratio | 2.08 | |
| | Compression ratio | 9.19:1 | | Gear type | Spiral bevel gear | |
| | Min. compression pressure | 765kPa | | Clutch type | Dog clutch | |
| | Number of carburetors | 1 | | Propeller drive system | Spline | |
| | Control system | Tiller control | | | | |
| | Starting system | Recoil starter | | | | |

MAINTENANCE INFORMATION

Power unit

| Item | | Description | Item | | Description | |
|-----------------------------|-------------------------------|---------------------------------|-----------------------|-------------------------------|----------------------------|-------------------------|
| Cylinder Head | Warp limit | 0.1mm | Valve | Valve clearance (cold) | Intake | 0.15~0.25mm |
| | Camshaft inside diameter | 35.000~35.012mm | | | Exhaust | 0.20~0.30mm |
| | Rocker shaft outside diameter | 12.941~12.951mm | | Face width | Intake | 1.98~3.11mm |
| | Rocker inside diameter | 13.000~13.018mm | | | Exhaust | 1.98~3.11mm |
| Cylinder | Bore | 59.00~59.015mm | | Seat width | Intake | 0.6~0.8mm |
| | Wear limit | 59.1mm | | | Exhaust | 0.6~0.8mm |
| | Taper limit | 0.08mm | | Margin thickness | Intake | 0.50~0.90mm |
| | Out of round limit | 0.05mm | | | Exhaust | 0.50~0.90mm |
| Piston | Piston diameter | 58.950~58.965mm | | Head diameter | Intake | 27.9~28.1mm |
| | Measuring point height | 5mm (from the bottom of piston) | | | Exhaust | 21.9~22.1mm |
| | Piston-to-cylinder clearance | 0.035~0.065mm | | Stem outside diameter | Intake | 5.475~5.490mm |
| | Pin boss inside diameter | 14.004~14.015mm | | | Exhaust | 5.460~5.475mm |
| Piston pin outside diameter | | 13.996~14.000mm | Guide inside diameter | Intake | 5.500~5.512mm | |
| Piston ring | Top ring | Thickness | | 1.17~1.19mm | | Stem to guide clearance |
| | | Breadth | 2.0~2.20mm | | | |
| | | End gap | 0.15~0.30mm | Stem roundness limit | 0.01mm | |
| | | Side clearance | 0.04~0.08mm | | | |
| | 2nd ring | Thickness | 1.47~1.49mm | Rocker shaft outside diameter | | 12.941~12.951mm |
| | | Breadth | 2.50~2.70mm | Rocker inside diameter | | 13.000~13.018mm |
| | | End gap | 0.30~0.50mm | Valve spring | Free length | 34.40mm |
| | | Side clearance | 0.02~0.04mm | | Free length limit | 32.68mm |
| | Oil ring | Thickness | 2.31~2.51mm | Connecting rod | Tilt limit | 1.5mm |
| | | Breadth | 2.30~2.60mm | | Small end inside diameter. | 14.015~14.029mm |
| | | End gap | 0.20~0.70mm | Big end inside diameter. | 31.031~31.042 mm | |
| | | Side clearance | 0~0.22mm | Big end oil clearance | 0.021~0.045mm | |

| | | | | | | |
|-----------------|---|---------|-----------------|-------------------|--------------------------|------------------|
| Camshaft | Height | Intake | 27.596~27.696mm | Crankshaft | Journal diameter | 34.997~35.009 mm |
| | | Exhaust | 27.616~27.716mm | | Crankpin diameter | 30.997~31.009 mm |
| | Round diameter | | 23.950~24.050mm | | Crankpin width | 21.00~21.07mm |
| | Journal diameter | | 34.935~34.955mm | | Big end side clearance | 0.05~0.22mm |
| | Camshaft round limit | | 0.03mm | | Round limit | 0.05mm |
| Oil pump | Discharge | | 5.70L/min | Thermostat | Opening temperature | 58~62°C |
| | Safety valve opening pressure | | 388.0~450.0kPa | | Full-opening temperature | 70°C |
| | Outside rotor to housing clearance | | 0.100~0.150mm | | Valve lift height | 3mm |
| | Outside rotor to inside rotor clearance | | 0.040~0.140mm | | | |
| | Rotor to cover clearance | | 0.030~0.090mm | | | |

Lower unit

| Item | | Description | Item | | Description |
|-----------------------|------------------------------|--------------|-----------------------|---------------------|--|
| Gear Clearance | Drive gear to forwarder gear | 0.19~0.86mm | Gear Clearance | Forwarder gear shim | 0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50mm |
| | Drive gear to back gear | 0.95~1.65mm | | Back gear shim | 0.10, 0.20, 0.30, 0.40, 0.50mm |
| | Drive gear shim | 1.13, 1.22mm | | | |

Ignition system

| Item | | Description | Item | | Description |
|--------------------------|-------------------|-------------|------------------------------|-----------------|-------------|
| Ignition timing | | BTDC 30° | Pulsed coil resistance | | 234~348 |
| Spark plug gap | | 0.8~0.9mm | Ignition assembly resistance | Primary coil | 0.16~0.25 |
| CDI output peak voltage | Start (load) | 155V | | Secondary coil | 3.92~6.65K |
| | 1500r/min | 170 V | Charge coil peak voltage | Start (no-load) | 175V |
| | 3500r/min | 170 V | | Start (load) | 170V |
| Pulsed coil peak voltage | Start (no-load) | 4.0 V | | 1500rpm | 180V |
| | Start (load) | 4.0 V | 3500rpm | 180V | |
| | 1500r/min (load) | 9 V | Charge coil resistance | | 272~408 |
| | 3500r/min (load) | 17V | | | |

Charge system

| Item | | Description | Item | Description | |
|------------------------|----------------------|-------------|-----------------------|---------------------|-----------|
| Charge current | Min. (3000 r/min) | 5.5 A | Light coil output | Start (load) | 14 V |
| | Max. (5000 r/min) | 6.0 A | | 1500r/min (no-load) | 30 V |
| Rectifier peak voltage | 3000r/min (no-load) | 24 V | | 3500r/min (no-load) | 70 V |
| | 5000r/min (no-load) | 38 V | Light coil resistance | | 0.33~0.72 |

TIGHTENING TORQUE


Specified torque

| Part to be tightened | | Part name | Thread size | Quantity | Torque | |
|----------------------|-----------------------|----------------|-------------|----------|--------|--------|
| Power unit | Safety valve | | — | 1 | 8Nm | |
| | Spark plug | | — | M12 | 1 | 18 Nm |
| | Recoil starter | | Bolt | M6 | 3 | 8 Nm |
| | Flywheel | | Nut | M16 | 1 | 110 Nm |
| | Carburetor | | Bolt | M6 | 2 | 10 Nm |
| | Intake manifold | | Bolt | M6 | 4 | 8 Nm |
| | Cylinder head cover | | Bolt | M6 | 4 | 8 Nm |
| | Cylinder head | 1st tightening | Bolt | M8 | 4 | 15 Nm |
| | | 2nd tightening | | | | 30 Nm |
| | | 1st tightening | Bolt | M6 | 3 | 6 Nm |
| | | 2nd tightening | | | | 12 Nm |
| | Oil filter | | — | — | 1 | 18 Nm |
| | Oil filter stud | | — | — | 1 | 40 Nm |
| | Locknut (rocker arm) | | Nut | M6x0.75 | 4 | 14 Nm |
| | Oil pump | | Bolt | M6 | 2 | 8 Nm |
| | Power unit assembling | | Bolt | M8 | 6 | 21 Nm |
| | Exhaust cover | 1st tightening | Bolt | M6 | 7 | 6 Nm |
| | | 2nd tightening | | | | 12 Nm |
| | Breather cover | | Bolt | M6 | 3 | 8 Nm |
| | Crankcase | 1st tightening | Bolt | M8 | 4 | 15 Nm |
| | | 2nd tightening | | | | 30 Nm |
| | | 1st tightening | Bolt | M6 | 6 | 6 Nm |
| | | 2nd tightening | | | | 12 Nm |
| | Connecting rod | 1st tightening | Bolt | M7 | 2 | 10 Nm |
| | | 2nd tightening | | | | 21Nm |
| | Oil pressure switch | | — | — | 1 | 18 Nm |
| Driven belt pulley | | Bolt | M6 | 1 | 13 Nm | |
| Timing pulley | | Nut | M28 | 1 | 54 Nm | |

| | | | | | |
|-------------------|--------------------------|------|-----|---|--------|
| Lower unit | Lower unit mounting | Bolt | M8 | 4 | 18 Nm |
| | Lower unit housing cover | Bolt | M6 | 2 | 8Nm |
| | Anode | Bolt | M6 | 1 | 8 Nm |
| | Water pump housing | Bolt | M8 | 4 | 18 Nm |
| | Water pump base | Bolt | M8 | 2 | 18 Nm |
| | Water inlet | Bolt | M5 | 2 | 5 Nm |
| | Oil drain bolt | Bolt | M8 | 1 | 9 Nm |
| | Oil filler hole | Bolt | M8 | 2 | 9 Nm |
| | Pinion | Nut | M8 | 1 | 25 Nm |
| | Propeller nut | Nut | M10 | 1 | 17 Nm |
| Upper Unit | Steering handle mounting | Bolt | M8 | 1 | 18 Nm |
| | Shift lever bracket | Bolt | M6 | 1 | 4.5 Nm |
| | Clamp bracket | Nut | M8 | 1 | 13 Nm |
| | Oil drain bolt | Bolt | M14 | 1 | 27 Nm |
| Ignition assy | | Bolt | M6 | 2 | 8 Nm |

General torque

| Nut (a) | Bolt (b) | Torque |
|---------|----------|--------|
| 8mm | M5 | 5Nm |
| 10mm | M6 | 8 Nm |
| 12mm | M8 | 18 Nm |
| 14mm | M10 | 36 Nm |
| 17mm | M12 | 43 Nm |



PERIODIC SERVICE MAINTENANCE TIME TABLE

| Items | Contents | Initial maintenace | | General maintenance period | |
|-----------------------------|--|----------------------|------------------------|----------------------------|-----------------------|
| | | 10 hours (month) | 50 hours (3 months) | 100 hours (6 months) | 200 hours (1 year) |
| Anode | Inspection/ replacement | | | | |
| Spark plug | Cleaning/ adjustment / replacement | | | | |
| Grease points | Greasing | | | | |
| Bolts and nuts | Inspection | | | | |
| Fuel filter | Inspection/ replacement | | | | |
| Fuel tank | Inspection/ cleaning | | | | |
| Throttle cable | Inspection/ adjustment/ replacement | | | | |
| Idling speed | Inspection/ adjustment | | | | |
| Start-in-gear projection | Inspection/ adjustment | | | | |
| Engine oil | Replacement | | | | |
| Oil filter | Replacement | | | | |
| Valve clearance (OHC) | Inspection/ adjustment | | | | |
| Ignition timing | Inspection | | | | |
| Thermostat | Inspection | | | | |
| Cooling water passage | Inspection/ Cleaning | | | | |
| Gear oil | Replacement | | | | |
| Water pump | Inspection | | | | |
| Propeller | Inspection/ replacement | | | | |
| Timing belt | Inspection/ replacement | | | | |

CAUTION:

After running the outboard engine in salt water, waste water or mud water, wash over the engine by fresh water immediately.

If using leaded gasoline frequently, check the valve and components each 100 hours.

Timing belt should be changed every 1000 hours (5 years).


FUEL SYSTEM

1. CHECK FUEL TANK, CARBURETOR, FUEL PUMP AND FUEL PIPE

Check if fuel tank, carburetor, fuel pump and fuel pipe are damaged or leaked.

Replace if necessary.

Check if the fuel filter on the tank is dirty. Clean dirt or replace if necessary.



2. CHECK FUEL COCK AND FUEL JOINT

Check if fuel cock and fuel joint are cracked, damaged or leaking.

Replace if necessary.

3. CHECK FUEL FILTER

Check if fuel filter is cracked, damaged or has dirt inside.

If so, replace.




CAUTION:

Clean the spilled fuel.

POWER UNIT


Engine oil level

1. Remove oil rule, check engine oil level, if between the following marks of the upper and lower.



1. Oil rule

2. High position mark



3. Low position mark

2. If above the upper mark, drain the engine oil; if below lower mark, add engine oil up to upper mark.



CAUTION:

Run the engine and then turn it off, wait for several minutes, and check the engine oil level by the oil rule again.

If the engine oil still not within the proper level, add/drain as needed.

Changing engine oil

1. Remove oil level plug, drain plug with washer and gasket; drain off the engine oil.



2. Install new bolt and washer; install drain plug .

3. Fill engine oil through oil filler hole.

Engine oil quantity: 1.0 L (Before changing oil filter)
1.2 L (After changing oil filter)

Oil type: API SE, SF, SE-SF, SG-CD SAE 10W30, 10W40

4. Install oil level plug.

5. Check engine oil level.

Valve clearance

1. Remove stopper hang rope from engine stop switch assy.

Remove spark plug cap from spark plug.

2. Remove starter and belt cover.

3. Remove fuel pump and cylinder cover.

4. Rotate the flywheel clockwise to make the mark “1” on driven pulley align with the mark “ ” on the cylinder head.

Check the clearance between the intake and exhaust valves of the upper cylinder. Adjust it if necessary.

5. Rotate the flywheel clockwise to make the mark “2” on driven pulley align with the mark “ ” on the cylinder head.

Check the clearance between the intake and exhaust valves under the lower cylinder. Adjust it if necessary.

CAUTION:

Don't rotate the flywheel counter clockwise in case the valve system is damaged.

NOTE:

Adjust the valve clearance when the engine is cold.

| | | |
|------------------------------------|---------------|-------------|
| Valve clearance (cold position) | Intake valve | 0.15~0.25mm |
| | Exhaust valve | 0.20~0.30mm |

6. Loose lock nut, rotate adjusting bolt to reach the specified valve clearance.

NOTE:


Rotate adjusting bolt clockwise to reduce the valve clearance.

Rotate adjusting bolt counter clockwise to increase the valve clearance.

7. Re-assemble the spare parts.

Spark plug

1. Remove spark plug cap and spark plug.
2. Clean off carbon build-up on the electrodes.
3. Check if the electrodes are corroded or have deposit, or if the washer is damaged. If necessary, change the spark plug.
Spark plug type : DPR7HS
4. Inspect if the spark plug gap is within specification. If necessary, change the spark plug.




5. Install spark plug. Use spark plug spanner to tighten it according to specified torque.
Specified torque: 18 Nm

CONTROL SYSTEM

Throttle grip

Recoil start type


1. Turn the throttle grip to fully closed position.
2. Check if the throttle cable is slack, if the throttle lever touches the throttle stop screw, or if the arresting stop on the throttle accelerograph enforce touches the check plate on the fixed mount.
3. Loosen the throttle cable adjusting screw, adjust the throttle cable position, and tighten throttle cable adjusting screw.



1. throttle cable stop screw


Electric start type

1. Turn the gear shift lever to neutral position.
2. Check if the arresting stop on the throttle accelerator enforce touches the check plate on the bracket.



1. check plate 2. arresting stop

3. Loosen the lock nut and take out the cotter pin, then remove the cable joint.



1. cotter pin 2. cable joint 3. lock nut

4. Adjust the joint position to make the joint hole align with the pin on the throttle accelerator enforce.

CAUTION:

The cable joint must be screwed in for over 8mm.

5. Fit on the cotter pin and tighten the lock nut.

Idling speed

Check idling speed, and adjust it if necessary.

1. Preheat engine for 5 minutes.
2. Attach the tachometer to the spark plug wire to measure idling speed RPM. If out of specification, adjust it.
Idling speed: 900~1000 r/min

- Turn the throttle stop screw clockwise or counter clockwise, until the specified idling speed is attained.

NOTE:

Turn clockwise to increase idling speed.


Turn counter clockwise to decrease idling speed.

If necessary, turn the idling speed screw on the carburetor clockwise or counter clockwise, until the specified idling speed is attained.

CAUTION:

Before adjusting the idling speed, the throttle cable should be properly adjusted.



After adjusting the idling speed, if necessary, you can adjust the throttle cable again.



1. throttle stop screw
2. idling speed screw

Start-in-gear protection

Set the shift lever in neutral, and check if the tightwire end of the arrester aligns with the marking of the starter. If necessary, adjust the adjusting nut on the tightwire of the arrester, to make the tightwire end align with the marking.



1. " N " marking 2. tightwire assy, arrester 3. adjusting nut

LOWER UNIT

Gear oil

Check gear oil level:

Remove the oil level plug screw. If the gear oil overflows, the oil level is correct; otherwise, add gear oil.




1. Oil level plug screw

Changing gear oil

- Hold the outboard engine in an upright position.
- Place a container with enough capacity under the outboard engine.

3) Remove the drain plug screw, the oil level plug screw, and then drain the gear oil.



1. Oil level plug screw 2. Drain plug screw

4) Add gear oil through the drain plug hole using pressure filling device.

5) When gear oil overflows through the oil level plug hole, install the oil level plug screw.

6) Install the drain plug screw, then clean overflowing gear oil.

NOTE:

Check the drained gear oil. If the gear oil is milky, check the oil seal. Replace the oil seal if necessary. If the gear oil contains metal chippings, check the gear and bearing.

CAUTION:

Must change drain plug washer each time.

Lower unit leakage check

Connecting the leakage tester to the oil level plug hole to check for the lower unit leakage. If the pressure drops (pressure: $1\text{kg}/\text{cm}^3$), inspect the oil seal and components.

GENERAL INSPECTION

Anode


Inspect lower unit anode and engine anode (on the thermostat cover). Clean the greasy dirt and scales. If wear or damage is above 1/2, replace the anode.

CAUTION :


Cannot grease or paint the anode, or it will not operate properly.

Grease points

1. Refer the illustration for greasing points, paint the water resistant grease.



2. Paint anti-corrosion grease on the propeller shaft.



Cooling water passage

1. Inspect cooling water passage, if blocked, clean it.



1. Cooling water passage inlet

2. Place the outboard engine in the water and ensure the water level is above the anti-vortex plate, then start the engine.

3. Check if water overflows at the cooling water checking hole. If there is no flow or intermittent flow, check the cooling water passage.



1. Cooling water inlet



2. Cooling water checking hole

Thermostat

1. Remove the thermostat cover and thermostat.
2. Hang the thermostat in a container with water.
3. Heat the container.
4. Check the valve open height under the specified water temperatures. If out of order, change it.

| Water temperature | Valve open height |
|-------------------|-------------------|
| Under 62 | 0.1mm |
| Over 70 | Over 3mm |


5. Fit on the thermostat and thermostat cover, then tighten the screws to specification.

RECOIL STARTER


NOTICE

When you service, always wear safety glasses and gloves. To prevent accidental start of the engine, remove the spark plug cap and remove stopper hang rope from stop switch assembly.


EXPLOSIVE DRAWING



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|-------------------------|-----------|---------------|
| 1 | F15-07130000 | 起动罩组件 STARTER ASSY | 1 | |
| 2 | F15-07130101 | 起动罩外壳 CASE, STARTER | 1 | |
| 3 | F15-07130300 | 起动架组合 FRAME, STARTER | 1 | |
| 4 | F4-04130013 | 起动绳导向管 COLLAR | 1 | |
| 5 | GB/T5783-M6x25 | 六角螺栓M6x25 BOLT M6x25 | 2 | |
| 6 | GB/T93-6 | 弹簧垫圈6 WASHER, SPRING | 1 | |
| 7 | GB/T5782-M6x90 | 六角螺栓M6x90 BOLT M6x90 | 1 | |
| 8 | GB/T6170-M6 | 六角螺母M6 NUT M6 | 1 | |
| 9 | F4-04130101 | 起动手柄 HANDLE, STARTER | 1 | |
| 10 | F4-04130102 | 起动手柄盖 COVER | 1 | |




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|------------------------------------|-----------|---------------|
| 11 | F15-07130305 | 橡胶堵头 GROMMET | 1 | |
| 12 | F15-05000028 | 制动器钢索组件 ARRESTER TIGHTWIRE ASSY | 1 | |
| 13 | F15-05000027 | 制动器钢索固定架 FRAME, ARRESTER TIGHTWIRE | 1 | |
| 14 | GB/T5783-M6x20 | 六角螺栓M6x20 BOLT M6x20 | 3 | |
| 15 | F15-07130304 | 发泡密封圈 SEAL, FROTHY RUBBER | 1 | |
| 16 | F15-07130201 | 起动轮 WHEEL, START-UP | 1 | |
| 17 | F15-07130107 | 涡形弹簧 SPRING, VOLUTE | 1 | |
| 18 | GB/T896-8 | 开口档圈8 CIRCLIP 8 | 1 | |
| 19 | F15-07130202 | 起动卡瓣 PAWL, DRIVE | 1 | |
| 20 | F15-07130204 | 卡瓣钢丝连杆 LINK, PAWL | 1 | |



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|---------------------|-----------|---------------------|
| 21 | F15-07130203 | 卡瓣拉簧 | 1 | SPRING, TENSION |
| 22 | F15-07130002 | 起动压板夹簧 | 1 | SPRING, DRIVE PLATE |
| 23 | F15-07130001 | 起动压板 | 1 | PLATE, DRIDE |
| 24 | GB/T5783-M6x16 | 六角螺栓M6x16 | 1 | BOLT M6x16 |
| 25 | F15-07130105 | 制动器 | 1 | ARRESTER |
| 26 | F15-07130102 | 带肩衬套 | 3 | BUSH, SHOULDER |
| 27 | F15-07130106 | 制动器扭簧 | 1 | SPRING, ARRESTER |
| 28 | GB/T97.1-6 | 平垫圈6 | 8 | WASHER PLATE |
| 29 | F15-05000029 | 制动器钢索拉簧 | 1 | TIGHTWIRE, SPRING |
| 30 | F15-07130205 | 起动绳 (4x1.78米) | 1 | START LING |


Electric start type



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|---|-----------|---------------|
| 1 | F15-07130306W | 阻风门手柄B HANDLE "B" | 1 | |
| 2 | F15-05010001 | 阻风门导向套 BUSH | 1 | |
| 3 | F15-07130308W | 护套定位板 PLATE | 1 | |
| 4 | F15-07130307W | 波纹护套B BUSH ,WAVE | 1 | |
| 5 | GB/T845-85 | 十字槽盘头自攻螺钉ST4.8×9 SCREW ,PAN HEAD ST4.8x9 | 1 | |
| 6 | F15-07130310W | 摇臂销轴 SHAFT ,ROCKER | 1 | |
| 7 | GB/T91-1.6x12 | 开口销1.6×12 COTTER PIN 1.6x12 | 1 | |
| 8 | F15-07130312W | 鞍形弹性垫圈5 WASHER ,SPRING SADDLE | 1 | |
| 9 | F15-07130311W | 尼龙垫圈5 WASHER ,NYLON | 2 | |
| 10 | F15-07130309W | 阻风门摇臂 ROCKER | 1 | |
| 11 | F15-07130314W | 阻风门接头 TIE-IN | 1 | |
| 12 | F15-07130313 | 阻风门连杆组件 LINK ROD ASS'Y | 1 | |


DISASSEMBLING

1. Open the top cowling.
2. Screw loosely the adjusting nut of the arrester tightwire.




1. Adjusting nut

3. Remove the tightwire from the arrester.
4. Remove the starter fixing bolts, and remove the starter.




STARTER ROPE REPLACEMENT

1. Pull the starter rope out, and insert it in the notch of the start-up wheel. Turn the start-up clockwise until the volute spring is free.



2. Pull the starter rope out completely.
3. Remove the starter handle cover from the starter handle, and remove the starter rope. Untie the knot at the end of the starter rope.
4. Pull out the starter rope from the start-up wheel completely.
5. Insert the new starter rope into the starter, and fix the starter rope onto the start-up wheel and starter handle. At the end of the rope tie a knot as shown.



6. Insert the start rope in the notch of the start-up wheel and turn the start-up wheel several rounds in counter clockwise direction.
7. Pull the starter handle many times to check if the start-up wheel rotates stably. If necessary, repeat step 6 and step 7.

DISASSEMBLING AND INSPECTION


Recoil start type

1. Remove the start rope and start frame assy.
2. Remove drive plate screw, and remove the drive plate and drive plate spring.
3. Remove the start-up wheel.

WARNING:

Uninstall the start-up wheel carefully, to ensure that the volute spring does not pop out to hurt people.


4. Remove the volute spring.
5. Remove the arrester and arrester spring.
6. Inspect if the arrester is cracked, worn or damaged. Replace if necessary.




7. Inspect if the drive pawl is cracked, worn or damaged. Replace if necessary.



8. Check if the tension spring and pawl link are cracked, cranked or damaged. Replace if necessary.



9. Check if the volute spring is broken, cranked or damaged. Replace if necessary.



Electric start type



1. Remove the link rod assy of chock valve.
2. Remove the cotter pin and rocker shaft.
3. Remove the rocker.
4. Remove the bush plate, guide bush and chock valve handle.
5. Check if the link rod assy is cranked or deformed. Replace if necessary.
6. Check if the chock valve rocker and handle are cracked or damaged. Replace if necessary.

ASSEMBLING

Reverse the steps of disassembling starter.

INSTALLATION

1. Put starter onto the power unit.
2. Screw the hexagon bolt, and tighten it according to the specified torque.
3. Install the arrester tightwire.
4. Adjust the adjusting nut on the tightwire of the arrester, and align the arrester tightwire end with the marking of the starter case.



1. " " marking 2. Arrester tightwire 3. Adjusting nut

IGNITION SYSTEM

NOTICE


When checking and repairing the ignition system, keep your hand, clothes, hair or personal belongings away from the rotating flywheel.

Check ignition coil on insulated working table, to prevent electricity leak and electroshock.


Don't touch the ignition coil or spark plug when the engine is running, to avoid electroshock. Keep the wires away from the rotating flywheel, to prevent the wire from being cut, or the insulating layer of the wire from being worn.

When replacing fixing parts such as nuts and bolts, only parts from original manufacturer or parts made of same material and with strength can be used. Parts must be tightened according to the specified torques.


EXPLOSIVE DRAWING



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|-------------------------------------|-----------|---------------|
| 1 | F15-07060001 | 整流器组件 RECTIFIER & REGULATOR ASSY | 1 | |
| 2 | F15-07060004 | 衬管 LINER | 4 | |
| 3 | F15-07060003 | 减震圈 GASKET , SHOCK ABSORPTION | 4 | |
| 4 | GB/T5783-M6x25 | 六角螺栓M6 × 25 HEXAGON BOLT M6 × 25 | 4 | |
| 5 | GB/T97. 1-6 | 平垫圈6 WASHER | 6 | |
| 6 | F15-07060005 | 方形线卡B QUADRATE CLAMP | 2 | |
| 7 | F15-07060002 | 整流器支座 BRACKET , RICTIFIER | 1 | |
| 8 | GB/T5783-M6x16 | 六角螺栓M6 × 16 HEXAGON BOLT M6 × 16 | 1 | |
| 9 | GB/T5783-M6x16 | 六角螺栓M6 × 12 HEXAGON BOLT M6 × 12 | 1 | |




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|--|-----------|---------------|
| 1 | F15-07000006 | 飞轮螺母 NUT, FLYWHEEL | 1 | |
| 2 | F15-07000005 | 飞轮螺母垫圈 WASHER, FLYWHEEL NUT | 1 | |
| 3 | F15-07070000 | 飞轮组件 FLYWHEEL ASSY | 1 | |
| 4 | GB/T5783-M6x25 | 六角头螺栓M6×25 HEXAGON BOLT M6×25 | 2 | |
| 5 | GB93-6 | 弹簧垫圈6 WASHER, SPRING | 2 | |
| 6 | GB/T97.1-6 | 平垫圈6 WASHER | 8 | |
| 7 | GB/T5783-M6x30 | 六角头螺栓M6×30 HEXAGON BOLT M6×30 | 4 | |
| 8 | F15-07000400 | 充电线圈A、B组合 COIL, CHARGE "A"&"B" ASSY | 1 | |
| 9 | F4-07000300 | 磁电机线圈组合 COIL | 1 | |
| 10 | F15-07000004 | 飞轮半圆键 KEY, SEMISIRCLE FLYWHEEL | 1 | |
| 11 | GB/T5783-M6x16 | 六角头螺栓M6×16 HEXAGON BOLT M6×16 | 2 | |
| 12 | F15-07000200 | 触发线圈组件 COIL, PULSER | 1 | |




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|--|-----------|---------------|
| 13 | F15-07130303 | 机油指示灯组件 EMERGENCY SIGNAL LIGHT ASSY | 1 | |
| 14 | F15-07000600 | 高压包组件 HIGH PRESSURE ASSY | 1 | |
| 15 | GB/T5783-M6x20 | 六角头螺栓M6×20 HEXAGON BOLT M6×20 | 4 | |
| 16 | GB/T97.1-6 | 平垫圈6 WASHER | 4 | |
| 17 | F15-07000003 | 波纹管φ27×φ22.5×71 RIPPLE TUBE | 1 | |
| 18 | F15-07000500 | 点火控制模块 C. D. I. UNIT ASSY | 1 | |
| 19 | F15-07010103 | 机油压力传感器 OIL PRESSURE SENSOR | 1 | |
| 20 | F15-07010101 | 绝缘护套 JACKET, INSULATION | 1 | |
| 21 | F15-07010102 | 导线组件 LEAD WIRE ASSY | 1 | |
| | | | | |
| | | | | |
| | | | | |

Electric start type




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|----------------------------------|-----------|---------------|
| 1 | F15-07070100W | 飞轮组件 FLYWHEEL ASSY | 1 | |
| 2 | F15-07150100W | 启动电机 STARTUP MOTOR | 1 | |
| 3 | GB/T5782-M8x50 | 六角头螺栓M8x50 HEXAGON BOLT M8x50 | 1 | |
| 4 | GB/T97.1-8 | 平垫圈8 WASHER 8 | 3 | |
| 5 | F25-05170001W | 电机固定螺栓M8 FIXATION BOLT, MOTOR | 1 | |
| 6 | F15-07150002W | 柱状螺栓M8 COLUMNAR BOLT | 1 | |
| 7 | F25-05010402W | 出水嘴 WATER GAP | 1 | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|---|-----------|---------------|
| 1 | F15-07150301W | 继电器护套 RELAY JACKET | 1 | |
| 2 | F15-07150300W | 继电器 RELAY | 1 | |
| 3 | F15-07150200W | 电源连接线 LINE, POWER SOURCE | 1 | |
| 4 | F25-05170201W | 电源连接线护套A COVERING A, POWER SOURCE LINE | 1 | |
| 5 | F25-05170202W | 电源连接线护套B COVERING B, POWER SOURCE LINE | 1 | |
| 6 | GB/T6170-M8 | 六角螺母M8 HEXANGULAR NUT M8 | 2 | |
| 7 | F15-07150500W | 电机连接线 CONNECTION LINE, MOTOR | 1 | |
| 8 | F15-07150501W | 电机连接线护套 JACKET, CONNECTION LINE | 2 | |
| 9 | GB/T97.1-6 | 平垫圈 6 WASHER 6 | 4 | |
| 10 | GB/T6170-M6 | 六角螺母M6 HEXANGULAR NUT M6 | 2 | HSn62-1 |
| 11 | GB/T97.1-8 | 平垫圈 8 WASHER 8 | 4 | |
| 12 | F25-05090100W | 熔断器组件 (JEF-709J) FUSE ASSY | 1 | |
| 13 | F15-07150001W | 保险丝20A FUSE | 1 | |

WIRING DIAGRAM



- | | | | |
|-----------------|--------------------|----------------------|---------------|
| 1 CDI | 4 Oil press switch | 7 Engine stop switch | 10 Spark plug |
| 2 Lighting coil | 5 Pulsed coil | 8 Grounding wire | |
| 3 Charge coil | 6 Ignition coil | 9 Oil alert light | |

Wire beam color:

| | | | | | |
|----------|--------|-----------|--------|------------|------------|
| W | White | O | Orange | Y/R | Yellow/Red |
| B | Black | L | Blue | R/W | Red/White |
| R | Red | G | Green | | |
| Y | Yellow | Br | Brown | | |

SPARK PLUG IGNITION

1. Remove spark plug cap from spark plug.
2. Connect the ignition tester to the spark plug cap.
3. Start the engine, and observe the sparks through the discharge window of the tester.

⚠ WARNING:

Do not touch any joint part of the lead wire of the tester. Keep away from inflammable gas or liquid, to prevent accident resulting from spark ignition.

SPARK PLUG CAP

1. Remove the spark plug cap. Check if the spark plug cap is broken. Replace if necessary.
2. Install the spark plug cap.
Turn it clockwise until it is tight.

FLYWHEEL MAINTENANCE

1. Use flywheel gripper to remove the nut and starter bush; use flywheel puller to remove flywheel.



2. Check if the flywheel is damaged or the permanent magnet part is firm. Replace if necessary.

CDI INSPECTION

CDI PEAK VOLTAGE

Use the digital circuit tester and peak voltage adaptor to measure CDI peak voltage. If below the specification, check the lead wire and measure the impulse and peak voltage output of the charge coil.



Digital circuit tester



Peak voltage adaptor

| | | |
|----------------------------|--------------|-------|
| CDI peak voltage output | Start (load) | 155V |
| | 1500r/min | 170 V |
| | 3500r/min | 170 V |

NOTE:

If the impulse and peak voltage output of the charge coil are just same as or above the specification, and the CDI peak voltage output is below the specification, replace the CDI.

IGNITION COIL INSPECTION

1. Remove the ignition coil and spark plug cap.
2. Measure ignition coil resistance. Replace if out of the specification.

| | |
|-------------------------|--|
| Resistance: 0.16 ~ 0.25 | (Tester (+) pole: orange wire; Tester (-) pole: black wire) |
| 3.92 ~ 6.65k | (Tester (+) pole: orange wire; Tester (-) pole: high-voltage wire) |

PULSED COIL INSPECTION

1. Pulsed coil peak voltage

Use the digital circuit tester and peak voltage adaptor to measure the peak voltage. If below the specification, check the pulsed coil resistance.



Digital circuit tester

Peak voltage adaptor

| | | |
|--------------------------|------------------|-----|
| Pulsed coil peak voltage | Start (no-load) | 4.0 |
| | Start (load) | 4.0 |
| | 1500r/min (load) | 9 |
| | 3500r/min (load) | 17V |

2. Pulsed coil resistance

Measure the pulsed coil resistance. Replace if out of specification, replace.

Resistance: 234 ~ 348 (Tester (+) pole: red/white wire; Tester (-) pole: black wire)

CHARGE COIL INSPECTION

1. Charge coil peak voltage

Use the digital circuit tester and peak voltage adaptor to measure the peak voltage. If below the specification, check the charge coil resistance.



Digital circuit tester


Peak voltage adaptor

| | | |
|--------------------------|-----------------|------|
| Charge coil peak voltage | Start (no-load) | 175V |
| | Start (load) | 170V |
| | 1500rmp | 180V |
| | 3500rmp | 180V |


2. Charge coil resistance

Measure charge coil resistance. Replace if out of specification.


Resistance: 272 ~ 408 (Tester (+) pole: brown wire; Tester (-) pole: blue wire)




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|---------------------|--|-----------|---------------|
| 13 | GB/T93-6 | 弹簧垫圈6 WASHER, SPRING 6 | 2 | |
| 14 | GB/T97.1-6 | 平垫圈6 WASHER, PLATE 6 | 3 | |
| 15 | F15-07080001 | 滤网罩 ELEMENT, FILTER | 1 | |
| 16 | GB/T3452.1-32.5x1.8 | 滤杯密封圈 32.5x1.8 WASHER, CUP FILTER | 1 | |
| 17 | F15-07080002 | 滤杯 CUP, FILTER | 1 | |
| 18 | GB/T818-M4x30 | 十字槽盘头螺钉 M4x30 SCRRW, PAN HEAD M4x30 | 4 | |
| 19 | F4-04090004 | 上隔膜 DIAPHRAGM, TOP | 1 | |
| 20 | F4-04090011 | 阀片螺钉M3x5 SCRRW, VALVE M3x5 | 2 | |
| 21 | F4-04090005 | 单向阀片 PLATE | 2 | |
| 22 | F15-07140002 | 燃油泵壳 FUEL PUMP SHELL | 1 | |
| 23 | F15-07140100 | 隔膜组件 DIAP HRAGM ASSY | 1 | |
| 24 | GB/T309-3x12 | 滚针 3x12 ROLLER NEEDLE | 1 | |



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|-----------------------------|-----------|---------------|
| 25 | F15-07140005 | 隔膜弹簧 SPRING, DIAP HRAGEM | 1 | |
| 26 | F15-07140004 | 柱塞弹簧 SPRING, PLUNGER | 1 | |
| 27 | F15-07140003 | 柱塞 PLUNGER | 1 | |
| 28 | GB/T6170-20000 | 六角螺母 M4 NUT M4 | 4 | |
| 29 | F4-04090003 | 燃油泵盖 COVER, FUEL PUMP | 1 | |
| 30 | F15-07140001 | 燃油泵座 SEAT, FUEL PUMP | 1 | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|-------------------|--------------------------------|-----------|---------------|
| 1 | F15-07000008 | 进气歧管 MANIFOLD, INTAKE | 1 | |
| 2 | F15-07000007 | 进气歧管密封垫片 GASKET, MANIFOLD | 1 | |
| 3 | F15-00000006 | 定位销 6x12 PIN, DOWEL 6x12 | 2 | |
| 4 | F15-07000017 | 化油器纸垫 GASKET, CARBURETOR | 2 | |
| 5 | F15-07000018 | 化油器绝缘垫 INSULATOR, CARBURETOR | 1 | |
| 6 | F15-05010003 | 阻风门杆接头 JOINT, CHOKE LEVER | 1 | |
| 7 | F15-05010001 | 阻风门导向套 CASE, STARTER | 1 | |
| 8 | F15-05010100 | 阻风门杆组件 ROD, CHOKE | 1 | |
| 9 | F15-07100000 | 进气消音器组件 SILENCER ASSY, INTAKE | 1 | |
| 10 | GB3452.1-35.5x1.8 | O型圈35.5x1.8 O-RING 35.5x1.8 | 1 | |
| 11 | GB/T5782-M6x100 | 六角螺栓M6x100 HEXAGON BOLT M6x100 | 2 | |
| 12 | GB/T97.1-6 | 平垫圈6 WASHER, PLATE 6 | 6 | |



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|---------------------------------|-----------|---------------|
| 13 | F15-07000021 | 进气消声器衬管 BUSHER, INTAKE SILENCER | 2 | |
| 14 | F15-07000022 | 进气消声器垫板 PLATE, INTAKE SILENCER | 1 | |
| 15 | F15-07010017 | 呼吸器弯管 PIPE, BREATHER | 1 | |
| 16 | F15-07010016 | 管卡 B CLAMP B | 1 | |
| 17 | F15-07010015 | 管卡 A CLAMP A | 1 | |
| 18 | F15-07090000 | 化油器 CARBURETOR | 1 | |
| 19 | GB/T5783-M6x40 | 六角螺栓M6 × 40 BOLT M6 × 40 | 4 | |
| 20 | F15-07000009 | 滤油杯支架 BRACKET ,OIL SIEVE | 1 | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

Electric start type



| 参照号码 | 零件编号 | 零件名称 | 数量 | 备注 |
|------|----------------|------------------------------------|-----|---------|
| SN. | PART NO. | DESCRIPTION | QTY | REMARKS |
| 1 | F4-0200011 | 变档轴密封圈 SEAL, SHAFT | 1 | |
| 2 | F15-1103000W | 电磁吸铁组件 ELECTROMAGNETIC MAGNET ASSY | 1 | |
| 3 | F15-11030301W | 铁芯 IRON CORE | 1 | |
| 4 | F15-11030302W | 铁芯连杆 LINK RAD, IRON CORE | 1 | |
| 5 | F15-11030303W | 铁芯拉头 HOOK, IRON CORE | 1 | |
| 6 | F15-11030300W | 吸铁铁芯组件 IRON CORE ASSY | 1 | |
| 7 | GB/T5783-M6x12 | 六角螺栓M6x12 BOLT, HEXAGON M6x12 | 2 | |
| 8 | GB/T97.1-6 | 平垫圈6 WASHER 6 | 2 | |
| 9 | F15-07090000W | 化油器总成 CARBURETOR | 1 | |
| | | | | |
| | | | | |
| | | | | |

THROTTLE CONNECTING ROD ADJUSTMENT

1. Turn throttle accelerator enforce to full opening position.

Turn carburetor throttle rod to full opening position.


- 1 . Throttle accelerator enforce
- 2 . Carburetor throttle rod
- 3 . Lock screw



2. In full opening position, tighten the throttle rod lock screw.

FUEL JOINT REMOVAL AND INSPECTION

1. Remove the bolts fixing the fuel joint.
2. Remove the fuel joint.
3. Inspect the fuel joint for crack or damage.




4. Connect the fuel joint exit with a vacuum pressure gauge.
5. Check whether the negative pressure can be maintained for over 10 minutes under the prescribed pressure. Replace if necessary.
Prescribed pressure: 50kPa.

FUEL PUMP REMOVAL AND INSPECTION

1. Remove the bolts fixing the fuel pump.
2. Remove the fuel pump.
3. Connect the fuel pump intake with a vacuum pressure gauge.
4. Block the exit of fuel pump with finger, and force a prescribed positive pressure to check for leakage.
Prescribed pressure: 50kPa
5. Force a prescribed negative pressure and check for leakage.
Prescribed pressure: 50kPa
6. Connect the fuel pump exit with a vacuum pressure gauge.

7. Force a prescribed negative pressure and check for leakage. Disassemble the fuel pump to check if necessary.
Prescribed pressure: 50kPa
8. Remove four bolts, and separate fuel pump cover from fuel pump seat.
9. Remove the valve screw from fuel pump, and remove the valve plate.
10. Press the plunger and diaphragm, rotate the fuel pump seat, and align the notch with the notch on the plunger. Take the roller needle out.
11. Inspect the diaphragm for crack and valve for damage. Replace if necessary.




12. Reverse above step 8 to step 10 to install the fuel pump.

FILTER INSPECTION

Check if the filter element is clogged or with foreign matter. Check the filter cup for damage or leakage. Use gasoline to clean it, or replace if necessary.

NOTE:

Coat a layer of gasoline onto the O-ring before installing the filter cup.




POWER UNIT


NOTICE

To avoid accidental start of outboard engine during maintenance, please take enough safety measures to disconnect the ignition system. For instance, remove the engine stop lanyard from engine stop switch assembly, and remove spark plug cap from spark plug.


EXPLOSIVE DRAWING




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|---------------------|-----------|---------------------|
| 1 | GB/T1099-1979 | 正时带轮半圆键 | 1 | KEY, WOODRUFF |
| 2 | F15-07010027 | 带轮罩橡胶圈 B | 1 | RUBBER RING B |
| 3 | F15-07030003 | 正时带轮 | 1 | BELT PULLEY, TIMING |
| 4 | F15-07030004 | 正时带轮盖板 | 1 | WASHER |
| 5 | F15-07030005 | 正时带轮螺母 | 1 | NUT |
| 6 | F15-07000002 | 正时皮带 | 1 | BELT, TIMING |
| 7 | F15-07000024 | 皮带罩壳 | 1 | COVER, DUST |
| 8 | F15-07050003 | 带轮罩橡胶圈 A | 2 | RING RUBBER A |
| 9 | GB/T5783-M6x16 | 六角螺栓M6x16 | 1 | BOLT M6x16 |
| 10 | GB/T5287-6 | 特大垫圈6 | 1 | BIG WASHER 6 |
| 11 | F15-07040018 | 从动带轮 | 1 | BELT PULLEY, DRIVEN |
| 12 | F15-07040017 | 从动齿轮垫圈 | 1 | WASHER |
| 13 | F15-07040008 | 油封 18X35X7-R | 1 | OIL SEAL 18X35X7-R |
| 14 | F15-07040200 | 凸轮轴组件 | 2 | CAMSHAFT ASSY |
| 15 | F15-07040016 | 机油泵密封垫 | 4 | MAT, QIRPROOF |
| 16 | F15-07040500 | 机油泵总成 | 1 | OIL PUMP ASSY |
| 17 | GB/T5783-M6x35 | 六角螺栓M6x35 | 3 | BOLT M6x35 |
| 18 | GB/T97.1-6 | 平垫圈6 | 3 | WASHER 6 |




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|---------------------------------------|-----------|---------------|
| 1 | F15-07000015 | 油门控制器连杆 LINK , ACCELEROGRAPH CONTROL | 1 | |
| 2 | F15-07000016 | 油门控制器连杆接头 JOINT ACCELEROGRAPH CONTROL | 1 | |
| 3 | GB/T5782-M6x55 | 六角螺栓M6 × 55 BOLT M6 × 55 | 1 | |
| 4 | GB/T97.1-6 | 平垫圈6 WASHER 6 | 5 | |
| 5 | GB/T96-6 | 大垫圈6 LARGE WASHER 6 | 1 | |
| 6 | F15-07000012 | 油门执行器衬管 BUSH , ACCELEROGRAPH ENFORCE | 1 | |
| 7 | F15-07000014 | 油门执行器从动滑轮 PULLEY , PASSIVITY | 1 | |
| 8 | F15-07000013 | 油门执行器主动滑轮 PULLEY , DRIVE | 1 | |
| 9 | GB/T5783-M6x10 | 六角螺栓M6 × 10 BOLT M6 × 10 | 1 | |
| 10 | F15-07000011 | 控制钢索固定架 BRACKET , CONTROL TIGHTWIRE | 1 | |
| 11 | GB/T5783-M6x25 | 六角螺栓M6 × 25 BOLT M6 × 25 | 1 | 电起动型 |
| 12 | GB/T5287-6 | 特大垫圈6 BIG WASHER 6 | 1 | 电起动型 |
| 13 | F25-03000027W | 换挡限位板 PLATE , SHIFT | 1 | 电起动型 |
| 14 | F25-03000028W | 限位板衬管 BUSH , LIMITED PLATE | 1 | 电起动型 |
| 15 | F15-05040103W | 换挡连接杆 LINK ROD , SHIFT | 1 | 电起动型 |
| 16 | F15-00000012 | 夹簧 1.8 SPRING | 1 | 电起动型 |
| 17 | GB/T96-5 | 大垫圈5 BIG WASHER 5 | 1 | 电起动型 |




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|------------------------------------|-----------|---------------|
| 1 | F15-07040100 | 气缸头组件 CYLINDER HEAD ASSY | 1 | |
| 2 | F15-07000001 | 空心定位销 10x 8.4x14 HOLLW PIN | 2 | |
| 3 | F15-07000100 | 气缸垫组合 GASKET, CYLINDER HEAD | 1 | |
| 4 | F15-07040104 | 气门导管 VALVE GUIDE BUSH | 4 | |
| 5 | F15-07040105 | 气门导管卡圈 CIRCLIP, GUIDE BUSH | 4 | |
| 6 | GB/T5783-M6x25 | 六角头螺栓M6X25 BOLT, HEXAGON M6X25 | 3 | |
| 7 | F15-07000028 | 六角头凸缘螺栓M8X75 BOLT, FLANGE M8X75 | 6 | |
| 8 | F15-07050001 | 气缸头罩 COVER, CYLINDER HEAD | 1 | |
| 9 | F15-07050002 | 气缸头罩密封圈 SEAL, CYLINDER COVER | 1 | |
| 10 | GB/T5783-M6x20 | 六角头螺栓M6X20 BOLT, HEXAGON M6X20 | 4 | |
| 11 | GB/T97.1-6 | 平垫圈6 WASHER, PLATE 6 | 7 | |
| 12 | F15-07050004 | 加油口盖 PLUG, OIL | 1 | |
| 13 | JA80 F404 31-025 | 加油口盖O形密封圈 O-RING | 1 | |
| 14 | DPR7HS | 火花塞 SPARK PLUG | 2 | |




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|--------------------------------|-----------|---------------|
| 1 | F15-07040001 | 进气门 VALVE, INTAKE | 2 | |
| 2 | F15-07040002 | 排气门 VALVE, EXHAUST | 2 | |
| 3 | F15-07040004 | 气门弹簧垫板 SEAL, VALVE SPRING | 4 | |
| 4 | PS2700.04.03 | 气门油封 SEAL, VALVE STEM | 4 | |
| 5 | F15-07040005 | 气门弹簧 SPRING, VALVE | 4 | |
| 6 | F15-07040006 | 气门弹簧座 RETAINER, VALVE SPRINGRE | 4 | |
| 7 | F15-07040007 | 气门弹簧卡圈 COTTER, VALVE | 8 | |
| 8 | F15-07040304 | 锁紧螺母 LOCK NUT | 4 | |
| 9 | F15-07040303 | 调整螺钉 SCREW, VALVE ADJUSTING | 4 | |
| 10 | F15-07040301 | 摇臂 ROCKER | 4 | |
| 11 | F15-07040014 | 摇臂轴弹簧B SPRING, ROCKER B | 3 | |
| 12 | F15-07040009 | 进气门垫管 BUSHER, VALVE INTAKE | 1 | |
| 13 | F15-07040013 | 摇臂轴弹簧A SPRING, ROCKER A | 1 | |
| 14 | F15-07040015 | 摇臂轴 SHAFT, ROCKER | 2 | |
| 15 | F15-07040012 | 排气门垫管B BUSHER, VALVE EXHAUST B | 1 | |
| 16 | F15-07040011 | 排气门垫管A BUSHER, VALVE EXHAUST A | 1 | |




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|-------------------------------|-----------|---------------|
| 1 | F15-07010000 | 机体机座组件 CRANKCASE ASSY | 1 | |
| 2 | F15-07000001 | 空心定位销 10x14PIN, HOLLOW | 2 | |
| 3 | GB/T5783-M6x35 | 六角螺栓M6X35 BOLT, HEXAGON M6X35 | 6 | |
| 4 | GB/T5783-M8x35 | 六角螺栓M8X55 BOLT, HEXAGON M8X55 | 4 | |
| 5 | F15-07010006 | 吸油管接头 PIPE, JOINT | 2 | |
| 6 | F15-07010008 | 机体阳极 ANODE | 1 | |
| 7 | F15-07010011 | 阳极盖板 COVER, ANODE | 1 | |
| 8 | F15-07010009 | 阳极密封圈 GROMMET, ANODE | 1 | |
| 9 | GB/T5783-M5x12 | 十字槽盘头螺钉M5X12SCREW, PAN HEAD | 1 | |
| 10 | GB/T97.1-5 | 平垫圈5 WASHER 5 | 1 | |
| 11 | GB/T97.1-8 | 平垫圈8 WASHER 5 | 4 | |
| 12 | F15-07010012 | 阳极锁止片 PLATE, ANODE | 1 | |



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|--------------------------------------|-----------|---------------|
| 13 | F15-07010013 | 呼吸器本体 COVER, BREATHER | 1 | |
| 14 | GB/T5783-M6x20 | 六角螺栓M6X20 BOLT M6X20 | 4 | |
| 15 | GB/T97.1-6 | 平垫圈6 WASHER 6 | 17 | |
| 16 | F15-07010014 | 呼吸器密封圈 BREATHER GASKET | 1 | |
| 17 | F15-04000036 | 节温器 THERMOSTAT | 1 | |
| 18 | F15-07010022 | 节温器盖垫 GASKET, THERMOSTAT | 1 | |
| 19 | F15-07010021 | 节温器盖 COVER, THERMOSTAT | 1 | |
| 20 | GB/T5783-M6x30 | 六角螺栓M6X30 BOLT M6X30 | 7 | |
| 21 | F15-07010018 | 排气盖板垫 GASKET, EXHAUST OUTER COVER | 1 | |
| 22 | F15-00000013 | 定位销 4x12 PIN | 2 | |
| 23 | GB/T820-M4x12 | 十字半沉头螺钉M4X12 SCREW | 1 | |
| 24 | F15-07010026 | 排气盖板阳极 ANODE | 1 | |




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|----------------------------------|-----------|---------------|
| 25 | F15-07010019 | 排气盖板 OUTER COVER, EXHAUST | 1 | |
| 26 | F15-04000005 | 水嘴 WATER NIPPLE | 3 | |
| 27 | F15-05000012 | 水管 A 10x 5x67 HOSE A | 1 | |
| 28 | F15-05000011 | 三通 THREE-WAY PIPE | 1 | |
| 29 | F15-05000013 | 水管 B 10x 5x172 HOSE B | 1 | |
| 30 | F15-05000014 | 水管 C 10x 5x300 HOSE C | 1 | |
| 31 | F15-07010003 | 机滤螺柱 BOLT UNION | 1 | |
| 32 | F15-07010023 | 机油滤清器 OIL CLEANER | 1 | |
| 33 | F15-00000014 | 发动机密封垫 GASKET, ENGINE | 1 | |
| 34 | F15-07010007 | 回油管 10x 5x70 HOSE, RETURN OIL | 1 | |
| | | | | |
| | | | | |




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|----------------------------------|-----------|---------------|
| 1 | F15-07030000 | 曲轴组件 CRANK ASSY | 1 | |
| 2 | F15-07030006 | 曲轴油封 A 25x40x6.5-L OIL SEAL A | 1 | |
| 3 | F15-07010024 | 轴瓦 MAIN BEARING | 4 | |
| 4 | F15-07020100 | 连杆组件 ROD,CONNECTING | 1 | |
| 5 | F15-07020103 | 连杆螺栓 BOLT,CONNECTING ROD | 2 | |
| 6 | F15-07020104 | 连杆螺栓垫片 WASHER,PLATE | 2 | |
| 7 | F15-07020001 | 活塞 PISTON | 1 | |
| 8 | F15-07020006 | 活塞销 PIN,PISTON | 1 | |
| 9 | F15-07020005 | 活塞销挡圈 CIRCLIP | 2 | |
| 10 | F15-07020002 | 活塞环 PISTON RING | 1 | |
| 11 | F15-07020003 | 活塞环 PISTON RING | 1 | |
| 12 | F15-07020004 | 组合油环 COMBINATION OIL RING | 1 | |
| 13 | F15-07030007 | 曲轴油封 B 35x47x6.5-R OIL SEAL B | 1 | |


SPECIAL TOOLS



Piston slider




Flywheel gripper and flywheel puller



Valve spring compressor



Housing oil seal installer



Space gauge



Oil cleaner spanner

COMPRESSION PRESSURE INSPECTION

1. Start the engine and preheat it for 5 minutes. Then stop it.
2. Remove stopper hang rope.
3. Remove spark plug and attach pressure gauge to spark plug hole.

CAUTION:

Before removing spark plug, use compressed air to clean the spark plug notch, to prevent dust and other foreign matter from entering cylinder.

4. Open the choke completely, and rotate the crankshaft with starter. When the pressure gauge readings become stable, check the cylinder pressure.

NOTE:

Please don't change the choke position when checking the cylinder pressure.

For models that use control box, remove the throttle link and open completely the carburetor throttle rod by hand, and then measure the pressure.

5. If the measured pressure is below the specification or there is difference between cylinders, add a little oil into cylinders and measure again.

NOTE:

If the cylinder pressure increases continuously, check piston and piston ring for damage. Replace if necessary.

If the cylinder pressure doesn't increase at all, check valve clearance, valve, valve seat, cylinder liner, cylinder cover and cylinder cover gasket. Adjust or replace if necessary.

The outboard engine comes with an automatic decompression device, so the pressure data measured may have variance.

OIL PRESSURE INSPECTION

1. Start the engine and preheat it for 5 minutes. Then stop it.
2. Remove the oil pressure switch and attach the pressure gauge.

NOTE:

Please use the pressure gauge equipped with 1/8in pitch thread adapter.

3. Check the oil pressure
Oil pressure (reference data): 110kPa (idling speed)

OIL PRESSURE SWITCH INSPECTION

1. Remove the oil pressure switch and attach the vacuum pressure gauge.
2. Load the stated pressure on oil pressure switch.
Inspect the continuity of oil pressure switch with digital circuit tester. Replace if unqualified.

| Pressure | Continuity |
|---------------|---------------|
| Above 14.7kPa | Discontinuous |
| Below 14.7kPa | Continuous |

3. When the engine rpm increases, check the opening pressure of the safety valve. Clean or replace if necessary.
Opening pressure: 388.0 ~ 450.0kPa

DISASSEMBLING POWER UNIT

1. Open the top cowling.
2. Remove starter.
3. Remove chokes cable and throttle cable.
4. Remove carburetor.
5. Remove flywheel with special tool.



Flywheel gripper and flywheel puller

6. Remove bolts connecting power unit and upper casing.
7. Lift the engine and remove the pin.
8. Remove oil strainer and safety valve.
Check the oil strainer for damage and clog. Replace if necessary.
Check the safety valve for damage and crack. Replace if necessary.
9. Remove the woodruff key.
10. Disconnect the engine stop switch wire and ground wire.
11. Remove throttle cable (manual start models) or cable joint (electric start models).
12. Remove charge coil, lighting coil and pulsed coil.
13. Remove high-pressure assembly, CDI unit, ignition coil, oil pressure switch and spark plug.

BELT PULLEY AND TIMING BELT

1. Rotate the flywheel clockwise. Align the mark '1' on the driven belt pulley with the mark " " on the cylinder cover.

CAUTION:

Please don't rotate the flywheel counter clockwise. Otherwise, valve system will be damaged.

2. Remove timing belt pulley nut with the special timing belt pulley nut barrel.

NOTE:

Please don't turn camshaft while unscrewing the timing belt pulley.

3. Remove timing belt from side of driven belt pulley.

CAUTION:

Please don't rotate the belt pulley before timing belt is fixed. Otherwise, valve system will be damaged.

4. Remove driven belt pulley bolt, driven belt pulley and woodruff key.

NOTE:

Please remove driven belt pulley bolt with flywheel gripper.

Please don't rotate camshaft while unscrewing the timing belt pulley.

5. Remove nut, limitative plate, timing belt pulley and woodruff key.

6. Check belt pulley and timing belt for crack, damage and wear. Replace if necessary.

7. Assemble woodruff key and driven belt pulley.

Align the mark "1" on the driven belt pulley with the mark " " on the cylinder cover. Tighten the driven belt pulley bolt temporarily.

CAUTION:

Please don't rotate the belt pulley before timing belt is fixed. Otherwise, valve system will be

damaged.

8. Assemble wood ruff key and timing belt pulley.

Align the notch mark on the timing belt pulley with the mark “ ” on the cylinder body.

9. Assemble new timing belt. Remember to put the timing belt part number vertical and upward.

CAUTION:

Please don't distort, rotate or bend the timing belt. Otherwise, it will be damaged.

Please keep timing belt from gasoline or oil.

Please don't rotate belt pulley counter clockwise. Otherwise, the valve system will be damaged.

10. Assemble limitative plate and tighten the nut temporarily.

11. Rotate timing belt pulley clockwise for two loops to eliminate the slack of timing belt pulley.

Check whether alignment marks are aligned well.

12. Tighten bolt and nut.

Locking torque: Driven belt pulley bolt 13.4 Nm

Timing belt pulley nut 54 Nm

NOTE:

Remove driven belt pulley bolt with flywheel gripper.

Tighten timing belt pulley nut with special timing belt pulley nut barrel.

DISASSEMBLING AND INSPECTION

CYLINDER COVER


Disassembling

1. Remove the bolts of cylinder head cover.
2. Remove the bolts of the cylinder cover according to the reverse numbering sequence marks on the cylinder cover.
3. Remove the cylinder cover. Remove the oil pump.
4. Remove the rocker arm shaft, spring and rocker arm assy.

NOTE:

Before removing rocker arm shaft, unscrew lock nut and adjust screw to slack.


5. Use the valve spring compressor to remove intake valve and exhaust valve.



Valve and valve guide bush

1. Inspect the valve seat width. If not in the prescribed range, repair the valve seat.
Valve seat width: 0.6 ~ 0.8mm

2. Inspect the valve margin thickness (T). If not as in the prescribed value, replace the valve.
The margin thickness of valve: 0.5 ~ 0.9mm




3. Inspect the valve stem diameter. If not in the prescribed range, replace the valve.

The diameter of valve stem:

Intake valve: 5.475 ~ 5.490mm

Exhaust valve: 5.460 ~ 5.475mm

4. Measure the valve stem run out. If exceeding the limit, replace the valve.
Valve stem run out limit: 0.01mm



5. Measure the inside diameter of the valve guide bush.
The inside diameter of the valve guide bush: 5.500 ~ 5.512mm

CAUTION:

When replacing the valve, use a new valve guide bush and valve oil seal.

Valve spring

1. Measure the free length of valve spring. If less than prescribed value, replace.
The minimum free length: 32.68mm
2. Measure the valve spring tilt. If exceeding the prescribed limit, replace.
The maximum tilt limit: 1.5mm

Valve rocker arm and rocker shaft

1. Check the interface between the valve rocker arm and rocker shaft for wear. Replace if necessary.
2. Measure whether the inside diameter of valve rocker arm and outside diameter of rocker shaft are within prescribed value.
The inside diameter of valve rocker arm: 13.000 ~ 13.018mm
The outside diameter of rocker shaft: 12.941 ~ 12.951 mm


Camshaft

1. Check the camshaft size.

Replace if necessary.

| | | |
|----------------------|------------------|-----------------|
| Height | Intake camshaft | 27.596~27.696mm |
| | Exhaust camshaft | 27.616~27.716mm |
| Base circle diameter | | 23.950~24.050mm |


2. Check camshaft run out. Replace if necessary.
Roundness limit: 0.03mm



3. Check main journal diameter of camshaft and journal inside diameter of cylinder cover. Replace if necessary.
Journal inside diameter of cylinder cover: 35.000~35.012mm
Main journal diameter: 34.935~34.955mm
4. Check the automatic decompression device for crack and damage. Replace the camshaft if necessary.

Oil pump check

1. Remove screw and oil pump.
2. Check rotor clearance of oil pump. Replace if out of specification.



| | |
|---|----------------|
| Clearance between external rotor and casing a | 0.100~0.150 mm |
| Clearance between external rotor and internal rotor b | 0.040~0.140 mm |
| Clearance between rotor and cover c | 0.030~0.090 mm |

Valve guide bush replacement

1. Knock out the valve guide bush from the direction of combustion room.
2. Knock in the new valve guide bush from the direction of the top of cylinder cover.

NOTE:

Coat the oil on the surface of pipe before installation.

3. Bore the inside diameter of pipe to the prescribed value by reamer.

Inside diameter of valve pipe: 5.500 ~ 5.512mm

NOTE:

When taking out the reamer, don't rotate it in counter clockwise direction.

Valve seat inspection

1. Clean the carbon on the valve.
2. Coat a thin layer of bluing dye evenly onto the seal face of the valve seat.

3. Lap the valve on valve seat by valve lapping tool.

4. Measure the valve seat width.

The valve face is with bluing dye.

If the valve and valve seat do not match, or the valve seat width does not conform to specified value, reface and lap the valve seat.

If the contact surface is not even, replace the valve guide bush.


The valve seat width: 0.6 ~ 0.8mm

The maximum valve seat width: 1.1mm


Valve seat cutting

1. Use 45° valve seat cutter to adjust the valve seat width. Turn the cutter clockwise until the valve seat face is smooth.


2. If the valve seat is centered on the valve face but it's too wide, to reduce the valve seat width, use 30° cutter to adjust the top edge of the seat, and use 60° cutter to adjust the bottom edge of the seat.



3. If the valve seat is too narrow and on the top edge of valve surface, use 30° cutter to adjust the top margin of the seat, and use 45° cutter to adjust the valve seat width if necessary.



4. If the valve seal surface is too narrow and on the bottom edge of valve surface, use 60° cutter to adjust the bottom edge of the seat, and use 45° cutter to adjust the valve seat width if necessary.



5. Coat evenly a thin layer of lapping compound onto valve seat, and lap the valve by lapping tool.

6. Clean up the remaining lapping compound.

7. Inspect again the valve seat width.

CAUTION:

Do not overlap the valve. Turn the lapping tool evenly with a downward force of 40~50N. Do not contaminate push rod and valve guide bush with lapping compound.

Valve installation

1. Install new valve oil seal and spread engine oil to the valve guide bush.
2. Install valve, valve spring seal, valve spring and valve spring retainer in sequence.
3. Compress the valve spring with valve spring compressor and install valve cotter.
4. Knock valve spring retainer slightly with plastic or rubber hammer to fix the valve cotter.

Assembling cylinder cover

1. Install new oil seal with special tool.
2. Install camshaft into cylinder cover from the direction of oil pump.
3. Check whether spline position is facing the conjunction surface of cylinder. Adjust if necessary.
4. Install rocker arm assembly, spring and rocker shaft.
5. Assemble oil pump.


NOTE:

Ensure mark on the external rotor is facing the oil pump cover.

6. Align oil pump drive shaft with camshaft pin, then install oil pump.

CAUTION:

Before installing oil pump, make sure the oil passage is through, and fill the oil pump with oil.



CRANKCASE

Disassembling

1. Remove the oil cleaner with special tool.


NOTE:

Put one piece of cloth under oil cleaner



Oil cleaner spanner


2. Remove thermostat cover and gasket.
3. Remove exhaust outer cover, gasket and pin.
Clean the anode surface and check the anode. Replace if the corrosion of anode is abnormal.
Check the exhaust outer cover for crack, distortion or corrosion. Replace if necessary.
4. Remove breather.
Check the breather body for crack, distortion or corrosion. Replace if necessary.
5. Remove the crankcase bolts according to below drawing, and remove the crankcase.



6. Remove the connecting rod bolts and connecting rod cover, remove the crank, and remove connecting rod and piston assy.
7. Remove piston pin circlip with pliers, and remove piston pin and piston.
8. Remove oil seal, pin and main bearing.

Piston

Measure piston outside diameter at the specified measuring point.
If out of specification, replace.
Piston diameter: 58.950 ~ 58.965mm
Measuring point a : 5mm




Cylinder bore

1. Measure cylinder bore separately at measuring point 1, 2, 3.
At each point, measure the cylinder bore at places D1, D3, D5 parallel to the crankshaft and at places D2, D4, D6 vertical to the crankshaft.

Measuring point height: 1 10mm;
2 40mm;
3 70mm

Cylinder bore: 59.00 ~ 59.02mm
Limit size: 59.10mm



2. Calculate taper limit and round limit. If out of specification, replace crankcase.

Taper limit: 0.08mm (D1-D5, D2-D6)

Round limit: 0.05mm (D2-D1, D6-D5)

Piston pin outside diameter

Measure piston pin outside diameter. If out of specification, replace the piston pin.

Piston pin outside diameter: 13.996 ~ 14.000mm

Piston ring

1. Push the piston ring parallel with the piston into the specified measuring point of the cylinder (10mm from conjunction surface).

2. Measure end gap by space gauge. If out of specification, replace the piston ring.

| | | |
|----------------------|----------|---------------|
| End gap (installed): | Top ring | 0.15 ~ 0.30mm |
| | 2nd ring | 0.30 ~ 0.50mm |
| | Oil ring | 0.2 ~ 0.7mm |

3. Install piston ring to piston, and measure side clearance between piston ring and its slot by space gauge. If out of specification, replace the piston ring.


| | | |
|-----------------|----------|---------------|
| Side clearance: | Top ring | 0.04 ~ 0.08mm |
| | 2nd ring | 0.02 ~ 0.04mm |
| | Oil ring | 0 ~ 0.22mm |

Crankshaft

1. Measure diameter of crankshaft main journal, crankpin diameter and crankpin width. If out of specification, replace the crankshaft.

| | |
|-------------------------------------|------------------|
| Diameter of crankshaft main journal | 34.997~35.009 mm |
| Crankpin diameter | 30.997~31.009 mm |
| Crankpin width | 21.00~21.07mm |

2. Measure crankshaft run out. If out of specification, replace.



Crankshaft run out limit: 0.05mm

Crankpin oil clearance

1. Put a piece of plastic space gauge on to the crankpin in parallel to the crankshaft.

2. Assemble connecting rod to the crankpin.
3. Tighten the connecting rod bolts to the specified torque.

| | | |
|--------------------|-------------------|-------|
| Tightening torque: | First tightening | 10 Nm |
| | Second tightening | 21 Nm |
4. Remove the connecting rod, measure the compressed width of the plastic space gauge. If out of specification, replace the connecting rod.
Oil clearance: 0.020 ~ 0.052mm

NOTE:

Don't rotate the connecting rod before completing measurement.

Main journal oil clearance

1. Clean main bearing, main journal and fitting surface of cylinder body and crankcase.
2. Install main bearing and crankshaft to cylinder body.
3. Put one plastic space gauge on the main journal, paralleling with crankshaft.

NOTE:

Don't put plastic space gauge on the oil hole of main journal.

4. Install main bearing onto crankcase and install crankcase onto cylinder body.
5. Following the numbering sequence on the crankcase, tighten the bolts at specified torques.
Tightening torques:

| | | |
|-------------------|----|-------|
| First tightening | M8 | 15 Nm |
| Second tightening | | 30 Nm |
| First tightening | M6 | 6 Nm |
| Second tightening | | 12 Nm |

6. Remove crankcase and measure the compressed width of each plastic gauge. If out of specification, replace the main bearing.
Oil clearance: 0.012 ~ 0.045mm

NOTE:

Please don't rotate the crankshaft before the measurement is completed.

Cylinder body and crankcase

1. Inspect cylinder body and crankcase for crack, damage or wear. Replace if necessary.
2. Inspect cooling water passage for dirt or clog. Clean if necessary.

FULL INSTALLATION

Piston connecting rod installation

Install piston, connecting rod, piston pin and piston pin circlip

NOTE:

When installing, make sure that the mark on the connecting rod is on the same side as the mark on the piston crown.

Piston ring installation


1. Install oil ring, 2nd ring and top ring.

NOTE:

Make sure that the mark is toward the piston crown when installing the 2nd ring.

2. Picture of the piston ring gap

- Oil ring end gap 1 (lower rail)
- Oil ring end gap 2 (expanded ring)
- Oil ring end gap 3 (upper rail)
- 2nd piston ring end gap 4
- Top piston ring end gap 5



Piston installation

Use piston slider to install piston, and make sure that the piston crown “UP” is toward the flywheel side.



NOTE:

Apply engine oil to the piston and piston ring side when installing.

Crankshaft installation

1. Install the crankshaft and main bearing to cylinder body. Install oil seal.

NOTE:

Apply grease onto new oil seal before installing.

2. Install connecting rod cover, and tighten the connecting rod bolt to the specified torque.

Tighten torque: First tightening 10 Nm
Second tightening 21Nm

NOTE:


Apply engine oil to moving parts before installing.

Assembling power unit

1. Install the main bearing to cylinder body.
2. Apply fluid sealant to conjunction surface of the cylinder body, and install dowel pin and cylinder body. Tighten the bolts twice according to the sequences on the right picture.

Tighten torque

| | | |
|-------------------|----|-------|
| First tightening | M8 | 15 Nm |
| Second tightening | | 30 Nm |
| First tightening | M6 | 6 Nm |
| Second tightening | | 12 Nm |



NOTE:

Apply engine oil to moving parts before installing.

3. Install bolt union of oil cleaner and tighten it to the specified torque.
Tighten torque: 40 Nm

4. Install breather.

5. Install exhaust outer cover, thermostat and thermostat cover.
Tighten bolts twice according to priority as picture.

Tighten torque: First tightening 6 Nm
Second tightening 12 Nm


6. Install dowel pin, cylinder gasket and cylinder cover assembly.

7. Inspect the position of woodruff key slot.

8. Tighten the cylinder cover bolts twice to specified torque according to sequences on right picture.


Tighten torque:

| | | |
|-------------------|----|-------|
| First tightening | M8 | 15 Nm |
| Second tightening | | 30 Nm |
| First tightening | M6 | 6 Nm |
| Second tightening | | 12 Nm |




9. Install timing belt pulley, driven belt pulley, timing belt and breather pipe.

10. Adjust valve clearance.




11. Install cover of cylinder cover and tighten bolt according to sequences on right picture.
12. Install throttle cable bracket and accelerograph enforce.
13. For electric start models, install gear shift limitative rod firstly.
14. Install oil pressure switch, ignition coil, C.D.I. unit assy. and rectifier and regulator assy.
15. Install pulsed coil, lighting coil and charge coil.
16. Install fuel system.
17. Install pressure relief valve and oil strainer.



UPPER UNIT

TOP COWLING

Explosive drawing




| 参照号码 | 零件编号 | 零件名称 | 数量 | 备注 |
|------|------------------|--|-----|---------|
| SN. | PART NO. | DESCRIPTION | QTY | REMARKS |
| 1 | F15-08000000 | 顶罩组件 TOP COWLING ASSY | 1 | |
| 2 | F15-00000001 | 顶罩 TOP COWLING | 1 | |
| 3 | GB/T818-M5x20 | 十字槽盘头螺钉M5×20 SCREW, PAN HEAD M5×20 | 2 | |
| 4 | F15-08000004 | 挂钩 POTHOOK | 1 | |
| 5 | F4-06000006 | 挂钩垫 UNDERLAY, POTHOOK | 1 | |
| 6 | GB/T845-ST5.5x19 | 十字槽盘头自攻螺钉 ST5.5x19 SCREW, TAPPING ST5.5x19 | 4 | |
| 7 | F4-06000004 | 橡胶垫片 UNDERLAY, RUBBER | 4 | |
| 8 | F15-08000003 | 顶罩消音器盖 COVER, TOP COWLING MUFFLE | 1 | |
| 9 | F15-08000002 | 密封橡胶条 SEAL | 1 | |
| 10 | F15-08000005 | 锁紧钩 HOOK, LOCKING | 1 | |
| 11 | GB/T97.1-5 | 平垫圈5 WASHER 5 | 4 | |
| 12 | GB/T6170-M5 | 六角螺母M5 NUT M5 | 4 | |

Disassembling and inspection


1. Remove rubber seal.
2. Remove top cowling muffler cover screw and rubber underlay.
3. Remove top cowling muffler cover.
4. Remove locking hook and pothook.
5. Inspect top cowling for crack or damage. Replace if necessary.
6. Inspect rubber seal for crack or damage. Replace if necessary.
7. Inspect top cowling muffler cover for crack or damage. Replace if necessary.
8. Inspect lock hook and pothook for crack, deform or damage. Replace if necessary.

BOTTOM COWLING


Explosive drawing




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|--------------------------------------|-----------|---------------|
| 1 | GB/T5783-M6x30 | 六角螺栓 M6X30 BOLT HEXAGON M6X30 | 3 | |
| 2 | F15-05000019 | 阻风门导向板 ORIENTED PLATE, CHOKE | 1 | |
| 3 | F15-05000018 | 底罩小盖板 COVER BOARD, BOTTOM COWLING | 1 | |
| 4 | F15-05010002 | 阻风门橡胶套 SHEATH, CHOKE | 1 | |
| 5 | F15-05000017 | 方形橡胶密封条 SEAL, RUBBER | 1 | |
| 6 | F15-05000007 | 圆形橡胶网头 RUBBER PLUG, CIRCULAR | 1 | |
| 7 | F15-05000006 | 波纹橡胶套 SHEATH, WAVE | 1 | |
| 8 | F15-01000015 | 油门钢索护套 JACKET, CABLE | 1 | |
| 9 | F15-05000015 | 针形橡胶堵头 RUBBER PLUG, NEEDLE | 1 | |
| 10 | F15-05000008 | 方形线夹A CLAMP A | 1 | |
| 11 | F15-05000003 | 长方形橡胶网头 RUBBER PLUG, QUADRATE | 1 | |
| 12 | GB/T5783-M6x25 | 六角螺栓 M6X25 BOLT HEXAGON M6X25 | 2 | |



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|--|-----------|---------------|
| 13 | GB/T91.7-6 | 平垫圈6 WASHER 6 | 10 | |
| 14 | F15-0500005 | 减震圈衬套 BUSHING, DAMPER | 4 | |
| 15 | F15-0500004 | 减震圈 DAMPER | 4 | |
| 16 | GB/T5783-M6x12 | 六角螺栓 M6x12 BOLT, HEXAGON M6X12 | 1 | |
| 17 | F15-05030000 | 顶罩锁紧组件 LOCKING ASSY, TOP COWLING | 1 | |
| 18 | F15-05000036 | 顶罩锁紧手柄尼龙套B BUSHING B | 1 | |
| 19 | F15-05000023 | 波形垫圈 WASHER, WAVE | 1 | |
| 20 | F15-05000026 | 锁紧块拉簧 SPRING, TENSION | 1 | |
| 21 | F15-05000025 | 拉簧支架组件 BRACKET ASSY, TENSIONAL SPRING | 1 | |
| 22 | F15-05000024 | 双耳水管卡 CLIP, WATER PIPE | 1 | |
| 23 | F15-05000022 | 顶罩锁紧手柄尼龙套A BUSHING A | 1 | |
| 24 | F15-05020000 | 顶罩锁紧手柄组件 LOCKING HANDLE ASSY, TOP COWLING | 1 | |



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|-----------------------------------|-----------|---------------|
| 25 | GB/T5783-Mx35 | 六角螺栓 M6X35 BOLT, HEXAGON M6X35 | 2 | |
| 26 | F15-05000033 | 变档连接杆护套 JACKET, LEVER | 1 | |
| 27 | F15-05000009 | 塑料出水嘴 NIPPLE, PLASTIC | 1 | |
| 28 | GB/T7583-M6x20 | 六角螺栓 M6X20 BOLT, HEXAGON M6X20 | 2 | |
| 29 | F15-05000021 | 小盖板 COVERING | 2 | |
| 30 | F15-05000001 | 底罩 BOTTOM COWLING | 1 | |
| 31 | F15-05000002 | 底罩密封圈 SEAL, BOTTOM COWLING | 1 | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|---------------------|---------------------|---------------|
| 1 | GB/T5783-M6x25 | 六角头螺栓M6 × 25 | BOLT M6 × 25 | 4 |
| 2 | GB/T97.1-6 | 平垫圈6 | WASHER 6 | 5 |
| 3 | F15-05040002 | 变档杆支座 | BRACKET , SHIFT ROD | 2 |
| 4 | F15-05040001 | 制动器摇臂 | ROCKER , STOPPER | 1 |
| 5 | F15-05040100 | 变档杆芯轴组件 | LEVER , SHIFT ROD | 1 |
| 6 | GB/T5783-M6x20 | 六角螺栓M6 × 20 | BOLT M6 × 20 | 1 |
| 7 | F15-05000031 | 档位弹簧片 | SPRING | 1 |
| 8 | F15-05000032 | 档位弹簧托片 | STOPPER SPRING | 1 |
| 9 | F15-05000034 | 变档连接杆 | SHIFT ROD | 1 |
| | F15-05000034S | 变档连接杆 | SHIFT ROD | 1 |
| 10 | F15-05000035 | 柱状螺母 | COLUMNED NUT | 1 |
| 11 | GB/T41-2000 | 六角螺母 | NUT | 1 |
| 12 | GB/T5783-2000 | 夹簧 | SPRING | 1 |
| 13 | GB/T879.2-3x20 | 弹性圆柱销 φ3x20 | PIN, SPRING φ3x20 | 1 |

Disassembling and inspection


1. Remove rubber plug, wave sheath and throttle cable jacket.
2. Remove bolts fixing bottom cowling cover board, and remove cover board.
3. Remove top cowling locking handle assembly screws, remove top cowling locking handle and top cowling locking block.
4. Remove top cowling locking handle bush A and top cowling locking handle bush B.
5. Remove wave washer.
6. Remove fixing bolt of shift rod bracket.
7. Remove cotter pin of shift rod.
8. Remove shift rod, spring pin and stopping rocker.
9. Remove spring and stopper spring.
10. Inspect bottom cowling for crack or damage. Replace if necessary.
11. Inspect top cowling locking handle and top cowling lock block for crack or damage. Replace if necessary.
12. Inspect wave washer and locking handle bush for crack or damage. Replace if necessary.
13. Inspect shift rod bracket and stopping rocker for crack or damage. Replace if necessary.
14. Inspect spring and stopper spring for crack, crank or damage. Replace if necessary.

STEERING HANDLE


Explosive drawing



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|-------------------|--------------------------------------|-----------|---------------|
| 1 | F15-01030004 | 油门钢索组件 THROTTLE CABLE ASSY | 2 | |
| 2 | F15-01000014 | 波纹塑管 TUBE , WAVE PLASTIC | 2 | |
| 3 | GB/T889-M10x1.25 | 六角锁紧螺母M10×1.25 LOCKNUT M10 × 1.25 | 4 | |
| 4 | GB/T6171-M10x1.25 | 六角螺母M10×1.25 NUT M10 × 1.25 | 1 | |
| 5 | F15-01000013 | 手柄定位板 PLATE , HANDLE ORIENTATION | 1 | |
| 6 | F15-01000011 | 手柄衬套(低) WASHER , HANDLE (LOW) | 1 | |
| 7 | F15-00000007 | 变档手柄 HANDLE , GEAR SHIFT | 1 | |
| 8 | F15-00000011 | 变档连杆 LINK , SHIFT ROD | 1 | |
| 9 | GB/T97.1-6 | 平垫圈6 WASHER , PLAIN 6 | 2 | |
| 10 | F15-00000012 | 夹簧 SPRING , CLAMP | 1 | |
| 11 | F15-00000009 | 波形垫圈 WASHER , WAVE | 2 | |
| 12 | F15-00000008 | 凸缘垫管 TUBE , FLANGE | 2 | |




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|-----------------------------------|-----------|---------------|
| 13 | GB/T5783-M6x30 | 六角头螺栓M6×30 HEXAGON BOLT M6×30 | 1 | |
| 14 | F15-01000012 | 衬套尼龙圈 WASHER ,NYLON | 1 | |
| 15 | F15-01000008 | 衬套垫圈 WASHER | 2 | |
| 16 | F15-01000009 | 衬套波形垫圈 WASHER ,WAVE | 2 | |
| 17 | F15-01000007 | 手柄衬套(高) BUSH ,HANDLE | 1 | |
| 18 | GB/T91-1.6x12 | 开口销 1.6×12 PIN ,COTTER 1.6×1 | 1 | |
| 19 | F15-01030200 | 阻力调整旋钮组件 BOLT | 1 | |
| 20 | F4-01090401 | 引擎停止安全索 STOPER ,HANG ROPE ASSY | 1 | |
| 21 | F4-01090400 | 急停开关组件 ENGINE STOP SWITCH ASSY | 1 | |
| 22 | GB/T848-10 | 小垫圈10 SMALL WASHER 10 | 1 | |
| 23 | GB/T827-2x5 | 标牌铆钉2×5 RIVET ,SEMICIRCLE 2×5 | 1 | |
| 24 | F4-01090301 | 操舵手柄塑胶套 GRIP ,STEERING HANDLE | 1 | |




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|--------------------------------|-----------|---------------|
| 25 | F4-01090302 | 操舵手柄橡胶套 RUBBER ,HANDLE | 1 | |
| 26 | GB/T820-M5x25 | 十字槽半沉头螺钉M5×25 SCREW M5×25 | 1 | |
| 27 | F4-01090300 | 操舵手柄塑胶套组件 STEERING HANDLE ASSY | 1 | |
| 28 | F4-01090303 | 油门标志牌 INDICATOR THROTTLE | 1 | |
| 29 | F4-01090007 | 压缩弹簧 SPRING ,COMPRESSON | 1 | |
| 30 | F4-01090006 | 衬套 BUSH | 1 | |
| 31 | F15-01030005 | 节气门固定板 STAY | 1 | |
| 32 | GB/T5783-M6x20 | 六角头螺栓M6×20 HEXAGON BOLT M6×20 | 2 | |
| 33 | F15-01030001 | 操舵手柄 HANDLE STEERING | 1 | |
| 34 | F15-01030100 | 节气门杆组件 LEVER ,THROTTLE ASSY | 1 | |
| 35 | F4-01090003 | 操舵手柄握把摩擦块 FRICTION | 1 | |

Disassembling and inspection

1. Remove shift handle.
2. Remove steering handle cover.
3. Remove handle bush, bush washer and wave washer.
4. Remove cotter pin and friction adjusting bolt.
5. Remove throttle handle.
6. Remove throttle cable.
7. Remove throttle lever stay and throttle lever.
8. Remove engine stop switch.
9. Inspect shift handle for crack or damage. Replace if necessary.
10. Inspect steering handle for crack or damage. Replace if necessary.
11. Inspect bush, bush washer and wave washer for crack or damage. Replace if necessary.




12. Inspect throttle cable for wear or crack. Replace if necessary.
13. Inspect the conduction of engine stop switch. Replace if out of specification.




| | |
|--------------------------|----------------|
| Remove locking plate: | Conducting |
| Install locking plate: | Not conducting |
| Push stop switch button: | Conducting |

BRACKET


Explosive drawing




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|--|-----------|---------------|
| 1 | GB/T6170-M8 | 六角螺母M8 NUT M8 | 2 | |
| 2 | F15-0000004 | 垫板 PLATE | 1 | |
| 3 | GB/T900-M8x50 | 双头螺栓M8 × 50 BOLT , DOUBLE HEAD M8 × 50 | 2 | |
| 4 | F15-02010000 | 双孔减震器组件 DOUBLE HOLE SHOCK ABSORBER ASSY | 1 | |
| 5 | GB/T5783-M6x25 | 六角螺栓M6 × 25 BOLT M6 × 25 | 3 | |
| 6 | GB/T97.1-6 | 平垫圈6 WASHER 6 | 3 | |
| 7 | F15-02010003 | 水管密封圈上 SEAL , WATER TUBE | 1 | |
| 8 | F15-00000016 | 特大垫圈 LARGE WASHER | 2 | |
| 9 | F15-01020001 | 操舵托架 BRACKET , HELM | 1 | L |
| | F15-01020001S | 操舵托架 BRACKET , HELM | 1 | S |
| 10 | F15-01000003 | 旋转支架上垫圈 WASHER , ABOVE | 1 | |
| 11 | F15-01000001 | 旋转支架上衬套 BUSH , ABOVE | 1 | |
| 12 | F15-01000002 | 上衬套锁紧块 PLATE , LOCK | 1 | |




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|--------------------|------------------------------------|-----------|---------------|
| 13 | F15-01010303 | 锁紧螺栓密封圈 SEAL ,LOCK BOLT | 1 | |
| 14 | GB/T5783-M6x20 | 六角螺栓M6 × 20 BOLT M6 × 20 | 1 | |
| 15 | JB/T 7940.1-M6 | 直通式压注油杯M6 OILER | 1 | |
| 16 | F15-01000004 | 旋转支架下衬套 BUSH ,BELOW | 1 | |
| 17 | GB/T3452.1-30x3.55 | 下衬套O形圈30 × 3.55 O - RING 30 × 3.55 | 1 | |
| 18 | F15-01000006 | 旋转支架下垫圈 WASHER ,BELOW | 1 | |
| 19 | F15-00000002 | 左右减震块 MOUNT DAMPER ,LEFT AND RIGHT | 2 | |
| 20 | GB/T6177-M8 | 六角法兰面螺母M8 NUT M8 | 4 | |
| 21 | F15-00000001 | 减震块外壳 SHELL ,MOUNT DAMPER | 2 | |
| 22 | F15-00000003 | 前减震块 MOUNT DAMPER ,FRONT | 1 | |
| 23 | F15-02000003 | 接地钢索B TIGHTWIRE , EARTHING | 1 | |
| 24 | GB/T97.1-8 | 平垫圈8 WASHER 8 | 4 | |
| 25 | GB/T5782-M8x105 | 六角螺栓M8 × 105 BOLT M8 × 105 | 2 | |
| 26 | GB/T5782-M8x85 | 六角螺栓M8 × 85 BOLT M8 × 85 | 2 | |



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|-----------------------------------|-----------|---------------|
| 1 | F15-01010007 | 托架夹紧螺母 NUT , SELF-LOCKING | 2 | |
| 2 | F15-01010003 | 双孔固定板 PLATE , TWO HOLE | 1 | |
| 3 | F15-01010001 | 夹紧托架双头螺管 BOLT , CLAMP BRACKET | 1 | |
| 4 | F15-01010201 | 右夹紧托架 BRACKET , RIGHT | 1 | |
| 5 | F15-01010103 | 扁六角轴位螺钉 SCREW , FLAT HEXAGON | 4 | |
| 6 | F15-01010105 | 倾斜制动板 PLATE , TILT STOPPER | 2 | |
| 7 | F15-01010104 | 波形垫圈 WASHER , WAVE | 1 | |
| 8 | F15-01010202 | 接地钢索A TIGHTWIRE , EARTHING | 1 | |
| 9 | GB/T818-M6x8 | 十字槽盘头螺钉M6×8 SCREW , PAN HEAD M6×8 | 1 | |
| 10 | F15-01010002 | 螺管尼龙垫圈 WASHER , NYLON | 2 | |
| 11 | F15-01010302 | 旋转支架螺管衬套 BUSH , ROTARY BRACKET | 2 | |
| 12 | F15-01010308 | 角度支撑定位轴套 BUSHING , ORIENTATION | 1 | |
| 13 | F15-01010309 | 角度支撑尼龙片 WASHER , NYLON | 1 | |
| 14 | F15-01010301 | 旋转支架 BRACKET , ROTARY | 1 | L |
| | F15-01010301S | 旋转支架 BRACKET , ROTARY | 1 | S |



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|--|-----------|---------------|
| 15 | F15-01010311 | 角度支撑尼龙衬套 BUSH, NYLON | 1 | |
| 16 | F15-01010100 | 左夹紧托架组件 LEFT BRACKET ASSY | 1 | |
| 17 | GB/T5782-M6x145 | 六角螺栓M6 × 145 BOLT M6 × 145 | 1 | |
| 18 | F15-01010400 | 角度限位杆组件 LIMITATIVE ROD ASSY | 1 | |
| 19 | F4-01050003 | 防脱落支脚 NOG, PREVENTED UNLOCK | 1 | |
| 20 | GB/T879.1-3x8 | 弹性圆柱销3 × 8 PIN, SPRING 3 × 8 | 1 | |
| 21 | F15-01010402 | 锥形弹簧 CONICAL SPRING | 1 | |
| 22 | F15-01010006 | 螺栓套管 TUBE, BOLT | 1 | |
| 23 | GB/T896-4 | 开口档圈4 CIRCLIP 4 | 2 | |
| 24 | GB/T818-M8x10 | 十字槽盘头螺钉M8 × 10 SCREW, PAN HEAD M8 × 10 | 2 | |
| 25 | F15-01010316 | 角度锁紧架长轴 LONG SHAFT, LOCK ANGLE | 1 | |
| 26 | GB/T896-5 | 开口档圈5 CIRCLIP 5 | 2 | |
| 27 | F15-01010304 | 角度支撑架拉簧 SPRING, TENSION | 1 | |
| 28 | F15-01010306 | 角度定位件 LEVER, ANGLE ORIENTATION | 1 | |
| 29 | GB/T818-M5x6 | 十字槽盘头螺钉M5 × 6 SCREW, PAN HEAD M5 × 6 | 1 | |



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|------------------------------------|-----------|---------------|
| 30 | F15-01010307 | 锁紧支架连杆 ROD, TILT LOCK | 1 | |
| 31 | F4-01010005 | 舰板夹紧手柄铆钉 RIVET, CLAMP HANDLE | 2 | |
| 32 | F15-01010102 | 舰板夹紧螺杆 SCREW, CLAMP | 2 | |
| 33 | F4-01010004 | 角度锁紧手柄组件 CLAMP SHIPBOARD HANDLE | 2 | |
| 34 | F15-01010305 | 舰板夹紧手柄 TILT CLAMP HANDLE ASSY | 1 | |
| 35 | F15-01010312 | 角度支撑定位轴 SHAFT, STOPPER | 1 | |
| 36 | F15-01010313 | 角度支撑组件 SUPPORT ASSY | 1 | |
| 37 | F15-01010317-3 | 角度锁紧短轴 SHORT SHAFT, LOCK ANGLE | 1 | |
| 38 | F15-01010317-2 | 角度锁紧外架 BRACKET, LOCK ANGLE | 1 | |
| 39 | F15-01010315 | 角度锁紧架扭簧 SPRING, TORSION | 1 | |
| 40 | F15-01010314 | 角度锁紧架拉簧 SPRING, TENSION | 1 | |
| 41 | F15-01010317-1 | 角度锁紧内架 INNER BRACKET | 1 | |
| 42 | GB/T848-6 | 小垫圈6 WASHER 6 | 1 | |
| 43 | GB/T6170-M6 | 六角螺母M6 NUT M6 | 1 | |
| 44 | F4-01010003 | 舰板夹紧圆盘 CLAMP PLATE | 2 | |
| 45 | F15-01010200 | 右夹紧托架组件 RIGHT BRACKET ASSY | 1 | |


Disassembling and inspection

1. Remove limitative rod and bolt (M6X145).
2. Remove nut and bolt of tilt stopper plate, and remove the tilt stopper plate.

3. Remove clamp bracket nut, two hole plate, and double head bolt of clamp bracket.
4. Remove clamp bracket.
5. Remove rotary bracket.
6. Remove lock angle handle and tilt lock rod. Remove tension spring and angle orientation lever.
7. Remove orientation bushing and nylon bush.
8. Remove lock angle long shaft and short shaft.
9. Remove lock angle bracket, torsion spring, tension spring and inner bracket.
10. Inspect rotary bracket and clamp bracket for damage or crack. Replace if necessary.
11. Inspect bush and gasket for damage or crack. Replace if necessary.
12. Inspect lock angle bracket and support bracket for deform. Replace if necessary.

UPPER UNIT

Explosive drawing




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS | |
|-------------|------------------|---------------------|---------------------------|---------------|---|
| 1 | F15-02000001 | 水上装置壳体 | UPPER CASING | 1 | L |
| | F15-02000001S | 水上装置壳体 | UPPER CASING | 1 | S |
| 2 | F15-00000015 | 水上装置罩壳 | MANTLE, UPPER CASING | 1 | |
| 3 | GB/T5783-M6x16 | 六角螺栓 M6X16 | HEXAGON BOLT M6X16 | 2 | |
| 4 | F15-00000006 | 定位销 | PIN, DOWEL | 2 | |
| 5 | F15-02000007 | 鼓形密封圈 | SEAL | 1 | |
| 6 | F15-00000005 | 油底壳密封垫 | GASKET | 1 | |
| 7 | F15-03000002 | 排气橡胶管 | RUBBER PIPE, EXHAUST | 1 | |
| 8 | F15-03000001 | 排气隔板 | CLAPBOARD, EXHAUST | 1 | |
| 9 | F15-03000003 | 隔板密封圈 | SEAL, CLAPBOARD | 1 | |
| 10 | GB/T818-M6x25 | 十字槽盘头螺钉 M6X25 | BOLT | 2 | |
| 11 | GB/T41-2000 | 六角螺母 | NUT, HEXAGON | 2 | |
| 12 | GB/T5783-M8x45 | 六角螺栓 M8X45 | BOLT, HEXAGON M8X45 | 6 | |
| 13 | GB/T97.1-6 | 平垫圈 6 | WASHER 6 | 4 | |
| 14 | GB/T97.1-8 | 平垫圈 8 | WASHER 8 | 6 | |
| 15 | GB/T93-6 | 弹性垫圈 6 | WASHER, SPRING | 2 | |
| 16 | F15-02000006 | 水管方形密封圈 | QUADRATE SEAL, WATER PIPE | 1 | |
| 17 | F15-02000005 | 水管 | TUBE, WATER | 1 | L |
| | F15-02000005S | 水管 | TUBE, WATER | 1 | S |

Disassembling and inspection

1. Remove the oil sump.
2. Remove the oil seal and abnormality seal.
3. Remove the exhaust pipe, oil drain bolt, oil drain jacket and exhaust pipe seal.
4. Remove double hole shock absorber assy, water pipe quadrate seal and water pipe.
5. Check the upper casing for crack or wear. Replace if necessary.
6. Check water pipe for deform or erosion. Replace if necessary.
7. Check exhaust clapboard for damage, wear or crack. Replace if necessary.

LOWER UNIT WATER PUMP ASSEMBLY

Explosive drawing




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|-----------------------------------|-----------|---------------|
| 1 | F15-0600007 | 外挡板 OUTER PLATE | 1 | |
| 2 | JASO F404-96 | 水泵壳O型密封圈31-45 O-RING 31-45 | 1 | |
| 3 | F15-06050000 | 水泵叶轮组件 IMPELLER | 1 | |
| 4 | F15-06060002 | 水泵内壳 INNER SHELL, WATER PUMP | 1 | |
| 5 | F15-00000013 | 定位销 4X12 PIN, DOWEL 4X12 | 2 | |
| 6 | F15-06060001 | 水泵壳体 WATER PUMP HOUSING | 1 | |
| 7 | F15-02000004 | 水管密封圈上 UPPER SEAL, WATER PIPE | 1 | |
| 8 | F15-06060004 | 泵壳水管密封圈 SEAL | 1 | |
| 9 | F15-06000014 | 泵壳固定板 FIXED PLATE, WATER PUMP | 2 | |
| 10 | GB/T5783-M8x45 | 六角螺栓 M8X45 BOLT, HEXAGON M8X45 | 4 | |

Disassembling and inspection


1. Remove water pump fixed plate.
2. Remove water pump housing.
3. Remove impeller and water pump inner shell.
4. Remove woodruff key and outer plate.
5. Check water pump housing and outer plate for crack, crank or damage. Replace if necessary.
6. Check inner water pump inner shell and impeller for crack, deform, burn or damage. Replace if necessary.

LOWER UNIT


Explosive drawing




| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|-----------------------------------|-----------|---------------|
| 1 | GB/T820-M5x25 | 十字槽半沉头螺钉M5x25 SCREW M5X25 | 1 | |
| 2 | F15-06000003 | 进水口 B WATER INLET B | 1 | |
| 3 | GB/T5783-M6x30 | 六角螺栓 M6X30 BOLT, HEXAGON M6X30 | 1 | |
| 4 | GB/T97.1-6 | 平垫圈 6 WASHER 6 | 1 | |
| 5 | GB/T861.1-6 | 内齿锁紧垫圈 6 WASHER, LOCKING 6 | 1 | |
| 6 | F15-06000004 | 水下阳极 ANODE | 1 | |
| 7 | F15-06000015 | 螺旋桨垫块 CUSHION, PROPELLER | 1 | |
| 8 | F15-06090000 | 螺旋桨组件 PROPELLER ASSY | 1 | |
| 9 | GB/T96-10 | 大垫圈 10 WASHER 10 | 1 | |
| 10 | F15-06000016 | 开槽六角螺母 NUT, HEXAGON | 1 | |
| 11 | GB/T91-2.5x20 | 开口销 2.5X20 PIN, COTTER 2.5X20 | 1 | |
| 12 | GB/T5783-M8x30 | 六角螺栓 M8X30 BOLT, HEXAGON M8X30 | 4 | |
| 13 | GB/T97.1-8 | 平垫圈 8 WASHER 8 | 4 | |
| 14 | F15-06020005 | 橡胶密封条 SEAL, RUBBER | 1 | |
| 15 | F15-00000013 | 定位销 4X12 PIN, DOWEL 4X12 | 2 | |
| 16 | GB/T6182-M5 | 非金属嵌件六角锁紧螺母M5 NUT, LOCKING M5 | 1 | |
| 17 | F15-06000002 | 进水口 A WATER INLET A | 1 | |




| 参照号码 | 零件编号 | 零件名称 | 数量 | 备注 |
|------|-----------------|----------------------------------|-----|---------|
| SN. | PART NO. | DESCRIPTION | QTY | REMARKS |
| 1 | F15-06000001 | 水下装置壳体 LOWER CASING | 1 | |
| 2 | F4-03000023 | 注油孔螺塞 PLUG,OIL HOSE | 2 | |
| 3 | F4-03000024 | 注油孔螺塞垫圈 GASKET | 2 | |
| 4 | F15-06000010-1 | 正档齿轮填隙片(t:0.10毫米) SHIM(t:0.10MM) | | |
| | F15-06000010-2 | 正档齿轮填隙片(t:0.12毫米) SHIM(t:0.12MM) | | |
| | F15-06000010-3 | 正档齿轮填隙片(t:0.15毫米) SHIM(t:0.15MM) | | |
| | F15-06000010-4 | 正档齿轮填隙片(t:0.18毫米) SHIM(t:0.18MM) | | |
| | F15-06000010-5 | 正档齿轮填隙片(t:0.30毫米) SHIM(t:0.30MM) | | |
| | F15-06000010-6 | 正档齿轮填隙片(t:0.40毫米) SHIM(t:0.40MM) | | |
| | F15-06000010-7 | 正档齿轮填隙片(t:0.50毫米) SHIM(t:0.50MM) | | |
| 5 | NTN 4T-30205 1L | 圆锥滚子轴承 BEARING | 1 | |
| 6 | F15-06010000 | 正档齿轮组件 GEAR, FORWARD | 1 | |
| 7 | F15-06070004 | 离合器销 PIN, CLUTCH | 1 | |
| 8 | F15-06070003 | 爪形离合器 CLUTCH, DOG | 1 | |
| 9 | F15-06070005 | 离合器环 RING, CLUTCH | 1 | |



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|--------------------------------------|-----------|---------------|
| 10 | F15-06070006 | 变档柱塞 PLUNGER, SHIFT | 1 | |
| 11 | F15-06070002 | 离合器弹簧 SPRING, CLUTCH | 1 | |
| 12 | F15-06070001 | 螺旋桨轴 SHAFT, PROPELLER | 1 | |
| 13 | F15-06070007 | 倒档齿轮垫圈 WASHER, REVERSE GEAR | 1 | |
| 14 | F15-06080005 | 倒档齿轮 GEAR, REVERSE | 1 | |
| 15 | F15-06080006-1 | 倒档齿轮填隙片 (t: 0.10毫米) SHIM (t: 0.10MM) | | |
| | F15-06080006-2 | 倒档齿轮填隙片 (t: 0.20毫米) SHIM (t: 0.20MM) | | |
| | F15-06080006-3 | 倒档齿轮填隙片 (t: 0.30毫米) SHIM (t: 0.30MM) | | |
| | F15-06080006-4 | 倒档齿轮填隙片 (t: 0.40毫米) SHIM (t: 0.40MM) | | |
| | F15-06080006-5 | 倒档齿轮填隙片 (t: 0.50毫米) SHIM (t: 0.50MM) | | |
| 16 | GB/T276-6005 | 深沟球轴承 6005 BEARING 6005 | 1 | |
| 17 | F15-06080002 | 水下壳体盖O型圈A O-RING A, COVER | 1 | |
| 18 | F15-06080003 | 水下壳体盖O型圈B O-RING B, COVER | 1 | |
| 19 | F15-06080001 | 水下装置壳体盖 COVER, LOWER CASING | 1 | |
| 20 | KOYO 17BM2312 | 滚针轴承 17BM2312 BEARING 17BM2312 | 1 | |



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|--|-----------|---------------|
| 21 | F15-06080004 | 螺旋桨轴油封17X30X6 (单唇) OIL SEAL | 2 | |
| 22 | F15-06080000 | 水上装置壳体盖组件 COVER ASSY, LOWER CASING | 1 | |
| 23 | GB/T97.1-6 | 平垫圈 6 WASHER 6 | 2 | |
| 24 | GB/T5783-M6x20 | 六角螺栓 M6X20 BOLT, HEXAGON M6X20 | 2 | |
| 25 | F15-06000005 | 驱动轴座密封垫 WASHER | 1 | |
| 26 | NSK F1420 | 滚针轴承 F1420 BEARING F1420 | 1 | |
| 27 | F15-06000006 | 长尼龙套管 BUSHING, NYLON | 1 | |
| 28 | F15-06020001 | 驱动轴座 BASE, DRIVE SHAFT | 1 | |
| 29 | F15-06020004 | O型圈 O-RING | 1 | |
| 30 | GB/T97.1-8 | 平垫圈 8 WASHER 8 | 2 | |
| 31 | GB/T5783-M8x25 | 六角螺栓 M8X25 BOLT, HEXAGON M8X25 | 2 | |
| 32 | F15-06020002 | 带挡边筒形轴承 BEARING | 1 | |
| 33 | F15-06020003 | 驱动轴油封 20X30X6 (单唇) OIL SEAL, DRIVE SHAFT 20X30X6 | 2 | |
| 34 | F15-06040000 | 驱动轴组件 DRIVE SHAFT ASSY | 1 | L |
| | F15-06040000S | 驱动轴组件 DRIVE SHAFT ASSY | 1 | S |



| 参照号码 SN. | 零件编号 PART NO. | 零件名称 DESCRIPTION | 数量 QTY | 备注 REMARKS |
|-------------|------------------|--|-----------|---------------|
| 35 | F15-06000013 | 半圆键 KEY,WOODRUFF | 1 | |
| 36 | F15-06030000 | 变档凸轮组件 CAM ASSY,SHIFT ROD | 1 | L |
| | F15-06030000S | 变档凸轮组件 CAM ASSY,SHIFT ROD | 1 | S |
| 37 | F15-06000020 | 平面滚针推力轴承 BEARING | 1 | |
| 38 | F15-06000008 | 小齿轮填隙片(t:1.13毫米) SHIM,PINION(t:1.13MM) | 1 | |
| | F15-06000009 | 小齿轮填隙片(t:1.20毫米) SHIM,PINION(t:1.20MM) | 1 | |
| 39 | F15-06000011 | 小齿轮 PINION | 1 | |
| 40 | F15-06000012 | 小齿轮螺母 M8X1 NUT,PINION M8X1 | 1 | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

Disassembling and inspection

1. Drain oil, and remove the cotter pin.
2. Put a piece of wood between propeller and anti-swirl baffle. Remove hexagon nut, anode and water inlet.
3. Remove propeller assembly and cushion.
4. Remove anode.
5. Remove the lower casing cover.
Remove reverse gear and shim. Remove oil seal.
6. Remove propeller shaft assembly.
7. Remove shift plunger.
8. Remove clutch ring, remove clutch pin and dog clutch. Remove clutch spring.
9. Remove the drive shaft by using female spline spanner. Remove forward gear.



Female spline spanner

10. Remove drive shaft base.
11. Remove shift rod cam Assy.
12. Remove rolling needle bearing from lower unit.




Rolling needle bearing installer

13. Remove oil seal and barrel bearing with guard board from the drive shaft base.

Propeller shaft and clutch block


1. Check dog clutch for crack or damage. Replace if necessary.
2. Check propeller shaft for wear or crank. Replace if necessary.
3. Check the run out of propeller shaft. If out of specification, replace.



Run out limit: 0.05mm

Dog clutch installation

1. Put clutch spring into the hole at the end of the propeller shaft.
2. Install the dog clutch as shown. Make sure the “F” mark is toward the forward gear. Install clutch pin.



3. Install clutch ring and shift plunger.

Lower casing cover

1. Check bearing for rust or rumbling when run. Replace if necessary.
2. Remove bearing and oil seal by bearing puller.

NOTE:

Don't remove bearing unless changing it.

3. Remove rolling needle bearing by using special tool.

NOTE:

Use new parts when reinstalling the oil seal and rolling needle bearing.

4. Clean casing cover by a soft brush and solvent.
5. Check casing cover for crack or damage. Replace if necessary.

Lower casing cover oil seal and bearing installation

1. Install oil seal.
2. Install bearing.

NOTE:

Install oil seal and bearing by using special tools.

Take note of the direction and depth when installing the oil seal.

Make sure the manufacturer mark of the bearing is toward the reverse gear.



Lower casing cover bearing installer



Lower casing cover barrel bearing installer



Lower casing cover oil seal installer


3. Install reverse gear and shim.

NOTE:

Adjust the shim when install the new reverse gear and bearing.

Drive shaft

1. Inspect the drive shaft for crank or wear. Replace if necessary.
2. Check the run out of drive shaft.



Run out limit: 0.05 mm

Shift rod cam

Check the shift rod cam for wear or deform. Replace if necessary.

Gear

Inspect the forward gear, reverse gear and pinion for wear or damage. Replace if necessary.

Forward gear bearing

Inspect bearing for rust or rumbling when rotating. Replace if necessary.

NOTE:

Adjust the shim when install new bearing.

Lower casing inspection

Check lower casing for crack or damage, check cooling water inlet for clog. Replace if necessary.

Assembling lower casing

1. Install the rolling needle bearing by using special tool.



Rolling needle bearing installer

2. Install new taper roller bearing (if replace).
3. Install barrel bearing with guard board. Align the notch on the bearing shoulder with the notch on the drive shaft base.



Bearing block copper sleeve installer

4. Install oil seal.
(unit: mm)



Bearing block oil seal installer

5. Install nylon bushing, shift rod cam assy, gasket, and drive shaft base. Install forward gear, drive shaft, shim, end thrust bearing and pinion.



Forward gear bearing installer

CAUTION:

Adjust shim when install new drive shaft base or drive shaft.

Adjust shim when install new end thrust bearing.

6. Tighten the pinion.
Specified torque: 25 Nm
7. Install propeller shaft assy.
8. Install lower casing cover.
9. Check if gearshift works normally.
10. Install water pump assy.
11. Install anode and water inlet.
12. Install propeller and hexagon nut. Put a piece of wood between propeller and anti-swirl baffle.
Tighten the nut according to specified torque.
Specified torque: 17 Nm

NOTE:


If the nut slot is not aligned with the hole of the propeller shaft cotter pin, tighten the nut until aligned.

Lower unit installation

1. Install dowel pin.
2. Move the shift rod cam assy to reverse gear position. Install the lower unit to upper casing, tighten the bolt according to specified torque.

3. Connect the columned nut and shift rod cam assy. Change shift, and check if the operation is normal. Adjust the columned nut position if necessary. Tighten the nut thoroughly.
4. Add gear oil using the pressure filling device.

Shim selection



T1、 T2、 T3: Shim thickness

M1: Reverse gear thickness; M2: Forward gear thickness; M3: Thrust rolling needle bearing with flat seat thickness

Calculate formula: $T1=80.57-M1$
 $T2=16.60-M2$
 $T3=6.05-M1$

NOTE:

Use three measuring points when measuring the thickness. Apply the average.
For the optional shim specs, refer to page 11.

COMMON TROUBLES AND SOLUTIONS

| Trouble type | Possible reason | Recovery action |
|------------------------------------|--|--|
| Starter will not operate | Starter components are faulty | Repair or replace |
| | Shift lever is not in the neutral position | Move to the neutral position |
| Engine will not start | Fuel tank is empty | Fill tank with clean, fresh fuel |
| | Fuel is contaminated or stale | |
| | Gasoline cleaner is obstructed | Replace |
| | Fuel pump is faulty | Inspect or replace |
| | Air vent screw not loosened | Loosen air vent screw |
| | Spark plug(s) fouled or of incorrect type. | Inspect spark plug(s). Clean or replace with recommended type |
| | Spark plug cap(s) fitted incorrectly | Check and re-fit cap(s) |
| | Ignition wiring is faulty | Check wires. Tighten all loose connections. Replace worn or broken wires |
| | Ignition parts are faulty | Replace |
| | Engine stop switch lanyard is not attached | Attach lanyard |
| | Engine inner parts are damaged | Repair |
| Engine idles irregularly or stalls | Spark plug(s) fouled or of incorrect type. | Inspect spark plug(s). Clean or replace with recommended type |
| | Fuel system is obstructed | Check for pinched or kinked fuel line or other obstructions in fuel system |
| | Fuel is contaminated or stale | Fill tank with clean, fresh fuel |
| | Fuel cleaner is obstructed | Replace |
| | Spark plug clearance is incorrect | Inspect and adjust as specified |
| | Ignition wiring is faulty | Check wires. Tighten all loose connections. Replace worn or broken wires |
| | Specified engine oil is not being used | Check and replace oil as specified |
| | Thermostat is faulty | Replace |
| | Carburetor is faulty | Replace |
| | Fuel pump is faulty | Replace |
| | Air vent screw on fuel tank is not loosen | Loosen air vent screw |
| | Fuel joint connection is incorrect | Connect correctly |
| | Choke knob is pulled out | Return to home position |
| Motor angle is too high | Return to normal operating position | |

Cont'd

| Trouble type | Possible reason | Recovery action |
|--|---|--|
| Engine power loss | Propeller is damaged | Repair or replace propeller |
| | Trim angle is incorrect | Adjust trim angle to achieve most efficient angle |
| | Motor is mounted at incorrect transom height | Adjust motor to proper transom height |
| | Boat bottom is fouled with marine growth | Clean boat bottom |
| | Weeds or other foreign matter are tangled on gear housing | Remove foreign matter and clean lower unit |
| | Spark plug(s) fouled or of incorrect type. | Inspect spark plug(s). Clean or replace with recommended type |
| | Fuel system is obstructed | Check for pinched or kinked fuel line or other obstructions in fuel system |
| | Fuel cleaner is obstructed | Replace |
| | Fuel is contaminated or stale | Fill tank with clean, fresh fuel |
| | Spark plug clearance is incorrect | Inspect and adjust as specified |
| | Ignition wiring is faulty | Check wires. Tighten all loose connections. Replace worn or broken wires |
| | Ignition parts have failed | Replace |
| | Specified engine oil is not being used or oil is added too much | Check and replace oil as specified, or adjust engine oil to specified position |
| | Thermostat is faulty | Replace |
| | Fuel pump is faulty | Replace |
| | Fuel joint connection is incorrect | Connect correctly |
| Specified spark plug(s) are not being used | Check and replace spark plug(s) as specified | |
| Engine vibrates excessively | Propeller is damaged | Repair or replace propeller |
| | Propeller shaft is damaged | Replace |
| | Weeds or other foreign matter are tangled on propeller | Remove and clean propeller |
| | Motor mounting bolt is loose | Tighten bolt |
| | Steering pivot is loose | Tighten steering pivot |
| | Steering pivot is damaged | Replace |