

**F400A
FL400A
F450A
FL450A**

OWNER'S MANUAL

▲ Read this manual carefully before operating this outboard motor.

6KN-28199-K0-E0

Read this manual carefully before operating this outboard motor. Keep this manual onboard in a waterproof bag when boating. This manual should stay with the outboard motor if it is sold.


Important manual information

EMU25108

To the owner

Thank you for selecting a Yamaha outboard motor. This Owner's Manual contains information needed for proper operation, maintenance and care. A thorough understanding of these simple instructions will help you obtain maximum enjoyment from your new Yamaha. If you have any question about the operation or maintenance of your outboard motor, please consult a Yamaha dealer.

In this Owner's Manual particularly important information is distinguished in the following ways.

 : This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

EWMM00782

WARNING

A WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

ECM00702

NOTICE

A NOTICE indicates special precautions that must be taken to avoid damage to the outboard motor or other property.

TIP:

A TIP provides key information to make procedures easier or clearer.

Yamaha continually seeks advancements in product design and quality. Therefore, while this manual contains the most current product information available at the time of printing, there may be minor discrepancies

between your machine and this manual. If there is any question concerning this manual, please consult your Yamaha dealer.

To ensure long product life, Yamaha recommends that you use the product and perform the specified periodic inspections and maintenance by correctly following the instructions in the owner's manual. Any damage resulting from neglect of these instructions is not covered by warranty.

Some countries have laws or regulations restricting users from taking the product out of the country where it was purchased, and it may be impossible to register the product in the destination country. Additionally, the warranty may not apply in certain regions. When planning to take the product to another country, consult the dealer where the product was purchased for further information.

If the product was purchased used, please consult your closest dealer for customer registration, and to be eligible for the specified services.

TIP:

The F400AST, FL400AST, F450AVT, FL450AVT and the standard accessories are used as a base for the explanations and illustrations in this manual. Therefore some items may not apply to every model.

EMU25123

**F400A, FL400A, F450A, FL450A
OWNER'S MANUAL
©2022 by Yamaha Motor Co., Ltd.
1st Edition, January 2022
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan**

Table of contents

Safety information	1	Digital electronic control requirements.....	12
Outboard motor safety.....	1	Battery requirements	13
Propeller.....	1	Battery specifications.....	13
Rotating parts.....	1	Propeller selection	14
Hot parts	1	Counter rotation models	14
Electric shock.....	1	Start-in-gear protection	14
Power trim and tilt.....	1	Engine oil requirements	15
Engine shut-off cord (lanyard).....	1	Fuel requirements.....	15
Gasoline	2	Gasoline	15
Gasoline exposure and spills	2	Anti-fouling paint	16
Carbon monoxide	2	Outboard motor disposal requirements.....	16
Modifications.....	2	Emergency equipment.....	16
Boating safety	2	Emission control information	16
Alcohol and drugs	2	U.S. insular areas	16
Personal flotation devices (PFDs)	2	Components	17
People in the water	2	Components diagram	17
Passengers.....	2	Optional items	19
Overloading.....	3	Helm Master™ EX (upgradable) ..	22
Avoid collisions	3	Digital electronic control.....	22
Collisions with floating or submerged objects	3	Control lever.....	23
Weather	4	Power trim and tilt switches.....	23
Passenger training	4	DEC alert indicator	24
Boating safety publications.....	4	Speed control switch	24
Laws and regulations	4	Neutral hold switch	25
General information	5	Station selector switch.....	25
Identification numbers record	5	Center engine switch.....	26
Outboard motor serial number.....	5	Single lever switch	26
Key number.....	5	6X6 switch	27
EC Declaration of Conformity (DoC).....	5	Main switch	27
CE Marking / UKCA Marking	5	Start/Stop switch panel.....	27
Compliance mark label	6	All Start/Stop switch panel (optional)	27
Read manuals and labels.....	7	Engine shut-off cord (lanyard) and clip	28
Warning labels	7	Outboard motor equipment.....	28
Engine data recording.....	9	Power trim and tilt switch on bottom cowling.....	28
Specifications and requirements ...	11	Tilt limiter.....	29
Specifications.....	11	Tilt support lever for power trim and tilt model	29
Installation requirements.....	12		
Boat horsepower rating.....	12		
Mounting outboard motor.....	12		

Table of contents

Cowling lock lever	29	Warming up engine.....	52
Flushing device	30	Procedure for warming up engine....	52
Fuel filter.....	30	Checks after engine warm up.....	53
Instruments and indicators	31	Shifting	53
CL5 Display	31	Stop switches.....	53
Engine control system	34	Shifting.....	53
Alert system	34	Neutral hold switch operation.....	54
Helm Master control system alert	34	Center engine switch operation....	54
Digital electronic control alert	34	Single lever switch operation.....	55
Overheat alert.....	34	Stopping boat	56
Low oil pressure alert.....	35	Boat direction	57
Water separator alert.....	36	Stopping engine.....	59
Installation	38	Procedure for stopping engine	
Installation	38	(6X6 switch).....	59
Mounting the outboard motor.....	38	Trimming outboard motor.....	59
Operation	40	Adjusting trim angle (Power trim	
First-time operation.....	40	and tilt)	60
Filling engine oil.....	40	Adjusting boat trim.....	61
Breaking in engine.....	40	Tilting up and down	61
Getting to know your boat	40	Procedure for tilting up (power trim	
Checks before starting engine	41	and tilt models)	62
Fuel level	41	Procedure for tilting down.....	64
Removing top cowling	41	PTT TotalTilt™	65
Fuel system	42	Shallow water	66
Controls.....	42	Cruising in shallow water	66
Engine shut-off cord (lanyard).....	43	Operating in other conditions	67
Engine oil.....	43	Maintenance	69
Outboard motor	43	Transporting and storing outboard	
Flushing device	44	motor	69
Installing top cowling	44	Storing outboard motor.....	69
Checking power trim and tilt		Lubrication	69
system	45	Flushing cooling water passage.....	70
Battery.....	46	Cleaning the outboard motor	71
Filling fuel	46	Checking painted surface of	
Operating engine.....	47	outboard motor	71
Sending fuel	47	Periodic maintenance	71
Starting engine	47	Replacement parts.....	71
Checks after starting engine	52	Severe operating conditions	72
Cooling water	52	Maintenance chart 1.....	73
		Maintenance chart 2.....	75
		Greasing	77
		Inspecting spark plug.....	79

Table of contents

Inspecting engine idle speed	79
Changing engine oil.....	79
Why Yamalube	79
Inspecting wiring and connectors....	79
Inspecting propeller	80
Removing propeller	80
Installing propeller	81
Changing gear oil	81
Inspecting and replacing anode(s) ...	83
Checking battery (for electric start models)	84
Connecting the battery.....	84
Disconnecting the battery	86
Trouble Recovery	88
Troubleshooting	88
Temporary action in emergency ...	91
Impact damage	91
Running in an emergency (twin engines or triple engines)	91
Replacing fuse	92
Power trim and tilt will not operate.....	93
Steer-by-wire system will not operate.....	93
Water separator-alert is activated after leaving port	94
Treatment of submerged motor	95
INDEX	97

EMU33623

Outboard motor safety

Observe these precautions at all times.

EMU36502

Propeller

People can be injured or killed if they come in contact with the propeller. The propeller can keep moving even when the motor is in neutral, and sharp edges of the propeller can cut even when stationary.

- Stop the engine when a person is in the water near you.
- Keep people out of reach of the propeller, even when the engine is off.

EMU40272

Rotating parts

Hands, feet, hair, jewelry, clothing, personal flotation device (PFD) straps, etc., can become entangled with internal rotating parts of the engine, resulting in serious injury or death.

Keep the top cowling in place whenever possible. Do not remove or replace the top cowling with the engine running.

Only operate the engine with the top cowling removed according to the specific instructions in the manual. Keep hands, feet, hair, jewelry, clothing, PFD straps, etc., away from any exposed moving parts.

EMU33641

Hot parts

During and after operation, engine parts are hot enough to cause burns. Avoid touching any parts under the top cowling until the engine has cooled.

EMU33651

Electric shock

Do not touch any electrical parts while starting or operating the engine. They can cause shock or electrocution.

EMU33662

Power trim and tilt

Body parts can be crushed between the motor and the clamp bracket when the motor is trimmed or tilted. Keep body parts out of this area at all times. Be sure no one is in this area before operating the power trim and tilt mechanism.

The power trim and tilt switches operate even when the main switch is off. Keep people away from the switches whenever working around the motor.

Never get under the lower unit while it is tilted, even when the tilt support lever is locked. Severe injury could occur if the outboard motor accidentally falls.

EMU33672

Engine shut-off cord (lanyard)

Attach the engine shut-off cord so that the engine stops if the operator falls overboard or leaves the helm. This prevents the boat from running away under power and leaving people stranded, or running over people or objects.

Always attach the engine shut-off cord to a secure place on your clothing or your arm or leg while operating. Do not remove it to leave the helm while the boat is moving. Do not attach the cord to clothing that could tear loose, or route the cord where it could become entangled, preventing it from functioning.

Do not route the cord where it is likely to be accidentally pulled out. If the cord is pulled during operation, the engine will shut off and you will lose most steering control. The boat could slow rapidly, throwing people and objects forward.

Safety information

EMU33811

Gasoline

Gasoline and its vapors are highly flammable and explosive. Always, refuel according to the procedure on page 47 to reduce the risk of fire and explosion.

EMU33821

Gasoline exposure and spills

Take care not to spill gasoline. If gasoline spills, wipe it up immediately with dry rags. Dispose of rags properly.

If any gasoline spills onto your skin, immediately wash with soap and water. Change clothing if gasoline spills on it.

If you swallow gasoline, inhale a lot of gasoline vapor, or get gasoline in your eyes, get immediate medical attention. Never siphon fuel by mouth.

EMU33901

Carbon monoxide

This product emits exhaust gases which contain carbon monoxide, a colorless, odorless gas which may cause brain damage or death when inhaled. Symptoms include nausea, dizziness, and drowsiness. Keep cockpit and cabin areas well ventilated. Avoid blocking exhaust outlets.

EMU33781

Modifications

Do not attempt to modify this outboard motor. Modifications to your outboard motor may reduce safety and reliability, and render the outboard unsafe or illegal to use.

EMU33742

Boating safety

This section includes a few of the many important safety precautions that you should follow when boating.

EMU33711

Alcohol and drugs

Never operate after drinking alcohol or taking drugs. Intoxication is one of the most common factors contributing to boating fatalities.

EMU40281

Personal flotation devices (PFDs)

Have an approved PFD on board for every occupant. Yamaha recommends that you must wear a PFD whenever boating. At a minimum, children and non-swimmers should always wear PFDs, and everyone should wear PFDs when there are potentially hazardous boating conditions.

EMU33732

People in the water

Always watch carefully for people in the water, such as swimmers, skiers, or divers, whenever the engine is running. When someone is in the water near the boat, shift into neutral and stop the engine.

Stay away from swimming areas. Swimmers can be hard to see.

The propeller can keep moving even when the motor is in neutral. Stop the engine when a person is in the water near you.

EMU33752

Passengers

Consult your boat manufacturer's instructions for details about appropriate passenger locations in your boat and be sure all passengers are positioned properly before accelerating and when operating above an idle speed. Standing or sitting in non-designated locations may result in being thrown either overboard or within the boat due to waves, wakes, or sudden changes in speed or direction. Even when people are positioned prop-

erly, alert your passengers if you must make any unusual maneuver. Always avoid jumping waves or wakes.

EMU33763


Overloading

Do not overload the boat. Consult the boat capacity plate or boat manufacturer for maximum weight and number of passengers. Be sure that weight is properly distributed according to the boat manufacturer's instructions. Overloading or incorrect weight distribution can compromise the boat's handling and lead to an accident, capsizing or swamping.

EMU33773

Avoid collisions

Scan constantly for people, objects, and other boats. Be alert for conditions that limit your visibility or block your vision of others.



ZMU06025

Operate defensively at safe speeds and keep a safe distance away from people, objects, and other boats.

- Do not follow directly behind other boats or waterskiers.
- Avoid sharp turns or other maneuvers that make it hard for others to avoid you or understand where you are going.
- Avoid areas with submerged objects or shallow water.

- Ride within your limits and avoid aggressive maneuvers to reduce the risk of loss of control, ejection, and collision.
- Take early action to avoid collisions. Remember, boats do not have brakes, and stopping the engine or reducing throttle can reduce the ability to steer. If you are not sure that you can stop in time before hitting an obstacle, apply throttle and turn in another direction.

EMU48100

Collisions with floating or submerged objects


If the outboard motor hits a floating object or an obstacle in the water while cruising, the following could occur:

- The passengers and any loose equipment or luggage could be thrown forward due to the sudden deceleration.
- Parts of the outboard motor could come loose as a result of the impact and could be thrown into the boat.
- The boat or outboard motor could be damaged as a result of the impact.

When you operate the boat in an area where there might be floating objects or obstacles in the water, be sure to adjust the trim angle of the outboard motor, slow down, and operate carefully. For further information, see page 66.

If the outboard motor hits a floating object or an obstacle in the water, make sure that there are no abnormalities with the boat and the outboard motor. If anything abnormal is found, return to the nearest harbor at low speed and have a Yamaha dealer inspect the outboard motor.

Safety information



EMU33791

Weather

Stay informed about the weather. Check weather forecasts before boating. Avoid boating in hazardous weather.

EMU33881

Passenger training

Make sure at least one other passenger is trained to operate the boat in the event of an emergency.

EMU33891

Boating safety publications

Be informed about boating safety. Additional publications and information can be obtained from many boating organizations.

EMU33602

Laws and regulations

Know the marine laws and regulations where you will be boating—and obey them. Several sets of rules prevail according to geographic location, but all are basically the same as the International Rules of the Road.

EMU25172


Identification numbers record

EMU25186


Outboard motor serial number

The outboard motor serial number is stamped on the label attached to the port side of the clamp bracket.

Record your outboard motor serial number in the spaces provided to assist you in ordering spare parts from your Yamaha dealer or for reference in case your outboard motor is stolen.



1. Outboard motor serial number location



ZMU01692

1. Serial number
2. Model name
3. Motor transom height
4. Engine code


EMU41572

Key number

The key identification number is stamped on the spare key as shown in the illustration. Keep the spare key in a safe place and record this number in the space provided for reference in case that you need a new key.



ZMU01693



1. Key number

EMU38984

EC Declaration of Conformity (DoC)

This declaration is included with outboard motors that conform to European regulations.

This outboard motor conforms to certain portions of the European Parliament directive relating to machinery.

Each conformed outboard motor accompanied with EC DoC. EC DoC contains the following information;


- Manufacturer
- Model name
- Engine code
- Applied directives

EMU48442

CE Marking / UKCA Marking

This label is affixed to outboard motors that conform to European regulations.

General information



1. CE marking location



CE marking

Outboard motors affixed with this “CE” marking conform with the directives of; 2006/42/EC, 2014/30/EU, and 2013/53/EU.

UKCA marking


This product is in compliance with the Recreational Craft Regulations 2017, Electromagnetic Compatibility Regulations 2016 and Supply of Machinery (Safety) Regulations 2008.

EMU46133

Compliance mark label

Engines affixed with this label conform to the regulations for each country.

This label is affixed to the clamp bracket or swivel bracket.



1. Compliance mark label location

Regulatory Compliance Mark (RCM)

Engines affixed with this mark conform to certain portion(s) of the Australian Radio Communications Act.



1

ZMU08190

1. Regulatory Compliance Mark (RCM)

ICES-002 Compliance Label

Engines affixed with this mark meet all requirements of the Canadian Interference Causing Equipment Regulations.



1

ZMU08191

1. ICES-002 Compliance Label

EMU33524

Read manuals and labels

Before operating or working on this outboard motor:


- Read this manual.
- Read any manuals supplied with the boat.
- Read all labels on the outboard motor and the boat.

If you need any additional information, contact your Yamaha dealer.

EMU33836

Warning labels

If these labels are damaged or missing, contact your Yamaha dealer for replacements.





General information


1



2



3



EMU47890

Contents of labels

The above warning labels mean as follows.

1

EWM01682



WARNING

- Keep hands, hair, and clothing away from rotating parts while the engine is running.
- Do not touch or remove electrical parts when starting or during operation.

2

EWM01672



WARNING

- Read Owner's Manuals and labels.
- Wear an approved personal flotation device (PFD).

- Attach engine shut-off cord (lanyard) to your PFD, arm, or leg so the engine stops if you accidentally leave the helm, which could prevent a runaway boat.

3

EWM04450



WARNING

Vapor separator tank (VST) contains pressurized fuel.

To reduce the risk of spraying fuel during VST service:

1. Wrap fuel hose connector in a cloth then disconnect hose slowly to release pressure.
2. Remove band from fuel nipple.
3. Open drain cap to drain the fuel from VST.

EMU33851

Other labels

4



Hazard caused by continuous rotation



ZMU05665

EMU35133

Symbols

The following symbols mean as follows.

Notice/Warning




ZMU05696

Read Owner's Manual



ZMU05664

Electrical hazard



ZMU05666

EMU48010

Engine data recording

This model's ECM stores certain engine data to assist in the diagnosis of malfunctions and for research, statistical analysis and development purposes.

Although the sensors and recorded data will vary by model, the main data points are:

- Engine status and engine performance data

This data will be uploaded only when a special Yamaha diagnostic tool is attached to the engine, such as when maintenance checks or service procedures are performed.

Yamaha will not disclose this data to a third party except in the following cases. In addition, Yamaha may provide engine data to a contractor in order to outsource services related to the handling of the engine data. Even

General information

in this case, Yamaha will require the contractor to properly handle the engine data we provided and Yamaha will appropriately manage the data.

- With the consent of the boat owner
- Where obligated by law
- For use by Yamaha in litigation
- For general Yamaha-conducted research purposes when the data is not related to an individual engine or owner

Specifications and requirements

EMU40501

Specifications

TIP:

“(SUS)” indicates that the specification is for the outboard motor when it is equipped with a stainless steel propeller.

EMU48360

Dimension and weight:

Overall length:

1217 mm (47.9 in)

Overall width:

652 mm (25.7 in)

Overall height X:

2059 mm (81.1 in)

Overall height U:

2186 mm (86.1 in)

Motor transom height X:

640 mm (25.2 in)

Motor transom height U:

767 mm (30.2 in)

Dry weight (SUS) X:

447 kg (985 lb)

Dry weight (SUS) U:

458 kg (1010 lb)

Performance:

Full throttle operating range:

5000–6000 r/min

Rated power:

294.2 kW (400 HP) (F400ASTU,
F400ASTX, FL400ASTU, FL400ASTX)

331.0 kW (450 HP) (F450AVTU,
F450AVTX, FL450AVTU, FL450AVTX)

Idle speed (in neutral):

650–750 r/min

Power unit:

Type:

4-stroke DOHC V8 32 valves

Total displacement:

5559 cm³ (339.2 c.i.)

Bore × stroke:

96.0 × 96.0 mm (3.78 × 3.78 in)

Ignition system:

TCI

Spark plug (NGK):

ILMAR7H-9

Spark plug gap:

0.8–0.9 mm (0.031–0.035 in)

Steering system:

Remote steering

Starting system:

Electric starter

Starting carburetion system:

Fuel injection

Valve clearance IN (cold engine):

0.17–0.24 mm (0.0067–0.0094 in)

Valve clearance EX (cold engine):

0.37–0.44 mm (0.0146–0.0173 in)

Battery rating (CCA/SAE):

700 A

Battery rating (MCA/ABYC):

900 A

Battery rating (RC/SAE):

170 minutes

Battery rating (CCA/EN):

670 A

Battery rating (20HR/IEC):

110 Ah

Maximum generator output:

102 A (F450AVTU, F450AVTX,
FL450AVTU, FL450AVTX)

104 A (F400ASTU, F400ASTX,
FL400ASTU, FL400ASTX)

Lower unit:

Gear shift positions:

Forward-neutral-reverse

Gear ratio:

1.79 (25/14)

Trim and tilt system:

Power trim and tilt

Specifications and requirements

Propeller mark:

Y (F400ASTU, F400ASTX, F450AVTU,
F450AVTX)
YL (FL400ASTU, FL400ASTX,
FL450AVTU, FL450AVTX)

Fuel and oil:

Recommended fuel:

Premium unleaded gasoline

Min. pump octane number (PON):
89

Min. research octane number (RON):
94

Recommended engine oil:

YAMALUBE 4 or 4-stroke outboard
motor oil



Recommended engine oil grade 1:

SAE 10W-30/10W-40/5W-30
API SG/SH/SJ/SL

Engine oil quantity (without oil filter
replacement):

7.5 L (7.93 US qt, 6.60 Imp.qt)

Engine oil quantity (with oil filter
replacement):

7.8 L (8.24 US qt, 6.86 Imp.qt)

Lubrication system:

Wet sump

Recommended gear oil:

YAMALUBE outboard gear oil or Hypoid
gear oil

Recommended gear oil grade:

SAE 80W API GL-5 / SAE 90 API GL-5

Gear oil quantity:

1.830 L (1.934 US qt, 1.610 Imp.qt)
(FL400ASTU, FL400ASTX, FL450AVTU,
FL450AVTX)

1.950 L (2.061 US qt, 1.716 Imp.qt)
(F400ASTU, F400ASTX, F450AVTU,
F450AVTX)

Noise and vibration level:

Operator sound pressure level (ICOMIA
39/94):
83.1 dB(A)

EMU33556

Installation requirements

EMU33566

Boat horsepower rating

EWMO1561



WARNING

**Overpowering a boat can cause severe in-
stability.**

Before installing the outboard motor(s), con-
firm that the total horsepower of your out-
board motor(s) does not exceed the boat's
maximum horsepower rating. See the boat's
capacity plate or contact the manufacturer.

EMU40491

Mounting outboard motor

EWMO2501



WARNING

- **Improper mounting of the outboard mo-
tor could result in hazardous conditions
such as poor handling, loss of control,
or fire hazards.**
 - **Because the outboard motor is very
heavy, special equipment and training is
required to mount it safely.**
-

Your dealer or other person experienced in
proper rigging should mount the outboard
motor using correct equipment and complete
rigging instructions. For further information,
see page 38.

EMU34954

Digital electronic control re- quirements

The digital electronic control is equipped with
a start-in-gear protection device(s). This de-
vice prevents the engine from starting unless
it is in neutral.

Specifications and requirements

EWM01581



- If the engine starts in gear, the boat can move suddenly and unexpectedly, possibly causing a collision or throwing passengers overboard.
- If the engine ever starts in gear, the start-in-gear protection device is not working correctly and you should discontinue using the outboard. Contact your Yamaha dealer.

This digital electronic control unit is only available for the outboard motor which you have purchased.

Prior to use of the digital electronic control unit, set it in order to operate your outboard motor only. Otherwise, it will not be possible to operate the outboard motor.

Perform setting of the outboard motor and the digital electronic control unit in the following cases.

- If a used outboard motor is installed
- If the digital electronic control unit is replaced
- If the ECM (Electronic control module) of the used outboard motor is replaced
- If the ECM (Electronic control module) of the digital electronic control unit is replaced

Consult your Yamaha dealer for setting.

EMU25695

Battery requirements

EMU44881

Battery specifications

For U.S. insular areas

It is necessary to meet only two of the three specifications (CCA, MCA, and RC) in one of the following combinations:

- CCA/SAE and RC
- MCA/ABYC and RC

Battery rating (CCA/SAE):

700 A

Battery rating (MCA/ABYC):

900 A

Battery rating (RC/SAE):

170 minutes

For Others

Battery rating (CCA/EN):

670 A

Battery rating (20HR/IEC):

110 Ah

The engine cannot be started if battery voltage is too low.

EMU36293

Mounting battery

Mount the battery holder securely in a dry, well-ventilated, vibration-free location in the boat. **WARNING! Do not put flammable items, or loose heavy or metal objects in the same compartment as the battery. Fire, explosion or sparks could result.**

[EWM01821]

Battery cable

The battery cable size and length are critical. Consult your Yamaha dealer about the battery cable size and length.

EMU36303

Multiple batteries

To connect multiple batteries, such as for multiple engine configurations or for an accessory battery, consult your Yamaha dealer about battery selection and correct wiring.

Battery isolator

Your outboard motor is capable of charging an accessory battery separate from the starting battery using an optional isolator lead.

Specifications and requirements

Contact your Yamaha dealer for installation of an optional isolator lead with over-current protection.

EMU41604

Propeller selection


Next to selecting an outboard motor, selecting the right propeller is one of the most important purchasing decisions a boater can make. The type, size, and design of your propeller have a direct impact on acceleration, top speed, fuel economy, and even engine life. Yamaha designs and manufactures propellers for every Yamaha outboard motor and every application.

Your Yamaha dealer can help you select the right propeller for your boating needs. Select a propeller that will allow the engine to reach the middle or upper half of the operating range at full throttle with the maximum boatload. Generally, select a larger pitch propeller for a smaller operating load and a smaller pitch propeller for a heavier load. If you carry loads that vary widely, select the propeller that lets the engine run in the proper range for your maximum load but remember that you may need to reduce your throttle setting to stay within the recommended engine speed range when carrying lighter loads.

Yamaha recommends to use a propeller suitable for the "Shift Dampener System (SDS)". For further information, consult your Yamaha dealer.

To check the propeller, see page 80.

Propeller example



1. Propeller diameter in inches
2. Propeller pitch in inches
3. Type of propeller (propeller mark)

EMU36313

Counter rotation models

Standard outboard motors rotate clockwise. Counter rotation models rotate counterclockwise and are typically used in multiple motor setups.

On counter rotation models, be sure to use a propeller intended for counterclockwise rotation. These propellers are identified with the letter "L" after the size indication on the propeller. **WARNING! Never use a standard propeller with a counter rotation motor, or a counter rotation propeller with a standard motor. Otherwise the boat could go in the direction opposite of that expected (for example, reverse instead of forward), which could lead to an accident.** [EWM01811]

For instructions on propeller removal and installation, see page 80.

EMU35141

Start-in-gear protection

Yamaha outboard motors or Yamaha-approved digital electronic control units are equipped with start-in-gear protection device(s). This feature permits the engine to be started only when it is in neutral. Always select neutral before starting the engine.

Specifications and requirements

EMU41953

Engine oil requirements

Select an oil grade according to the average temperatures in the area where the outboard motor will be used.

Recommended engine oil:

YAMALUBE 4 or 4-stroke outboard motor oil

Recommended engine oil grade 1:

SAE 10W-30/10W-40/5W-30
API SG/SH/SJ/SL

Recommended engine oil grade 2:

SAE 15W-40/20W-40/20W-50
API SH/SJ/SL

Engine oil quantity (without oil filter replacement):


7.5 L (7.93 US qt, 6.60 Imp.qt)

Engine oil quantity (with oil filter replacement):

7.8 L (8.24 US qt, 6.86 Imp.qt)


If oil grades listed under Recommended engine oil grade 1 are not available, select an alternative oil grade listed under Recommended engine oil grade 2.

Recommended engine oil grade 1



ZMU08143

Recommended engine oil grade 2



ZMU06855

EMU36361

Fuel requirements

EMU44820

Gasoline

Use a good quality gasoline that meets the minimum octane rating. If knocking or pinging occurs, use a different brand of gasoline or premium unleaded fuel. Yamaha recommends that you use alcohol-free (see Gasohol) gasoline whenever possible.

Recommended fuel:

Premium unleaded gasoline

Min. pump octane number (PON):

89

Min. research octane number (RON):

94

ECM01982

NOTICE

- Do not use leaded gasoline. Leaded gasoline can seriously damage the engine.
- Avoid getting water and contaminants in the fuel tank. Contaminated fuel can cause poor performance or engine damage. Use only fresh gasoline that has been stored in clean containers.

Gasohol

There are two types of gasohol: gasohol containing ethanol (E10) and that containing methanol. Ethanol can be used if the ethanol

Specifications and requirements


content does not exceed 10% and the fuel meets the minimum octane ratings. All ethanol blends containing more than 10% ethanol can cause fuel system damage or cause engine starting and running problems. Yamaha does not recommend gasohol containing methanol because it can cause fuel system damage or engine performance problems.

EMU36331

Anti-fouling paint

A clean hull improves boat performance. The boat bottom should be kept as clean of marine growth as possible. If necessary, the boat bottom can be coated with an anti-fouling paint approved for your area to inhibit marine growth.

Do not use anti-fouling paint which includes copper or graphite. These paints can cause more rapid engine corrosion.



ZMU05176

EMU40302

Outboard motor disposal requirements

Never illegally discard (dump) the outboard motor. Yamaha recommends consulting the dealer about discarding the outboard motor.

EMU36353

Emergency equipment

Keep the following items onboard in case there is trouble with the outboard motor.

- A tool kit with assorted screwdrivers, pliers, wrenches (including metric sizes), and electrical tape.

- Waterproof flashlight with extra batteries.
- An extra engine shut-off cord (lanyard) with clip.
- Spare parts, such as an extra set of spark plugs.

Consult your Yamaha dealer for details.

EMU25223

Emission control information

EMU25311


U.S. insular areas

Engines affixed with the label pictured below conform to U.S. Environmental Protection Agency (EPA) regulations for marine SI engines. See the label affixed to your engine for details.

EMU47930

Approval label of emission control certificate

This label is attached at the location shown. New Technology; (4-stroke) DFI



1. Approval label location




ZMU06894

EMU48680

Components diagram

TIP:


* May not be exactly as shown; also may not be included as standard equipment on all models (order from dealer).



1. Top cowling
2. Cowling lock lever
3. Anti-cavitation plate
4. Cooling water inlet
5. Anode
6. Power trim and tilt unit

7. Clamp bracket
8. Idle hole
9. Propeller*

Components




1. Oil dipstick
2. Oil filler cap
3. Fuse box
4. Fuel filter
5. Power trim and tilt switch
6. Flushing device

EMU46733




Optional items

The following items are available from your Yamaha dealer. For details, consult your Yamaha dealer.



1. CL5 Display





For single-engine boats



1. Digital electronic control
2. Switch panel
3. Start/Stop switch panel (sub station)
4. Engine shut-off switch panel (sub station)
5. Joystick (upgradable)
6. Autopilot (upgradable)






Components

For twin-engine boats



1. Digital electronic control
2. Switch panel
3. Start/Stop switch panel
4. All Start/Stop switch panel
5. Engine shut-off switch panel (sub station)
6. Joystick (upgradable)
7. Autopilot (upgradable)

For triple-engine boats



1. Digital electronic control
2. Switch panel
3. Start/Stop switch panel
4. All Start/Stop switch panel
5. Engine shut-off switch panel (sub station)
6. Joystick (upgradable)
7. Autopilot (upgradable)

Components

EMU48695

Helm Master™ EX (upgradable)

TIP:

For further information about the Helm Master EX, consult your Yamaha dealer.


Joystick

Because the joystick allows you to move the boat laterally left or right or pivot it 360 degrees in place using the single joystick lever, you can maneuver the boat easily when leaving or arriving at a dock or when traveling in narrow waterways or other tight spaces, such as in marinas.



Autopilot

The Autopilot supports steering operations, allowing you to keep correct bow direction and travel while maintaining a constant route.



EMU48460

Digital electronic control


The digital electronic control actuates the shifter, throttle and remote electrical operations. Make sure that the digital electronic

control-alert indicator lights in blue and that the digital electronic control unit is correctly connected to the outboard motor. The digital electronic controls of the main station and sub station have the same functions.

TIP:


This manual mainly covers basic operation. For more information, see the 6X9 DIGITAL ELECTRONIC CONTROL operation manual.

Single engine




1. Control lever
2. "NEUTRAL HOLD" switch
3. "STATION" switch
4. DEC alert indicator
5. Speed control switch
6. Power trim and tilt switch

Twin engines / Triple engines



1. Control lever
2. "SINGLE LEVER" switch
3. "CENTER ENGINE" switch (triple engines)
4. "NEUTRAL HOLD" switch
5. "STATION" switch
6. DEC alert indicator
7. Speed control switch
8. Power trim and tilt switch (all engines)



1. Power trim and tilt switch (individual engine)


EMU48471

Control lever

Lowering the lever from the neutral position to the bow side 22.5° (a detent can be felt) engages the forward gear. Lowering the lever to the stern side engages the reverse gear and the engine begins to run at the lowest speed. Lowering the lever farther opens the throttle, and the engine will begin to accelerate.

TIP:

You can adjust the resistance of the control lever movement. For further information, see the 6X9 DIGITAL ELECTRONIC CONTROL operation manual.



1. Neutral "N"
2. Forward "F"
3. Reverse "R"
4. Shift
5. Fully closed
6. Throttle
7. Fully open

EMU48480


Power trim and tilt switches

Pushing the switch "UP" (up) trims the outboard motor up, and then tilts it up. Pushing the switch "DN" (down) tilts the outboard motor down and trims it down. When the switch is released, the outboard motor will stop in its current position.

Components



For multiple engine applications, the switch on the control lever controls all outboard motors at the same time.

Single engine



1. Power trim and tilt switch

Twin engines / Triple engines



1. Power trim and tilt switch (all engines)
2. Power trim and tilt switch (individual engine)


EMU48491

DEC alert indicator

The alert indicator changes from blue to orange if a connection problem between the digital electronic control and the outboard


motor occurs. A beep also sounds (repeatedly on and off) to alert the operator. For more information, consult your Yamaha dealer.

Single engine



1. DEC alert indicator

Twin engines / Triple engines




1. DEC alert indicator

EMU48503

Speed control switch


There are two modes for keeping the engine speed and speed. Pressing the "UP" (up) / "DN" (down) switch enables you to keep the engine speed or to adjust the speed.

Single engine



1. Speed control switch

Twin engines / Triple engines




1. Speed control switch

EMU48512

Neutral hold switch


When the “NEUTRAL HOLD” switch is pressed, the buzzer will sound and the LED will come on. You will be able to open or close the throttle with the shift control in neutral. This can also be done when the control lever is set in reverse. For further information, see page 54.

Single engine



1. “NEUTRAL HOLD” switch
2. LED

Twin engines / Triple engines



1. “NEUTRAL HOLD” switch
2. LED

EMU48531

Station selector switch

The “STATION” switch can select either the main station or sub station for operating the boat.


The “STATION” switch can be used when the control lever is in the “N” (neutral) position. The LED for the operating seat that can operate the boat comes on.

TIP:

- Even the not-selected station can start and stop the engine.
- The LED blinks 3 times if station selection fails.


Components

Single engine




1. "STATION" switch
2. LED

Triple engines



1. "CENTER ENGINE" switch
2. LED

Twin engines / Triple engines



1. "STATION" switch
2. LED

EMU48543

Center engine switch

When the "CENTER ENGINE" switch is pressed while all engines have been started, the buzzer will sound and the LED will come on. While the LED is lit, the port side control lever allows you to perform shift and throttle operations for the center engine only. For further information, see page 54.

EMU48550


Single lever switch

For multiple engines, when the "SINGLE LEVER" switch is pressed, the buzzer will sound, the LED will come on, and the port side control lever will allow you to perform shift and throttle operations for all outboard motors that have been started. For further information, see page 55.

TIP:

- When the single lever switch is activated, the starboard control lever is inoperable.
- You must start all the engines to enable the single lever switch.

Twin engines / Triple engines



1. "SINGLE LEVER" switch
2. LED

EMU48643

6X6 switch

EMU41554

Main switch

The main switch controls the ignition system; its operation is described below.

- **“OFF” (off)**

With the main switch in the “OFF” (off) position, the electrical circuits are off, and the key can be removed.


- **“ON” (on)**

With the main switch in the “ON” (on) position, the electrical circuits are on, and the key cannot be removed. The engine can be started by pressing the Start/Stop button.

- **“START” (start)**


With the main switch in the “START” (start) position, the starter motor turns to start the engine. When the key is released, it returns automatically to the “ON” (on) position.

Single engine



ZMU07145

Twin engines / Triple engines




ZMU07146

EMU42082


Start/Stop switch panel

The engine can be started or turned off by pressing the Start/Stop button. For twin and triple type, it is possible to start or turn off individual engine. The indicator for the corresponding engine will come on.

- **PORT:** Port side engine
- **CENTER:** Center engine
- **STBD:** Starboard side engine



1. Indicator
2. Start/Stop button




1. Indicator
2. Start/Stop button

EMU41633


All Start/Stop switch panel (optional)

The Start/Stop button allows all engines to start or turn off.

Components



1. All Start/Stop button



1. Engine shut-off cord (lanyard)

EMU35775

Engine shut-off cord (lanyard) and clip

The clip must be attached to the engine shut-off switch for the engine to run. The cord should be attached to a secure place on the operator's clothing, or arm or leg. Should the operator fall overboard or leave the helm, the cord will pull out the clip, stopping ignition to the engine. This will prevent the boat from running away under power.


EWMO1791

WARNING

- **Attach the engine shut-off cord to a secure place on your clothing, or your arm or leg while operating.**
- **Do not attach the cord to clothing that could tear loose. Do not route the cord where it could become entangled, preventing it from functioning.**
- **Avoid accidentally pulling the cord during normal operation. Loss of engine power means the loss of most steering control. Also, without engine power, the boat could slow rapidly. This could cause people and objects in the boat to be thrown forward.**

TIP:

The engine cannot be started with the clip removed.



1. Engine shut-off switch
2. Clip
3. Engine shut-off cord (lanyard)

EMU48651

Outboard motor equipment

EMU26156

Power trim and tilt switch on bottom cowling


The power trim and tilt switch is located on the side of the bottom cowling. Pushing the switch "UP" (up) trims the outboard motor up, and then tilts it up. Pushing the switch "DN" (down) tilts the outboard motor down and trims it down. When the switch is released, the outboard motor will stop in its current position.

For instructions on using the power trim and tilt switch, see page 61.

EWM01032

WARNING

Use the power trim and tilt switch located on the bottom cowling only when the boat is at a complete stop with the engine off. Attempting to use this switch while the boat is moving could increase the risk of falling overboard and could distract the operator, increasing the risk of collision with another boat or an obstacle.



1. Power trim and tilt switch

EMU35041

Tilt limiter

This outboard motor is equipped with a tilt limiter that controls the tilt range.



TIP:

Consult your Yamaha dealer about changing the setting.

EMU47780

Tilt support lever for power trim and tilt model

To keep the outboard motor in the tilted up position, lock the tilt support lever to the clamp bracket. Make sure that the lever is securely held in place by the bolts.



1. Tilt support lever

TIP:

To use the lower tilted up position, remove the upper bolts.

ECM00661

NOTICE


Do not use the tilt support lever or knob when trailering the boat. The outboard motor could shake loose from the tilt support and fall. If the motor cannot be trailered in the normal running position, use an additional support device to secure it in the tilt position.

EMU40762


Cowling lock lever

The cowling lock levers are used to secure the top cowling.

Components



1. Cowling lock lever




1. Cowling lock lever

EMU40803

Flushing device

The flushing device is used to clean the cooling water passages of the outboard motor using a garden hose and tap water. For instructions on using the flushing device, see page 70.




1. Flushing device

EMU41312

Fuel filter

The fuel filter functions to remove foreign material and separate water from the fuel. If water separated from the fuel exceeds a specific volume, the alert system will activate. For further information, see page 36.



1. Fuel filter

Instruments and indicators

EMU48593


CL5 Display

The CL5 Display shows engine status and alert information. The display can be changed. This manual mainly covers the alert display.


If a warning message appears on the CL5 Display, follow the instructions on the display.

TIP:

- The functions shown in the display varies according to the equipment of the boat.
- For more information, see the CL5 owner's manual.



1. Touchscreen
2. Power button



1. Autopilot button (Equipped with an Autopilot panel)
2. Boat status
3. Speedometer
4. Shift position
5. Tank level

6. Engine condition
7. Boat control indicator
8. Boat control mode button (Equipped with a Joystick)
9. Trim angle
10. Engine alert
11. Tachometer
12. Sub status
13. Engine status

GPS signal strength icons

The icons shown in the upper-right of the engine screen indicate the GPS signal strength. "📶" shows GPS satellite signal strength according to the number of antenna symbol. "📶×" shows no GPS antenna connection.

TIP:

To use the GPS feature, a GPS receiver must be connected to this device.

Contact your Yamaha dealer for information on how to connect a GPS receiver.

Engine condition icons

Orange icons indicate engine conditions.

● Yamaha Security System indicator "🔒" (optional)

This indicator appears when the Yamaha Security System is in lock mode. Make sure it is off before starting the engine.

TIP:

This function is displayed when the 6X6 switch panel is equipped.

● Engine warm-up indicator "🔥"

This indicator appears while the engine is being warmed up and goes off when warming-up is finished.


● Engine synchronization indicator "🔄"

In multiple engine types, this indicator appears while the engines are under synchronization control. It goes off when engine synchronization control is released.

Instruments and indicators


Engine alert icons

Red icons indicate engine abnormalities. When an abnormality occurs, a pop-up window will be displayed, and the buzzer will sound.



1. Pop-up window
2. Confirm button

Press the confirm button to change to the normal display. The engine alert icon will start to blink.



1. Engine alert icon

ECM00093

NOTICE

Do not continue to operate the engine if an alert device has activated. Consult your Yamaha dealer if the problem cannot be located and corrected.

The engine alert icon will appear according to the kind of abnormality. The symbols and their explanations are described below.

● Overheat alert “”

If the engine temperature rises too high while cruising, this alert will be activated. Stop the engine immediately. Check the cooling water inlet for clogging, and clear it if it is blocked.

ECM01594

NOTICE

- **Do not continue to run the engine if the overheat-alert indicator blinks. Serious engine damage will occur.**
- **Do not continue to operate the engine if an alert device has activated. Consult your Yamaha dealer if the problem cannot be located and corrected.**

● Low oil pressure alert “”

If the engine oil pressure drops too low, this alert will be activated. Stop the engine immediately. Check the engine oil level and replenish oil if necessary. If the alert device has activated while the appropriate engine oil level is maintained, consult your Yamaha dealer.

ECM01602

NOTICE

Do not continue to run the engine if the low oil pressure alert device has activated. Serious engine damage will occur.

● Water in Fuel Alert “”

If water has accumulated in the water separator (fuel filter) while cruising, this alert will be activated. Stop the engine immediately and see page 91 of this manual to drain the water from the fuel filter. Consult a Yamaha dealer.

ECM00911

NOTICE

Gasoline mixed with water could cause damage to the engine.

- **Low battery voltage alert** “”

If the battery voltage drops, this alert will be activated. If the low battery voltage alert device has activated, return to port and consult a Yamaha dealer immediately. To charge the battery, consult your Yamaha dealer.

- **Check engine alert** “”

If the engine malfunctions while cruising, this alert will be activated. Return to port and consult a Yamaha dealer immediately.

- **Check System / Steering Malfunction Alert**

If a malfunction occurs in the system, the system alert will be activated. Return to port immediately and contact your Yamaha dealer.

Engine control system

EMU26806

Alert system

ECM00093

NOTICE

Do not continue to operate the engine if an alert device has activated. Consult your Yamaha dealer if the problem cannot be located and corrected.

EMU47362


Helm Master control system alert

The Helm Master control system alert information is displayed on the display installed in the boat. For further information, see the owner's manual.


EMU35188

Digital electronic control alert

If during operation of the outboard motor any communication troubles between the digital electronic control and the outboard motor occur, the DEC alert indicator will change from blue to orange. Even if there is no symptom of trouble with shifting or throttle, get back to port soon and have a Yamaha dealer inspect or repair the outboard motor.



1. DEC alert indicator



1. DEC alert indicator

EMU47384

Overheat alert

This outboard motor has an overheat alert system. If the engine temperature rises too high, the alert system will activate.


- The engine speed will automatically decrease to about 2000–3500 r/min.
- The overheat-alert indicator will come on or blink.
- The pop-up window will appear on the Multi-Display.



- The buzzer will sound. (The device that produces the sound may be different depending on the equipment installed on the boat.)


Engine control system

Illustration showing an example of the possible buzzer location




If the alert system has activated, stop the engine and check the cooling water inlets.

- Check the trim angle to be sure that the cooling water inlets are submerged.



1. Cooling water inlet

- Check the cooling water inlets for clogging.




1. Cooling water inlet

Multiple-engine users

If the overheat alert system of one outboard motor activates, the engine will slow down.

To turn off the alert activation on the outboard motors not affected by overheating

- (1) Stop the overheated engine.




1. Main switch

TIP:

If the alert system has activated, stop the engine and tilt the outboard motor up to check the cooling water inlets for clogging.

- (2) If the alert system is still activated, tilt the overheated outboard motor up and return to port.



ZMU01815

EMU47395

Low oil pressure alert

If the oil pressure drops too low, the alert system will activate.


- The engine speed will automatically decrease to about 2000–3500 r/min.
- The low oil pressure-alert indicator will come on or blink.
- The pop-up window will appear on the Multi-Display.

Engine control system



- The buzzer will sound. (The device that produces the sound may be different depending on the equipment installed on the boat.)

Illustration showing an example of the possible buzzer location



TIP:


If the alert system has activated, stop the engine as soon as it is safe to do so. Check the oil level and add oil as needed. If the oil level is correct and the alert system does not turn off, consult your Yamaha dealer.

Multiple-engine users

If the low oil pressure alert system of one outboard motor activates, all of the engines will slow down and the buzzer will sound.

To turn off the alert activation on the outboard motors not affected by the low oil pressure

Stop the engine that has the low oil pressure.



1. Main switch

EMU47403

Water separator alert

The outboard motor is equipped with a water separator alert system. If water separated from the fuel exceeds a specific volume, the alert system will activate.

- The water separator-alert indicator will come on or blink.
- The pop-up window will appear on the Multi-Display.



- The buzzer will sound intermittently when the control lever is in the neutral position.

If the alert system has activated

Stop the engine and see page 94 of this manual to drain the water from the fuel filter. Return to port and consult a Yamaha dealer immediately.

ECM02471

NOTICE

Although the buzzer will stop when the engine is started and the control lever is moved to the forward or reverse position, do not use the outboard motor. Otherwise, serious engine damage could occur.

Installation

EMU26903

Installation

The information presented in this section is intended as reference only. It is not possible to provide complete instructions for every possible boat and motor combination. Proper mounting depends in part on experience and the specific boat and motor combination.

EWM01591



WARNING

- **Overpowering a boat could cause severe instability. Do not install an outboard motor with more horsepower than the maximum rating on the capacity plate of the boat. If the boat does not have a capacity plate, consult the boat manufacturer.**
- **Improper mounting of the outboard motor could result in hazardous conditions such as poor handling, loss of control, or fire hazards. For permanently mounted models, your dealer or other person experienced in proper rigging should mount the motor.**

EMU35812


Mounting the outboard motor

The outboard motor should be mounted so that the boat is well balanced. Otherwise, the boat could be hard to steer. For single-engine boats, mount the outboard motor on the centerline (keel line) of the boat.


For twin engine boats, mount the outboard motors equidistant from the centerline.

For triple engine boats, mount the center outboard motor on the centerline (keel line), and the port side and starboard side outboard motors equidistant from the center outboard motor.


Consult your Yamaha dealer or boat manufacturer for further information on determining the proper mounting location.



1. Center line (keel line)



1. Center line (keel line)



1. Center line (keel line)

EMU26937


Mounting height (boat bottom)

The mounting height of your outboard motor affects its efficiency and reliability. If it is mounted too high, propeller ventilation may occur, which will reduce propulsion due to excessive propeller slip, and the water intakes for the cooling system may not get an adequate water supply, which can cause en-

engine overheating. If the engine is mounted too low, water resistance (drag) will increase, thereby reducing engine efficiency and performance.

Most commonly, an outboard motor should be mounted so that the anti-cavitation plate is in alignment with the bottom of the boat. The optimum mounting height of the outboard motor is affected by the boat/motor combination and the desired use. Test runs at different heights can help determine the optimum mounting height. Consult your Yamaha dealer or boat manufacturer for further information on determining the proper mounting height.

enter the engine through the air intake opening in the top cowling to cause severe engine damage. Remove the cause of the airborne water spray.



1. Idle hole

ECM01635

NOTICE

- **Make sure that the idle hole is high enough to prevent water from entering the engine even if the boat is stationary with the maximum load.**
- **Incorrect engine height or obstructions to the smooth flow of water (such as the design or condition of the boat, or accessories, such as transom ladders or depth finder transducers) can create airborne water spray while the boat is cruising. If the outboard motor is operated continuously in the presence of airborne water spray, enough water could**

Operation

EMU36382

First-time operation


EMU40512

Filling engine oil

The outboard motor is shipped from the factory without engine oil. If your Yamaha dealer did not fill the engine with engine oil, you must fill the engine before starting it. **NOTICE: Make sure that the engine is filled with engine oil before operating the outboard motor for the first time. Otherwise, the engine could be damaged severely.**

[ECM02241]

The following tag, which is fitted on the outboard motor when it is shipped from the factory, should be removed after the engine is filled with engine oil for the first time. For more information on checking the engine oil level, see page 43.



ZMU01710

EMU30175

Breaking in engine

Your new engine requires a period of break-in to allow mating surfaces of moving parts to wear in evenly. Correct break-in will help ensure proper performance and longer engine life. **NOTICE: Failure to follow the break-in procedure could result in reduced engine life or even severe engine damage.** [ECM00802]

EMU41223

Procedure for breaking in engine

Your new engine requires a period of 10 hours break-in so that mating surfaces of moving parts wear in evenly.

Operate the engine in the water under load (in gear with a propeller installed) for 10 hours as follows. When breaking in the engine, avoid extended idling, rough water, and crowded areas.

- (1) For the 1st hour of operation:
Operate the engine at varying speeds up to 2000 r/min or approximately 1/2 throttle.
- (2) For the 2nd hour of operation:
Increase the engine speed until the boat is on plane (but avoid full-throttle operation), and then back off on the throttle while keeping the boat at a planing speed.
- (3) For the remaining 8 hours of operation:
Operate the engine at any speed. However, avoid operating at full throttle for more than 5 minutes at a time.
- (4) After the 1st 10 hours of operation:
Operate the engine normally.

EMU36402

Getting to know your boat

All boats have unique handling characteristics. Operate cautiously while you learn how your boat handles under different conditions and various trim angles (see page 59).

EMU36414

Checks before starting engine

EWM01922

WARNING

If any item in “Checks before starting engine” is not working properly, have it inspected and repaired before operating the outboard motor. Otherwise, an accident could occur.

ECM00121

NOTICE

Do not start the engine out of water. Overheating and serious engine damage can occur.

EMU36422

Fuel level

Be sure you have plenty of fuel for your trip. A good rule is to use 1/3 of your fuel to get to the destination, 1/3 to return, and to keep 1/3 as an emergency reserve. With the boat level on a trailer or in the water, turn the key to “ON” (on) and check the fuel level. For fuel filling instructions, see page 46.


EMU47580

Removing top cowling


For the following checks in this chapter, remove the top cowling.

To remove the top cowling

- (1) Pull the cowling lock levers outward, and then turn them upward.



1. Cowling lock lever



1. Cowling lock lever

- (2) Lift up the top cowling.



1. Top cowling

Operation

EMU36443

Fuel system

EWM00061

WARNING

Gasoline and its vapors are highly flammable and explosive. Keep away from sparks, cigarettes, flames, or other sources of ignition.

EWM00911

WARNING

Leaking fuel can result in fire or explosion.

- Check for fuel leakage regularly.
- If any fuel leakage is found, the fuel system must be repaired by a qualified mechanic. Improper repairs can make the outboard unsafe to operate.

EMU36453


Check for fuel leaks

- Check for fuel leaks or gasoline fumes in the boat.
- Check for fuel leakage from the fuel system.
- Check the fuel tank and fuel lines for cracks, swellings, or other damage.

EMU37323

Checking the fuel filter

Check that the fuel filter is clean and free of water. If any water is found in the fuel, or if a significant amount of debris is found, the fuel tank should be checked and cleaned by a Yamaha dealer.




1. Fuel filter


EMU47812

Controls

- (1) Make sure that when the main switch is turned “ON” (on) or the “POWER” switch is pressed, the DEC alert indicator will come on in blue.



1. DEC alert indicator




1. DEC alert indicator

- (2) Turn the steering wheel fully to the left and right and make sure that the outboard motor moves to port and starboard smoothly.
- (3) Operate the throttle levers several times to make sure there is no hesitation in their travel.

EMU40363

Engine shut-off cord (lanyard)

Check the engine shut-off cord and clip for damage, such as cuts, breaks, and wear.




ZMU06873

1. Clip
2. Engine shut-off cord (lanyard)

EMU40994


Engine oil

- (1) Place the engine outboard motor in a vertical position (not tilted). **NOTICE: If the outboard motor is not level, the oil level indicated on the oil dipstick may not be accurate.** [ECM01862]
- (2) Remove the oil dipstick and wipe it clean.



1. Oil dipstick

- (3) Insert the oil dipstick completely and remove it again.
- (4) Check that the oil level on the oil dipstick is between the upper and lower marks. Consult your Yamaha dealer if the oil level is not at the proper level or if it appears milky or dirty.



1. Oil dipstick
2. Upper mark
3. Lower mark

EMU40412

Outboard motor

- Check that the outboard motor is mounted properly and check the outboard motor mounting bolts for looseness.
- Check the propeller for damage.
- Check for engine oil leaks.


Operation

EMU49240

Flushing device

Check that the garden hose connector cap on the bottom cowling is securely installed.

NOTICE: If the garden hose connector cap is not properly installed, cooling water can leak out and the engine can overheat during operation. [ECM05750]




1. Garden hose connector cap

EMU47570

Installing top cowling

(1) Check the rubber seal for damage. If the rubber seal is damaged, have it replaced by a Yamaha dealer.




1. Rubber seal
2. Apron

(2) Check that the rubber seal is seated all the way around the aprons.


(3) Check that all of the cowling lock levers are pulled outward and turned upward.

(4) Place the top cowling on the aprons.





1. Top cowling

(5) Turn the cowling lock levers downward, and then push them inward to secure the top cowling.



1. Cowling lock lever



1. Cowling lock lever

- (6) Check the fitting of the top cowling by pushing it with both hands. **NOTICE: If the top cowling is not installed correctly, water can enter the top cowling and damage the engine, or the top cowling can blow off at high speeds.**

[ECM02371]



EMU35245


Checking power trim and tilt system

EWM01931

WARNING


- Never get under the lower unit while it is tilted, even when the tilt support lever is locked. Severe injury could occur if the outboard motor accidentally falls.
- Body parts can be crushed between the motor and the clamp bracket when the motor is trimmed or tilted.
- Be sure no one is near the outboard motor before performing this check.

- (1) Check the power trim and tilt unit for any sign of oil leaks.
- (2) Operate each of the power trim and tilt switches on the digital electronic control and engine bottom cowling (if equipped) to check that all switches work.
- (3) Tilt the outboard motor up and check that the tilt rod and trim rods are extended completely.



1. Tilt rod
2. Trim rod


- (4) Use the tilt support lever to lock the motor in the up position. Operate the tilt down switch briefly so the motor is supported by the tilt support lever.



1. Tilt support lever


- (5) Check that the tilt rod and trim rods are free of corrosion or other flaws.
- (6) Activate the tilt-down switch until the trim rods have retracted completely into the cylinders.

Operation



1. Trim rod

- (7) Activate the trim-up switch until the tilt rod is fully extended. Unlock the tilt support lever.



1. Tilt rod

2. Tilt support lever

- (8) Tilt the outboard motor down. Check that the tilt rod and trim rods operate smoothly.

EMU36585

Battery

Check the battery's charge. If your boat is equipped with a Yamaha digital speedometer, the voltmeter and low battery alert functions will help you monitor the battery's charge. A battery in good condition will provide a minimum of 12 volts. Check that the battery connections are clean, secure and covered by insulating covers. The electrical

connections of the battery and cables must be clean and properly connected or the battery will not start the engine.

If the battery needs charging, consult your Yamaha dealer or the battery manufacturer's instructions.

EMU47642

Filling fuel

EWM01831



- Gasoline and its vapors are highly flammable and explosive. Always refuel according to this procedure to reduce the risk of fire and explosion.
- Gasoline is poisonous and can cause injury or death. Handle gasoline with care. Never siphon gasoline by mouth. If you should swallow some gasoline or inhale a lot of gasoline vapor, or get some gasoline in your eyes, see your doctor immediately. If gasoline spills on your skin, wash with soap and water. If gasoline spills on your clothing, change your clothes.

ECM05272

NOTICE

Check the amount of remaining fuel regularly. Running out of fuel can damage the engine.

- (1) Make sure that the engine is stopped.
- (2) Make sure that the boat is in a well-ventilated outdoor area, either securely moored or trailered.
- (3) Make sure that no one is in the boat.
- (4) Do not smoke and keep away from sparks, flames, static electric discharge, or other sources of ignition.
- (5) If you use a portable container to store and dispense fuel, only use a locally approved GASOLINE container.

- (6) Touch the fuel nozzle to the filler opening or funnel to help prevent electrostatic sparks.
- (7) Fill the fuel tank. **WARNING! Do not overfill. Otherwise fuel can expand and overflow if the temperature increases.** [EWM02611]
- (8) Tighten the fuel tank cap securely.
- (9) Wipe up any spilled gasoline immediately with dry rags. Dispose of rags properly according to local laws or regulations.

EMU40252

Operating engine

EWM02601




WARNING

This product emits exhaust gases which contain carbon monoxide, a colorless, odorless gas which could cause brain damage or death when inhaled. Symptoms include nausea, dizziness, and drowsiness. Keep cockpit and cabin areas well ventilated. Avoid blocking exhaust outlets.

EMU31814

Sending fuel

- (1) If there is a fuel joint or a fuel valve on the boat, firmly connect the fuel line to the joint or open the fuel valve.
- (2) Squeeze the primer pump, with the arrow pointing up, until you feel it become firm.



ZMU02025

1. Arrow

EMU27496

Starting engine

EWM01601



WARNING

Before starting the engine, make sure that the boat is tightly moored and that you can steer clear of any obstructions. Be sure there are no swimmers in the water near you.

EMU41792

Start-up checks

Place the control lever in neutral and turn the main switch to "ON" (on) or turn the "POWER" switch on. If the buzzer sounds and the water separator-alert indicator blinks, consult a Yamaha dealer immediately.

EMU48763

Procedure for single station models (6X6 switch)

EWM01842




WARNING

- Failure to attach the engine shut-off cord could result in a runaway boat if operator is ejected. Attach the engine shut-off cord to a secure place on your clothing, or your arm or leg while operating. Do not attach the cord to clothing that could tear loose. Do not route the cord where it could become entangled, preventing it from functioning.

Operation

- **Avoid accidentally pulling the cord during normal operation. Loss of engine power means the loss of most steering control. Also, without engine power, the boat could slow rapidly. This could cause people and objects in the boat to be thrown forward.**


- (1) Place the control lever in “N” (neutral).




TIP:

The start-in-gear protection device prevents the engine from starting except when in neutral.

- (2) Attach the engine shut-off cord to a secure place on your clothing, or your arm or leg. Then install the clip on the other end of the cord into the engine shut-off switch.




1. Engine shut-off cord (lanyard)




1. Engine shut-off switch
2. Clip
3. Engine shut-off cord (lanyard)

- (3) Turn the main switch to “ON” (on) and make sure that the DEC alert indicator comes on in blue. The engine cannot be started if the DEC alert indicator comes on in orange.




1. Main switch
- (4) Turn the main switch to “START” (start), and hold it for a maximum of 5 seconds. **NOTICE: Never turn the main switch to “START” (start) while the engine is running. Do not keep the starter motor turning for more than 5 seconds. If the starter motor is turned continuously for more than 5 seconds, the battery will be quickly discharged, thus making it impossible to start the engine. The starter can also be damaged. If the engine will not start after 5 sec-**

onds of cranking, return the main switch to “ON” (on), wait 10 seconds, then crank the engine again. [ECM00193]




1. Main switch

When starting the engine using the Start/Stop button, press the button to start the engine. The indicator for the starting engine will come on.



ZMU07148



ZMU07149

When starting the engine using the All Start/Stop button on the All Start/Stop switch panel, press the button to start the all engines.



ZMU07150


TIP:

- When the main switch is turned to “START” (start) with the clip removed from the engine shut-off switch, the buzzer will sound.
- Except the single type, if the clip is not installed to the engine shut-off switch, the buzzer will sound when the Start/Stop button is pressed.
- Except the single type, if one of the engines has started, it can be stopped by pressing the Start/Stop button on the All start/Stop panel.

EMU48772

Procedure for dual station models (main station/6X6 switch)

- (1) Place the control lever in “N” (neutral).




Operation

TIP:


The start-in-gear protection device prevents the engine from starting except when in neutral.

- (2) Turn the main switch to “ON” (on) and make sure that the DEC alert indicator comes on in blue. The engine cannot be started if the DEC alert indicator comes on in orange.




1. Main switch

- (3) Push the “STATION” switch. Station change is only possible when all control levers have been set to “N” (neutral). Make sure that the DEC alert indicator comes on in blue.



1. “STATION” switch
2. LED



1. “STATION” switch
2. LED

- (4) The procedure until starting the engine is the same as that of the single station models. **NOTICE: Never turn the main switch to “START” (start) while the engine is running. Do not keep the starter motor turning for more than 5 seconds. If the starter motor is turned continuously for more than 5 seconds, the battery will be quickly discharged, thus making it impossible to start the engine. The starter can also be damaged. If the engine will not start after 5 seconds of cranking, return the main switch to “ON” (on), wait 10 seconds, then crank the engine again.** [ECM00193]

TIP:

The sub station can start and stop the engine. However, it cannot operate the digital electronic control.

EMU48782

Procedure for dual station models (sub station/6X6 switch)

EWM01842


WARNING

- Failure to attach the engine shut-off cord could result in a runaway boat if operator is ejected. Attach the engine shut-off cord to a secure place on your clothing, or your arm or leg while operating. Do not attach the cord to clothing


that could tear loose. Do not route the cord where it could become entangled, preventing it from functioning.

- Avoid accidentally pulling the cord during normal operation. Loss of engine power means the loss of most steering control. Also, without engine power, the boat could slow rapidly. This could cause people and objects in the boat to be thrown forward.

- (1) Turn the main switch of the main station to “ON” (on) and make sure that the DEC alert indicator comes on in blue. The engine cannot be started if the DEC alert indicator comes on in orange.
- (2) Place the control lever in “N” (neutral).
- (3) Push the “STATION” switch of the sub station. Station change is only possible when all control levers have been set to “N” (neutral). Make sure that the DEC alert indicator of the sub station comes on in blue.



1. “STATION” switch
2. LED




1. “STATION” switch
2. LED

TIP:

The main station can still start and stop the engine. However, it cannot operate the digital electronic control.

- (4) Attach the engine shut-off cord to a secure place on your clothing, or your arm or leg. Then install the clip on the other end of the cord into the engine shut-off switch.




ZMU07322

- (5) Press the Start/Stop button to start the engine. The indicator for the starting engine will come on. **NOTICE: Do not keep the starter motor turning for more than 5 seconds. If the starter motor is turned continuously for more than 5 seconds, the battery will be quickly discharged, thus making it impossible to start the engine. The starter can also be damaged. If the engine will not**

Operation

start after 5 seconds of cranking, release the Start/Stop button, wait 10 seconds, then crank the engine again.

[ECM02491]



1. Start/Stop button

TIP:

If the clip is not installed to the engine shut-off switch, the buzzer will sound when the Start/Stop button is pressed.

EMU36511

Checks after starting engine

EMU41361

Cooling water

Check for a steady flow of water from the cooling water pilot hole. A continuous flow of water from the cooling water pilot hole shows that the water pump is pumping water through the cooling water passages.

TIP:


When the engine is started, there may be a slight delay before water flows from the cooling water pilot hole.

ECM02251

NOTICE

If water is not flowing out of the cooling water pilot hole at all times while the engine is running, overheating and serious damage could occur. Stop the engine and check whether the cooling water inlet on the lower case or the cooling water pilot

hole is blocked. Consult your Yamaha dealer if the problem cannot be located and corrected.



1. Cooling water pilot hole

EMU27671


Warming up engine

EMU47821

Procedure for warming up engine

After the engine has started, warm up the engine until the engine speed settles at idling speed.

The engine warm-up indicator “ CE ” appears while the engine is being warmed up and goes off when warming-up is finished.



1. Engine warm-up indicator

EMU36532

Checks after engine warm up

EMU36542

Shifting

While the boat is tightly moored, and without applying throttle, confirm that the engine shifts smoothly into forward and reverse, and back to neutral.

EMU41821

Stop switches

Perform the following procedure to check that the main switch and engine shut-off switch operate properly.

- Check that the engine stops when the main switch is turned to the "OFF" (off) position, or press the Start/Stop button.
- Check that the engine stops when the clip is pulled from the engine shut-off switch.
- Check that the engine cannot be started with the clip removed from the engine shut-off switch.

EMU35126

Shifting

EWM00181


WARNING

Before shifting, make sure there are no swimmers or obstacles in the water near you.

Warm up the engine before shifting into gear. Until the engine is warm, the idle speed may be higher than normal. The control lever of the Digital electronic control can be operated even at high engine speeds. However, gear shifting will not work until the engine speed has automatically decreased to a speed at which actual gear shifting is possible. As a result, for quick gear shifting there could be a time lag when the gear is shifted until the engine speed has decreased sufficiently.


To shift out of neutral

- (1) Pull the neutral interlock trigger up (if equipped).
- (2) Move the control lever firmly and crisply forward (for forward gear) or backward (for reverse gear) 22.5° (a detent can be felt).




To shift from in gear (forward/reverse) to neutral

- (1) Close the throttle so that the engine slows to idle speed.



- (2) After the engine is at idle speed in gear, move the control lever firmly and crisply into the neutral position.

Operation




EMU48702

Neutral hold switch operation

To set

- (1) Place the control lever in “N” (neutral).
- (2) When the “NEUTRAL HOLD” switch is pressed, a beep will sound and the LED will come on.



1. “NEUTRAL HOLD” switch
2. LED

- (3) You can open or close the throttle. This can also be done when the control lever is set in reverse.

To release

- (1) Place the control lever in “N” (neutral).
- (2) When the “NEUTRAL HOLD” switch is pressed, a beep will sound and the LED will go off.
- (3) You can perform normal forward or reverse operation

EMU48711


Center engine switch operation

TIP:



- You cannot operate the starboard control lever when the single lever switch is activated.
- You must start all the engines to enable the center engine.

To set

- (1) Place the control lever in “N” (neutral).
- (2) When the “CENTER ENGINE” switch is pressed, a beep will sound and the LED will come on.



1. “CENTER ENGINE” switch (triple engines)
2. LED
- (3) You can operate the center engine by using the port side control lever.



1. Port side control lever
2. Center engine

To release

- (1) Place the control lever in “N” (neutral).
- (2) When the “CENTER ENGINE” switch is pressed, a beep will sound and the LED will go off.

EMU48720


Single lever switch operation

TIP:


- When the single lever switch is activated, the starboard control lever is inoperable. You must start all the engines to enable the single lever switch.

To set

- (1) Place the control lever in “N” (neutral).
- (2) When the “SINGLE LEVER” switch is pressed, a beep will sound and the LED will come on.



1. “SINGLE LEVER” switch
2. LED
- (3) The port side control lever will allow you to perform shift and throttle operations for all outboard motors that have been started.



1. Port side control lever
2. Port side engine
3. Center engine
4. Starboard side engine

To release

- (1) Place the control lever in “N” (neutral).
- (2) When the “SINGLE LEVER” switch is pressed, a beep will sound and the LED will go off.
- (3) You can perform normal shift or throttle operations.

Operation

EMU31743

Stopping boat

EWM01511



- **Do not use the reverse function to slow down or stop the boat as it could cause you to lose control, be ejected, or impact the steering wheel or other parts of the boat. This could increase the risk of serious injury. It could also damage the shift mechanism.**
 - **Do not shift into reverse while traveling at planing speeds. Loss of control, boat swamping, or damage to the boat could occur.**
-


The boat is not equipped with a separate braking system. Water resistance stops it after the throttle lever is moved back to idle. The stopping distance varies depending on gross weight, water surface conditions, and wind direction.

EMU48731

Boat direction

The illustrations below indicate the boat direction when operating multiple outboard motors.

Lever operation (Twin engines)



↕:Lever operation


↩:Boat direction and turning force

The size of the arrow is proportional to the turning force.

↔:Propulsion

Operation

Lever operation (Triple engines)



◀:Lever operation

↩:Boat direction and turning force

The size of the arrow is proportional to the turning force.

↔:Propulsion

EMU27823

Stopping engine

Before stopping the engine, first let it cool off for a few minutes at idle or low speed. Stopping the engine immediately after operating at high speed is not recommended.


EMU42196

Procedure for stopping engine (6X6 switch)


The engine can be turned off either by pressing the Start/Stop button or by turning the main switch to the "OFF" (off) position.

Situations when stopping engine from main station (dual-station models) or helm (single-station models)

- (1) Turn the main switch to "OFF" (off) or press the Start/Stop button until the engine stops completely.



1. Main switch



1. Start/Stop button


TIP:

The engine can also be stopped by pulling the cord and removing the clip from the engine shut-off switch, then turning the main switch to "OFF" (off).

- (2) If the Start/Stop button was pressed to stop the engine in step (1), turn the main switch to "OFF" (off).
- (3) Remove the key if the boat will be left unattended.

Situations when stopping engine from sub station (dual-station models)

- (1) Press the Start/Stop button until the engine stops completely.



1. Start/Stop button
- (2) Turn the main switch to "OFF" (off) on the main station.

TIP:

The engine can also be stopped by pulling the cord and removing the clip from the engine shut-off switch, then turning the main switch to "OFF" (off) on the main station.

- (3) Remove the key if the boat will be left unattended.

EMU27865

Trimming outboard motor

EWM00741




Excessive trim for the operating conditions (either trim up or trim down) can cause boat instability and can make steering

Operation

the boat more difficult. This increases the possibility of an accident. If the boat begins to feel unstable or is hard to steer, slow down and/or readjust the trim angle.

The trim angle of the outboard motor helps determine the position of the bow of the boat in the water. Correct trim angle will help improve performance and fuel economy while reducing strain on the engine. Correct trim angle depends upon the combination of boat, engine, and propeller. Correct trim is also affected by variables such as the load in the boat, sea conditions, and running speed.



1. Trim operating angle

EMUJ27889

Adjusting trim angle (Power trim and tilt)


EWM00754

WARNING



- Be sure all people are clear of the outboard motor when adjusting the trim angle. Body parts can be crushed between the motor and the clamp bracket when the motor is trimmed or tilted.
- Use caution when trying a trim position for the first time. Increase speed gradually and watch for any signs of instability or control problems. Improper trim angle can cause loss of control.

- If equipped with a power trim and tilt switch located on the bottom cowling, use the switch only when the boat is at a complete stop with the engine off. Do not adjust the trim angle with this switch while the boat is moving.

Adjust the outboard motor trim angle using the power trim and tilt switch.



1. Power trim and tilt switch



1. Power trim and tilt switch (all engines)
2. Power trim and tilt switch (individual engine)

To raise the bow (trim-out), press the switch “UP” (up).


To lower the bow (trim-in), press the switch “DN” (down).

Make test runs with the trim set to different angles to find the position that works best for your boat and operating conditions.

EMU27913

Adjusting boat trim


When the boat is on plane, a bow-up attitude results in less drag, greater stability and efficiency. This is generally when the keel line of the boat is up about 3 to 5 degrees. With the bow up, the boat may have a greater tendency to steer to one side or the other. Compensate for this as you steer. When the bow of the boat is down, it is easier to accelerate from a standing start onto plane.



ZMU01785

Bow Down


Too much trim-in causes the boat to “plow” through the water, decreasing fuel economy and making it hard to increase speed. Operating with excessive trim-in at higher speeds also makes the boat unstable. Resistance at the bow is greatly increased, heightening the danger of “bow steering” and making operation difficult and dangerous.



ZMU01784

Bow Up

Too much trim-out puts the bow of the boat too high in the water. Performance and economy are decreased because the hull of the boat is pushing the water and there is more air drag. Excessive trim-out can also cause the propeller to ventilate, which reduces performance further, and the boat may “porpoise” (hop in the water), which could throw the operator and passengers overboard.



ZMU01786

TIP:

Depending on the type of boat, the outboard motor trim angle may have little effect on the trim of the boat when operating.

EMU48401

Tilting up and down

If the engine will be stopped for some time or if the boat is moored in shallows, the outboard motor should be tilted up to protect the propeller and lower case from damage by collision with obstructions, and also to reduce salt corrosion.

Operation

EWM01544

WARNING

Make sure that all people are clear of the outboard motor when tilting the outboard motor up and down. Body parts can be crushed between the outboard motor and the clamp bracket when the outboard motor is trimmed or tilted.

ECM00993

NOTICE

- Before tilting the outboard motor, follow the procedure under “Stopping engine” in this chapter. Never tilt the outboard motor while the engine is running. Severe damage from overheating can result.
 - To prevent the cooling water passages from becoming frozen when the ambient temperature is 5°C (41°F) or below, tilt the outboard motor up after it has been stopped 30 seconds or more.
-


TIP:

When the PTT TotalTilt function is activated, you can tilt the outboard motor up/down automatically without keeping the PTT switch pressed. For further information, see page 65.


EMU3550C


Procedure for tilting up (power trim and tilt models)

- (1) Place the control lever in neutral.






- (2) Press the power trim and tilt switch “UP” (up) until the outboard motor has tilted up completely.






the motor cannot be trailed in the normal running position, use an additional support device to secure it in the tilt position. For more detailed information, see page 69. [ECM01642]



- (3) Set the tilt support lever to support the engine. **WARNING!** After tilting the outboard motor, be sure to support it with the tilt support knob or tilt support lever. Otherwise the outboard motor could fall back down suddenly if oil in the power trim and tilt unit or in the power tilt unit loses pressure. [EWM00263] **NOTICE:** Do not use the tilt support lever or knob when trailering the boat. The outboard motor could shake loose from the tilt support and fall. If

1. Tilt support lever
- (4) Once the outboard motor is supported with the tilt support lever, press the power trim and tilt switch “DN” (down) to retract the trim rods. **NOTICE:** Make sure that the trim rods retract completely during mooring. This protects the rods from marine growth and corrosion, which could damage the power trim and tilt mechanism. [ECM00254]

Operation






1. Trim rod


EMU42703

Procedure for tilting down


- (1) Push the power trim and tilt switch “UP” (up) until the outboard motor is supported by the tilt rod and the tilt support lever becomes free.
- (2) Release the tilt support lever.



1. Tilt support lever



- (3) Push the power trim and tilt switch “DN” (down) to lower the outboard motor to the desired position.



EMU48415

PTT TotalTilt™

This outboard motor is equipped with an automatic PTT tilt function. When this function is activated, you can tilt the outboard motor up/down automatically without keeping the PTT switch pushed.

TIP:

The PTT TotalTilt function is available only when the engine is stopped.

Activating and deactivating the PTT TotalTilt function


This function is deactivated by default. You can activate and deactivate it by yourself.

EWM01544

WARNING


Make sure that all people are clear of the outboard motor when tilting the outboard motor up and down. Body parts can be crushed between the outboard motor and the clamp bracket when the outboard motor is trimmed or tilted.

- (1) Make sure that all the battery switches are turned on before operation.
- (2) Fully tilt the outboard motor down.
- (3) Remove the clip from the engine shut-off switch.




1. Engine shut-off switch
2. Clip
3. Engine shut-off cord (lanyard)

- (4) Hold the “DN” (down) side of the PTT switch pushed.



- (5) Operate the trim zero set while keeping the “DN” (down) side of the PTT switch pushed.



TIP:

- For how to operate the trim zero set, see the owner's manual included with the gauge.
- When the PTT TotalTilt function is activated, the buzzer will sound once.
- When the PTT TotalTilt function is deactivated, the buzzer will sound twice.

Automatic tilt-up

EWM01544

WARNING

Make sure that all people are clear of the outboard motor when tilting the outboard motor up and down. Body parts can be

Operation

crushed between the outboard motor and the clamp bracket when the outboard motor is trimmed or tilted.

- (1) Make sure that the PTT TotalTilt function is activated.
- (2) Push the “UP” (up) side of the PTT switch twice quickly.

TIP:

- This operation causes the outboard motor to automatically tilt up to the fully tilted-up position and stop.
- If the tilt limiter is installed, the auto tilt up operation causes the outboard motor to automatically tilt up to the angle set by the tilt limiter and stop.
- The buzzer sounds before the automatic operation begins, and sounds intermittently during automatic tilting.
- Pushing the PTT switch briefly during the automatic operation, stops the operation.

Automatic tilt-down

EWM01544



Make sure that all people are clear of the outboard motor when tilting the outboard motor up and down. Body parts can be crushed between the outboard motor and the clamp bracket when the outboard motor is trimmed or tilted.

- (1) Make sure that the PTT TotalTilt function is activated.
- (2) Push the “DN” (down) side of the PTT switch twice quickly.

TIP:

- This function causes the outboard motor to automatically tilt down to the fully trimmed-out position and stop.
- The buzzer sounds before the automatic operation begins, and sounds intermittently during automatic tilting.

- Pushing the PTT switch briefly during the automatic operation, stops the operation.

If automatic tilting does not operate

In the following situations, the PTT TotalTilt function is deactivated and does not operate. If you suspect a malfunction, consult your Yamaha dealer.

- The PTT unit is stuck, or foreign matter is preventing the tilting operation.
- The buzzer is malfunctioning.
- The tilt sensor is malfunctioning.

EMU28063

Shallow water

EMU47840


Cruising in shallow water

The outboard motor can be tilted up partially to allow operation in shallow water.

ECM01491

NOTICE

- **If the engine speed is suddenly increased when the outboard motor is partially tilted up, the power trim and tilt unit could be damaged.**
- **Do not tilt the outboard motor up so that the cooling water inlet on the lower unit is above the surface of the water when setting up for and cruising in shallow water. Otherwise severe damage from overheating can result.**



1. Cooling water inlet


TIP:

When the outboard motor is partially tilted up for shallow water operation, the engine speed may be controlled around 2000 r/min. The engine speed is controlled to protect the power trim and tilt unit and does not indicate a malfunction. For instructions on de-activating the engine speed control system, see page 67.

EMU35238

Procedure for power trim and tilt models

- (1) Place the control lever in neutral.



- (2) Slightly tilt the outboard motor up to the desired position using the power trim and tilt switch. **WARNING! Using the power trim and tilt switch on the bottom cowling while the boat is moving or engine is on could increase the risk of falling overboard and could distract the operator, increasing the risk of collision with another boat or an obstacle.** [EWM01851]
- (3) To return the outboard motor to the normal running position, press the power trim and tilt switch and slowly tilt the outboard motor down.

EMU47850


De-activating the engine speed control system

ECM02501

NOTICE

This procedure must be done out of the shallow water. Otherwise, the outboard motor may hit an object in the water as tilting down.

- (1) Close the throttle so that the engine slows to idle speed.
- (2) After the engine is at idle speed in gear, move the control lever firmly and crisply into the neutral position.



TIP:

If the engine speed is increased to 3000 r/min or more, this control system will also be deactivated.

- (3) Press the power trim and tilt switch and fully tilt the outboard motor down.

EMU41371

Operating in other conditions

Operating in salt water

After operating in saltwater, brackish water, or water high in other minerals, flush the cooling system with fresh water to minimize corrosion and clogging of the cooling water passages with deposits. Also, rinse the exterior of the outboard motor with fresh water.

Operation

Operating in water containing mud, sand, silt, debris, or vegetation

Mud, sand, silt, debris, and vegetation in the water may restrict water flow into the cooling water inlet covers or clog internal water passages. Check and clean the cooling water inlet covers frequently when operating in these conditions. Flush the engine with clean, fresh water after use in these environments. Consult your dealer if normal water flow can not be restored by cleaning the cooling water inlet covers or flushing with fresh water.

EMU31845

Transporting and storing outboard motor

EWM02641

WARNING

- **USE CARE** when transporting fuel tank, whether in a boat or car.
- **DO NOT** fill fuel container to maximum capacity. Gasoline will expand considerably as it warms up and can build up pressure in the fuel container. This can cause fuel leakage and a potential fire hazard.
- **Leaking fuel is a fire hazard.** Tighten securely the fuel valve when transporting and storing the outboard motor.
- **Never get under the outboard motor while it is tilted.** Severe injury could occur if the outboard motor accidentally falls.
- **Do not use the tilt support lever or knob when trailering the boat.** The outboard motor could shake loose from the tilt support and fall. If the outboard motor cannot be trailered in the normal running position, use an additional support device to secure it in the tilt position.

ECM02441

NOTICE

When storing the outboard motor for prolonged time, fuel must be drained from the fuel tank. The deteriorated fuel could clog the fuel line causing engine start difficulty or malfunction.

Leaking fuel is a fire hazard. When trailering the boat, close the fuel valve to prevent fuel from leaking.

The outboard motor should be transported and stored in the normal running position. If there is insufficient road clearance in this po-

sition, then trailer the outboard motor in the tilt position using a motor support device such as a transom saver bar. Consult your Yamaha dealer for further details.

When the outboard motor is tilted prolonged time for mooring or trailering the boat, close the fuel valve.

EMU35581

Storing outboard motor


When storing your Yamaha outboard motor for prolonged periods of time (2 months or longer), several important procedures must be performed to prevent excessive damage. It is advisable to have your outboard motor serviced by an authorized Yamaha dealer prior to storage. However, you, the owner, with a minimum of tools, can perform the following procedures.

ECM01721

NOTICE

Store the outboard motor in a dry, well-ventilated place, not in direct sunlight.

Keep the outboard motor in the attitude shown when transporting and storing it.



EMU47800

Lubrication

- (1) Change the gear oil and check the gear oil for the presence of water that indicates a leaky seal. For details, consult your Yamaha dealer.

Maintenance

- (2) Lubricate all grease fittings. For details, see page 77.

TIP:

For long-term storage, fogging the engine with fogging oil is recommended. Contact your Yamaha dealer for information about fogging oil and procedures for your outboard motor.

EMU49250

Flushing cooling water passage


Perform this procedure right after operation for the most thorough flushing.

ECM01531


NOTICE

Do not perform this procedure while the engine is running. The water pump may be damaged and severe damage from overheating can result.

- (1) Remove the garden hose connector cap on the bottom cowling.



1. Garden hose connector cap
- (2) Connect the garden hose to the garden hose connector.



1. Garden hose
 2. Garden hose adapter (commercially available)
 3. Garden hose connector
- (3) With the engine off, turn on the water supply and let the water flush through the cooling water passages for about 15 minutes.
 - (4) Turn off the water supply, and then disconnect the garden hose from the garden hose connector.
 - (5) Install the garden hose connector cap on the bottom cowling securely. **NOTICE: If the garden hose connector cap is not properly installed, cooling water can leak out and the engine can overheat during operation.** [ECM05750]

TIP:

When flushing the cooling water passages with the boat in the water, tilting the outboard motor up until it is completely out of the water will achieve better results.


- (6) To prevent water from freezing in the cooling water passages, tilt the outboard motor down and wait at least 3 minutes or disconnect the garden hose connector to drain the water.

EMU44342

Cleaning the outboard motor

When cleaning the outboard motor, the top cowling must be installed.

- (1) Wash the exterior of the outboard motor using fresh water. **NOTICE: Do not spray water into the air intake.** [ECM01841]



1. Air intake
- (2) Drain the cooling water completely out of the outboard motor. Clean the body thoroughly.

EMU28463

Checking painted surface of outboard motor

Check the outboard motor for scratches, nicks, or flaking paint. Areas with damaged paint are more likely to corrode. If necessary, clean and paint the areas. Touch-up paint is available from your Yamaha dealer.

EMU2850F

Periodic maintenance

EWM01872



These procedures require mechanical skills, tools, and supplies. If you do not have the proper skills, tools, or supplies to perform a maintenance procedure, have a Yamaha dealer or other qualified mechanic do the work.

The procedures involve disassembling the motor and exposing dangerous parts. To reduce the risk of injury from moving, hot, or electrical parts:

- Turn off the engine and keep the key(s) and engine shut-off cord (lanyard) with you when you perform maintenance unless otherwise specified.
- The power trim and tilt switches operate even when the ignition key is off. Keep people away from the switches whenever working around the motor. When the motor is tilted, keep away from the area under it or between it and the clamp bracket. Be sure no one is in this area before operating the power trim and tilt mechanism.
- Allow the engine to cool before handling hot parts or fluids.
- Always completely reassemble the motor before operation.

Maintenance, replacement, or repair of the emission control devices and systems on models affixed with an emission control label may be performed by any marine engine repair establishment or individual. All warranty repairs, however, including those to the emission control system, must be performed by an authorized Yamaha marine dealership.

EMU28512

Replacement parts

If replacement parts are necessary, use only genuine Yamaha parts or parts of equivalent design and quality. Any part of inferior quality may malfunction, and the resulting loss of control could endanger the operator and passengers. Yamaha genuine parts and accessories are available from your Yamaha dealer.

Maintenance

EMU34152

Severe operating conditions

Severe operating conditions involve one or more of the following types of operation on a regular basis:

- Operating continuously at or near maximum engine speed (rpm) for many hours
- Operating continuously at a low engine speed (rpm) for many hours
- Operating without sufficient time for engine to warm up and cool down
- Frequent quick acceleration and deceleration
- Frequent shifting
- Frequently starting and stopping the engine(s)
- Operation that fluctuates often between light and heavy cargo loads

Outboard motors operating under any of these above conditions require more frequent maintenance. Yamaha recommends that you do this service twice as often as specified in the maintenance chart. For example, if a particular service should be done at 50 hours, do it instead at 25 hours. This will help prevent more rapid deterioration of engine components.

EMU46073

Maintenance chart 1

TIP:

- Refer to the sections in this chapter for explanations of each owner-specific action.
- The maintenance cycle on these charts assume usage of 100 hours per year and regular flushing of the cooling water passages. Maintenance frequency should be adjusted when operating the engine under adverse conditions such as extended trolling.
- Disassembly or repairs may be necessary depending on the outcome of maintenance checks.
- Expendable or consumable parts and lubricants will lose their effectiveness over time and through normal usage regardless of the warranty period.
- When operating in salt water, muddy, other turbid (cloudy), acidic water, the engine should be flushed with clean water after each use.

The “●” symbol indicates the check-ups which you may carry out yourself.

The “○” symbol indicates work to be carried out by your Yamaha dealer.

Item	Actions	Initial	Every			Page
		20 hours (3 months)	100 hours (1 year)	300 hours (3 years)	500 hours (5 years)	
Anode(s) (external)	Inspection or replacement as necessary		●/○			83
Battery (electrolyte level, terminal)	Inspection	●/○	●/○			84
Battery (electrolyte level, terminal)	Fill, charging or replacing as necessary		○			—
Cooling water leakage	Inspection or replacement as necessary	○	○			—
Cowling lock lever	Inspection		●/○			41, 44
Engine starting condition/noise	Inspection	●/○	●/○			47
Engine idle speed/noise	Inspection	●/○	●/○			79
Engine oil	Replacement	○	○			—
Engine oil filter (cartridge)	Replacement		○			—
Fuel filter (can be disassembled)	Inspection or replacement as necessary	●/○	●/○			42
Fuel line (DI pressure)	Inspection	●				—

Maintenance

Item	Actions	Initial	Every			Page
		20 hours (3 months)	100 hours (1 year)	300 hours (3 years)	500 hours (5 years)	
Fuel line (DI pressure)	Inspection or replacement as necessary	○				—
Fuel line (High pressure)	Inspection	●	●			—
Fuel line (High pressure)	Inspection or replacement as necessary	○	○			—
Fuel line (Low pressure)	Inspection	●	●			—
Fuel line (Low pressure)	Inspection or replacement as necessary	○	○			—
Fuel pump	Inspection or replacement as necessary			○		—
Fuel/engine oil leakage	Inspection	○	○			—
Gear oil	Replacement	●/○	●/○			81
Greasing points	Greasing	●/○	●/○			77
Impeller/water pump housing	Inspection or replacement as necessary		○			—
Impeller/water pump housing	Replacement			○		—
OCV (Oil Control Valve) filter	Replacement				○	—
Power trim and tilt unit	Inspection	●/○	●/○			45
Propeller/propeller nut/cotter pin	Inspection or replacement as necessary	●/○	●/○			80
PCV (Pressure Control Valve)	Inspection or replacement as necessary		○			—
Spark plug(s)	Inspection or replacement as necessary		○			—
Water from the cooling water pilot hole	Inspection	●/○	●/○			52

Maintenance

Item	Actions	Initial	Every			Page
		20 hours (3 months)	100 hours (1 year)	300 hours (3 years)	500 hours (5 years)	
Thermostat	Inspection or replacement as necessary		○			—
Timing belt	Inspection or replacement as necessary		○			—
Cooling water inlet	Inspection	●/○	●/○			17
Main switch/stop switch	Inspection or replacement as necessary	○	○			—
Wire harness connections/wire coupler connections	Inspection or replacement as necessary	○	○			—
(Yamaha) Meter/gauge	Inspection	○	○			—
SBW (Steer-by-wire)	Inspection or replacement as necessary	○	○	○	○	—

EMU46082

Maintenance chart 2

Item	Actions	Every	Page
		1000 hours	
Exhaust guide/exhaust manifold	Inspection or replacement as necessary	○	—
Timing belt	Replacement	○	—
Cam chain	Inspection or replacement as necessary	○	—
Cam chain tensioner	Inspection or replacement as necessary	○	—
Valve clearance	Inspection and adjustment	○	—
Fuel strainer	Inspection or replacement as necessary	○	—
Fuel line (DI pressure)	Inspection	●	—
Fuel line (DI pressure)	Inspection or replacement as necessary	○	—

Maintenance

Item	Actions	Every	Page
		1000 hours	
Anode(s) (internal) *1	Inspection or replacement as necessary	○	—
Anode(s) (Under the timing belt)	Inspection or replacement as necessary	○	—
SBW (Steer-by-wire)	Inspection or replacement as necessary	○	—


EMU47550






*1 cylinder head, cylinder block, oil cooler, cooling water passage, exhaust joint

EMU46621






Greasing

Yamalube grease A “” (water resistant grease)

Yamaha grease D “” (corrosion resistant grease)



Maintenance



EMU47591

Inspecting spark plug

The spark plug is an important engine component. The spark plug must be checked every 100 hours. For details, consult your Yamaha dealer.

Standard spark plug:
ILMAR7H-9

EMU41872

Inspecting engine idle speed

ECM01691

NOTICE

This procedure must be performed while the outboard motor is in the water.

Inspect the engine idle speed using the meter that is equipped on the boat. Results may vary depending on whether testing is conducted with the outboard motor in the water.

- (1) Start the engine and allow it to warm up fully in neutral until it is running smoothly.
- (2) Inspect the engine idle speed. If the engine idle speed is out of specification, consult a Yamaha dealer or other qualified mechanic.

Idle speed (in neutral):
650–750 r/min

EMU47601

Changing engine oil

The engine oil must be changed every 100 hours. For details, consult your Yamaha dealer.

Recommended engine oil:

YAMALUBE 4 or 4-stroke outboard motor oil

Engine oil quantity (without oil filter replacement):

7.5 L (7.93 US qt, 6.60 Imp.qt)

Engine oil quantity (with oil filter replacement):

7.8 L (8.24 US qt, 6.86 Imp.qt)

EMU48060

Why Yamalube

YAMALUBE oil is a Genuine YAMAHA Part born of the engineers' passion and belief that engine oil is an important liquid engine component. We form teams of specialists in the fields of mechanical engineering, chemistry, electronics and track testing, and have them develop the engine together with the oil it will use. Yamalube oils take full advantage of the base oil's qualities and blend in the ideal balance of additives to make sure the final oil clears our performance standards. Thus, Yamalube mineral, semisynthetic and synthetic oils have their own distinct characters and value. Yamaha's experience gained over many years of research and development into oil since the 1960's helps make Yamalube the best choice for your Yamaha engine.




EMU29116

Inspecting wiring and connectors

- Inspect that each connector is engaged securely.
- Inspect that each ground lead is properly secured.

Maintenance



EMU41671


Inspecting propeller

EWM02681



You could be seriously injured if the engine accidentally starts when you are near the propeller. Before inspecting, removing, or installing the propeller, move the control lever to the neutral position, turn the main switch to the “OFF” (off) position, remove the key, and remove the clip from the engine shut-off switch. Turn off the battery cut-off switch if your boat has one.


Do not use your hand to hold the propeller when loosening or tightening the propeller nut. Place a block of wood between the anti-cavitation plate and the propeller to prevent the propeller from turning.



ZMU06953

Checkpoints

- Check each of the propeller blades for erosion from cavitation or ventilation, and other damage.
- Check the propeller shaft for damage.
- Check the splines for wear and damage.
- Check for fish line tangled around the propeller shaft.




1. Propeller shaft

EMU41992

Removing propeller

- (1) Straighten the cotter pin and pull it out using a pair of pliers.
- (2) Remove the propeller nut, washer, and spacer. **WARNING! Do not use your hand to hold the propeller when loosening the propeller nut.** [EWM01891]



1. Cotter pin
2. Propeller nut
3. Washer
4. Spacer
5. Propeller
6. Thrust washer

- (3) Remove the propeller and thrust washer.

EMU41963

Installing propeller

EWM00771

WARNING


On counter rotation models, be sure to use a propeller intended for counterclockwise rotation. These propellers are identified with the letter “L” after the size indication on the propeller. Otherwise the boat could move in the opposite direction from that expected.

ECM00502

NOTICE

Make sure to use a new cotter pin and bend the ends over securely. Otherwise, the propeller could come off during operation and be lost.

- (1) Apply Yamalube Marine Grease to the propeller shaft.
- (2) Install the thrust washer and propeller on the propeller shaft. **NOTICE: Make sure to install the thrust washer before installing the propeller. Otherwise, the lower case and propeller boss could be damaged.** [ECM01882]
- (3) Install the spacer, washer, and propeller nut. Tighten the propeller nut to the specified torque.




1. Thrust washer

2. Propeller
3. Spacer
4. Washer
5. Propeller nut
6. Cotter pin

Propeller nut tightening torque:
80 N·m (8.0 kgf·m, 59 lb·ft)

- (4) Align the propeller nut slot with the propeller shaft hole. Insert a new cotter pin in the hole and bend the cotter pin ends. **NOTICE: Do not reuse the cotter pin. Otherwise, the propeller can come off during operation.** [ECM01892]



ZMU06956

TIP:

If the propeller nut slot does not align with the propeller shaft hole after tightening the propeller nut to the specified torque, tighten the nut further to align the slot with the hole.

EMU47941

Changing gear oil

EWM02531

WARNING


- Make sure that the outboard motor is mounted securely to the transom or a stable stand. You could be severely injured if the outboard motor falls on you.

Maintenance

- **Never get under the lower unit while it is tilted. Severe injury could occur if the outboard motor accidentally falls.**


Before filling the lower unit with gear oil, the outboard motor must be placed in a vertical position. If you are not able to place the outboard motor in a vertical position, have a Yamaha dealer change the gear oil.

- (1) Tilt the outboard motor so that the gear oil drain bolt is at the lowest point possible.
- (2) Place a suitable container under the lower unit.
- (3) Loosen the bolts, and then remove the cooling water inlet covers on both sides of the lower unit.



1. Bolt
2. Cooling water inlet cover

- (4) Remove the gear oil drain bolt and O-ring.




1. Gear oil drain bolt

2. O-ring

- (5) Remove the oil level plug and O-ring to allow the gear oil to drain completely. **NOTICE: Check the used gear oil after it has been drained. If the gear oil is milky or contains water or a large amount of metal particles, the gear case may be damaged. Have a Yamaha dealer check and repair the outboard motor.** [ECM00714]

TIP:

For disposal of used gear oil, consult your Yamaha dealer.



1. Oil level plug
2. O-ring

- (6) Remove any metal particles on the magnetic gear oil drain bolt. **NOTICE: If there is an excessive quantity of metal particles on the magnetic gear oil drain screw, this can indicate lower unit problem. Consult your Yamaha dealer.**

[ECM01901]

- (7) Put a new O-ring on the gear oil drain bolt. Insert and tighten the gear oil drain bolt to the specified torque.


TIP:

Apply a light coat of gear oil to the gear oil drain bolt thread and O-ring before installation.

Tightening torque:

2.5 N·m (0.25 kgf·m, 1.8 lb·ft)

- (8) Remove the oil filler bolt and O-ring.



1. Oil filler bolt
2. O-ring

- (9) Place the outboard motor in a vertical position. Using a flexible or pressurized filling device, inject the gear oil into the oil filler bolt hole.

Recommended gear oil:


YAMALUBE outboard gear oil or Hypoid gear oil

Recommended gear oil grade:

SAE 80W API GL-5 / SAE 90 API GL-5

Gear oil quantity:

1.830 L (1.934 US qt, 1.610 Imp.qt)
(FL400ASTU, FL400ASTX,
FL450AVTU, FL450AVTX)
1.950 L (2.061 US qt, 1.716 Imp.qt)
(F400ASTU, F400ASTX, F450AVTU,
F450AVTX)



- (10) Put a new O-ring on the oil level plug. When the gear oil begins to flow out of the oil level plug hole, insert and tighten the oil level plug to the specified torque.

TIP:

Apply a light coat of gear oil to the oil level plug thread and O-ring before installation.

Tightening torque:

2.5 N·m (0.25 kgf·m, 1.8 lb·ft)

- (11) Put a new O-ring on the oil filler bolt. Insert and tighten the oil filler bolt to the specified torque.

TIP:

Apply a light coat of gear oil to the oil filler bolt thread and O-ring before installation.

Tightening torque:

2.5 N·m (0.25 kgf·m, 1.8 lb·ft)

- (12) Install the cooling water inlet covers on both sides of the lower unit, and then tighten the bolts to the specified torque.

Tightening torque:

2.5 N·m (0.25 kgf·m, 1.8 lb·ft)

EMU29318

Inspecting and replacing anode(s)

Yamaha outboard motors are protected from corrosion by sacrificial anodes. Inspect the external anodes periodically. Remove scales


Maintenance

from the surfaces of the anodes. Consult a Yamaha dealer for replacement of external anodes.

ECM00721

NOTICE

Do not paint anodes, as this would render them ineffective.



1. Anode

TIP:

Inspect ground leads attached to external anodes on equipped models. Consult a Yamaha dealer for inspection and replacement of internal anodes attached to the power unit.

EMU29324

Checking battery (for electric start models)

EWM01903

WARNING

Battery electrolyte is poisonous and caustic, and batteries generate explosive hydrogen gas. When working near the battery:

- Wear protective eye gear and rubber gloves.
- Do not smoke or bring any other source of ignition near the battery.


The procedure for checking the battery varies for different batteries. This procedure contains typical checks that apply to many batteries, but you should always refer to the battery manufacturer's instructions.

ECM01921

NOTICE

A poorly maintained battery will quickly deteriorate.

- (1) Check the electrolyte level.



ZMU01810

- (2) Check the battery's charge. If your boat is equipped with the digital speedometer, the voltmeter and low battery alert functions will help you monitor the battery's charge. If the battery needs charging, consult your Yamaha dealer.
- (3) Check the battery connections. They should be clean, secure, and covered by an insulating cover. **WARNING! Bad connections can produce shorting or arcing and cause an explosion.** [EWM01913]

EMU35608

Connecting the battery

EWM00573

WARNING


Mount the battery holder securely in a dry, well-ventilated, vibration-free location in the boat. Install a fully charged battery in the holder.

ECM01125

NOTICE

Do not reverse the battery cables. Otherwise, the electrical parts could be damaged.

- (1) Make sure the main switch (on applicable models) is "OFF" (off) before working on the battery.
- (2) Connect the red battery cable to the POSITIVE (+) terminal first. Then connect the black battery cable to the NEGATIVE (-) terminal.




ZMU01811

1. Red cable
 2. Black cable
 3. Battery
- (3) The electrical contacts of the battery and cables must be clean and properly connected, or the battery will not start the engine.

Connecting an accessory battery (optional)

If connecting an accessory battery, consult your Yamaha dealer about correct wiring. It is recommendable to install the fuse to the isolator lead as shown in the illustration. For the fuse size, be sure to follow local regulations. For example, for USA, the ABYC rules (E-11) should be observed.


Single engine



1. Isolator lead with circuit protection
2. Red cable
3. Black cable
4. Fuse
5. Battery for accessories
6. Battery for starting
7. Negative connecting cable


Maintenance

Twin engines



1. Starboard side engine
2. Port side engine
3. Red cable
4. Black cable
5. Isolator leads with circuit protection
6. Fuse
7. Battery for starting
8. Battery for accessories
9. Negative connecting cable

Triple engines



1. Starboard side engine
2. Center engine
3. Port side engine
4. Red cable
5. Black cable
6. Isolator leads with circuit protection
7. Fuse
8. Battery for starting
9. Battery for accessories
10. Negative connecting cable

EMU29372

Disconnecting the battery

- (1) Turn off the battery cut-off switch (if equipped) and main switch. **NOTICE: If they are left on, the electrical system can be damaged.** [ECM01931]
- (2) Disconnect the negative cable(s) from the negative (-) terminal. **NOTICE: Always disconnect all negative (-) cables first to avoid a short circuit and damage to the electrical system.** [ECM01941]

- (3) Disconnect the positive cable(s) and remove the battery from the boat.
- (4) Clean, maintain, and store the battery according to the manufacturer's instructions.

Trouble Recovery

EMU48434

Troubleshooting

This section describes the likely causes and remedies for problems, such as those in the fuel, compression, and ignition systems, poor starting, and loss of power. Please note that all of the items in this section may not apply to your model.

If your outboard motor requires repair, bring it to a Yamaha dealer.

If the engine trouble-alert indicator is blinking, consult your Yamaha dealer.

Trouble	Starter will not operate.	
Item	Question	Answer
DEC alert indicator	Does the DEC alert indicator come on in orange?	Have serviced by a Yamaha dealer.
Control lever	Is control lever in gear?	Shift to neutral.
Battery	Is battery capacity low or weak?	Check battery condition. Use battery of recommended capacity.
	Are battery connections corroded or loose?	Tighten battery cables and clean battery terminals.
Fuse	Is fuse for starter relay or electric circuit blown?	Check for cause of electric overload and repair. Replace fuse with one of correct amperage.
Starter	Are starter components malfunctioning?	Have serviced by a Yamaha dealer.

Trouble	Engine will not start (starter operates).	
Item	Question	Answer
Engine shut-off cord (lanyard)	Is clip on engine shut-off cord (lanyard) installed?	Install clip to engine shut-off switch.
Fuel tank	Is fuel tank empty?	Fill tank with clean, fresh fuel.
Fuel	Is fuel contaminated or stale?	Fill tank with clean, fresh fuel.
Fuel filter	Is fuel filter clogged?	Clean or replace fuel filter.
Fuel pump	Is fuel pump malfunctioning?	Have serviced by a Yamaha dealer.
Spark plugs	Are spark plugs fouled or of incorrect type?	Inspect spark plugs. Clean or replace with recommended type.
Ignition parts	Are ignition parts malfunctioning?	Have serviced by a Yamaha dealer.
Ignition wiring	Is ignition wiring damaged or poorly connected?	Inspect wires for breaks and wear. Have connections tightened and broken or worn wires replaced by a Yamaha dealer.
Engine inner parts	Are engine inner parts damaged?	Have serviced by a Yamaha dealer.

Trouble Recovery

Trouble	Engine idles irregularly or stalls.	
Item	Question	Answer
Spark plugs	Are spark plugs fouled or of incorrect type?	Inspect spark plugs. Clean or replace with recommended type.
	Is spark plug gap incorrect?	Replace spark plug.
Fuel system	Is fuel system clogged?	Inspect for pinched or kinked fuel line or other obstructions in fuel system.
Fuel	Is fuel contaminated or stale?	Fill tank with clean, fresh fuel.
Fuel filter	Is fuel filter clogged?	Clean or replace fuel filter.
Ignition parts	Are ignition parts malfunctioning?	Have serviced by a Yamaha dealer.
Alert system	Has alert system activated?	Find and correct cause of alert.
Ignition wiring	Is ignition wiring damaged or poorly connected?	Inspect wires for breaks and wear. Have connections tightened and broken or worn wires replaced by a Yamaha dealer.
Engine oil	Is specified engine oil not being used?	Inspect engine oil and replace with specified type.
Thermostat	Is thermostat clogged or malfunctioning?	Have serviced by a Yamaha dealer.
Fuel pump	Is fuel pump malfunctioning?	Have serviced by a Yamaha dealer.
Fuel tank	Is fuel tank air vent restricted or clogged?	Remove obstruction.
Fuel joint	Is fuel joint connection incorrect?	Connect correctly.
Battery	Is battery cable disconnected?	Connect securely.

Trouble	Alert buzzer sounds or indicator lights.	
Item	Question	Answer
Cooling system	Is cooling system clogged?	Inspect cooling water inlet for obstructions.
Low oil pressure-alert	Is low oil pressure-alert indicator on or blinking?	Have serviced by a Yamaha dealer.
Spark plugs	Is heat range of spark plugs incorrect?	Inspect spark plugs and replace with recommended type.
Engine oil	Is specified engine oil not being used?	Inspect engine oil and replace with specified type.
	Is engine oil contaminated or deteriorated?	Replace engine oil with specified type.
Oil filter	Is oil filter clogged?	Have serviced by a Yamaha dealer.
Oil pump	Is oil pump malfunctioning?	Have serviced by a Yamaha dealer.
Thermostat	Is thermostat malfunctioning?	Have serviced by a Yamaha dealer.
Water pump	Is water pump malfunctioning?	Have serviced by a Yamaha dealer.
Fuel filter	Is there excess water in fuel filter?	Drain fuel filter.

Trouble Recovery

Trouble	Engine power loss.	
Item	Question	Answer
Propeller	Is propeller damaged?	Have propeller repaired or replaced.
	Is propeller pitch or diameter incorrect?	Install correct propeller to operate outboard motor at its recommended speed (r/min) range.
Mounting height	Is outboard motor mounted at incorrect height on transom?	Have outboard motor adjusted to proper transom height.
Alert system	Has alert system activated?	Find and correct cause of alert.
Boat bottom	Is boat bottom fouled with marine growth?	Clean boat bottom.
Spark plugs	Are spark plugs fouled or of incorrect type?	Inspect spark plugs. Clean or replace with recommended type.
	Is spark plug gap incorrect?	Replace spark plug.
	Is heat range of spark plugs incorrect?	Inspect spark plugs and replace with recommended type.
Lower unit	Are weeds or other foreign material tangled on gear housing?	Remove foreign material and clean lower unit.
Fuel system	Is fuel system clogged?	Inspect for pinched or kinked fuel line or other obstructions in fuel system.
Fuel filter	Is fuel filter clogged?	Clean or replace fuel filter.
Fuel	Is fuel contaminated or stale?	Fill tank with clean, fresh fuel.
	Is specified fuel not being used?	Replace fuel with specified type.
Ignition wiring	Is ignition wiring damaged or poorly connected?	Inspect wires for breaks and wear. Have connections tightened and broken or worn wires replaced by a Yamaha dealer.
Electrical parts	Are electrical parts malfunctioning?	Have serviced by a Yamaha dealer.
Engine oil	Is specified engine oil not being used?	Replace engine oil with specified type.
Thermostat	Is thermostat clogged or malfunctioning?	Have serviced by a Yamaha dealer.
Fuel tank	Is fuel tank air vent restricted or clogged?	Remove obstruction.
Fuel pump	Is fuel pump malfunctioning?	Have serviced by a Yamaha dealer.
Fuel joint	Is fuel joint connection incorrect?	Connect correctly.
Control lever	Is engine not responding properly to control lever position?	Have serviced by a Yamaha dealer.

Trouble	Engine vibrates excessively.	
Item	Question	Answer
Propeller	Is propeller damaged?	Have propeller repaired or replaced.
	Are weeds or other foreign material tangled on propeller?	Remove and clean propeller.

Trouble	Engine vibrates excessively.	
Item	Question	Answer
Propeller shaft	Is propeller shaft damaged?	Have serviced by a Yamaha dealer.
Outboard motor mounting	Are outboard motor mounting bolts loose?	Tighten bolts or have serviced by a Yamaha dealer.
Steering pivot	Is steering pivot loose or damaged?	Have serviced by a Yamaha dealer.

Trouble	The PTT TotalTilt function will not operate.	
Item	Question	Answer
PTT TotalTilt function	Is the function deactivated?	Activate it.
PTT unit	Is the PTT unit stuck?	Clean the area around the PTT unit.
Buzzer	Is the buzzer malfunctioning?	Have serviced by a Yamaha dealer.
Tilt sensor	Is the tilt sensor malfunctioning?	Have serviced by a Yamaha dealer.

EMU29435

Temporary action in emergency

EMU29442

Impact damage

EWM00871



The outboard motor can be seriously damaged by a collision while operating or trailering. Damage could make the outboard motor unsafe to operate.

If the outboard motor hits an object in the water, follow the procedure below.



- (1) Stop the engine immediately.

- (2) Check the control system and all components for damage. Also, check the boat for damage.
- (3) Whether damage is found or not, return to the nearest harbor slowly and carefully.
- (4) Have a Yamaha dealer check the outboard motor before operating it again.

EMU35791

Running in an emergency (twin engines or triple engines)

Normally use all outboard motors together for cruising. When using only one or two engines in an emergency, be sure to keep the unused engine(s) tilted up and operate the other engine(s) at low speed.

ECM01731


NOTICE

If the boat is operated with only one or two engines, be sure to tilt the unused engine(s) up. Otherwise water could enter the exhaust pipe due to the wave action, causing engine trouble.

Trouble Recovery

TIP:

When maneuvering at low speed, such as near a dock, it is recommended to tilt the unused engine(s) down and to operate the unused engine(s) in neutral gear if possible.



EMU47621

Replacing fuse


EWM00632



WARNING


Substituting an incorrect fuse or a piece of wire could allow excessive current flow. This could cause electric system damage and a fire hazard.

The location of the fuse box for this model is shown in the following illustration.




1. Fuse box

This model is equipped with the following fuses.



1. RC-ECU fuse (10 A)
2. Main switch / PTT switch fuse (20 A)
3. ETV fuse (10 A)
4. Fuel pump 2 fuse (15 A)
5. Fuel pump 1 fuse (15 A)
6. Fuel pump fuse (30 A)
7. Shift actuator fuse (15 A)
8. Starter relay fuse (30 A)
9. DI system 2 fuse (20 A)
10. DI system 1 fuse (20 A)
11. Engine ECU / Ignition coil fuse (30 A)
12. Fuel feed pump fuse (10 A)
13. Isolator 1 fuse (70 A)
14. Isolator 2 fuse (70 A)
15. Engine main 1 fuse (70 A)
16. Engine main 2 fuse (70 A)
17. Power STRG fuse (100 A)



1. Fuse box cover
2. Spare fuse (10 A, 15 A, 20 A, 30 A, 70 A, 100 A)
3. Fuse puller

TIP:


- RC: Remote control

Trouble Recovery

- ETV: Electric throttle valve
- DI: Direct injection
- ECU: Engine control unit
- STRG: Steering
- PTT: Power trim and tilt


If a fuse has blown, replace the fuse according to the following procedure.

- (1) Turn the main switch to the "OFF" (off) position.
- (2) Remove the fuse box cover.
- (3) If the fuse is secured using screws, remove the screws, and then remove the fuse. Install a spare fuse of the proper amperage, and then tighten the screws.



1. Screw
2. Fuse

- (4) If the fuse is not secured using screws, remove the fuse using the fuse puller. Install a spare fuse of the proper amperage.



1. Fuse puller

Consult your Yamaha dealer if the new fuse immediately blows again.

EMU29529

Power trim and tilt will not operate

EWM02331




WARNING

Never get under the engine while it is tilted. Severe injury could occur if the outboard motor accidentally falls.

If the outboard motor cannot be tilted up/down using the power trim and tilt unit, e.g. because of a discharged battery or a failure with the unit itself, the outboard motor can be tilted manually.

- (1) Stop the engine.
- (2) Loosen the manual valve screw by turning it counterclockwise until it stops.



1. Manual valve screw

- (3) Adjust the outboard motor to a navigable angle, tighten the manual valve screw clockwise, and secure the outboard motor.

EMU47560


Steer-by-wire system will not operate

If the steer-by-wire system does not operate, the outboard motor can be steered manually.

To steer the outboard motor manually


- (1) Remove the clamp bracket cover by removing the bolts.

Trouble Recovery




1. Bolt
2. Clamp bracket cover

(2) Loosen the nut until it stops.



1. Nut

(3) To steer the outboard motor to the port side, turn the lever counterclockwise. To steer the outboard motor to the starboard side, turn the lever clockwise.



1. Lever

EMU47611

Water separator-alert is activated after leaving port

EWM01501

WARNING

Gasoline is highly flammable, and its vapors are flammable and explosive.



- Do not perform this procedure on a hot or running engine. Allow the engine to cool.
- There will be fuel in the fuel filter. Keep away from sparks, cigarettes, flames or other sources of ignition.
- This procedure will allow some fuel to spill. Catch fuel in a rag. Wipe up any spilled fuel immediately.
- The fuel filter must be reassembled carefully with the O-ring, filter cup, and hoses in place. Improper assembly or replacement could result in a fuel leak, which could result in a fire or explosion hazard.

If the water separator-alert indicator blinks or the buzzer sounds intermittently, perform the following procedure.

Trouble Recovery


TIP:

The buzzer sounds only when the control lever is placed in neutral.




To check for water in separator

- (1) Stop the engine.
- (2) Remove the top cowling.
- (3) Remove the fuel filter housing from its holder.



1. Fuel filter

- (4) Remove the fuel filter cap, and then remove the fuel filter element and O-ring from the filter cup.



1. Fuel filter cap
2. Filter element
3. O-ring
- (5) Drain the water in the filter cup by soaking it up with a rag.
- (6) Put the O-ring on the filter cup in its original position, and then install the fuel filter element and fuel filter cap.
- (7) Install the fuel filter housing onto its holder.
- (8) Install the top cowling.
- (9) Turn the main switch to the "ON" (on) position and check that the water separator-alert indicator remains off and the buzzer does not sound. If the water separator-alert indicator blinks or the buzzer sounds, have your Yamaha dealer check the outboard motor. **NOTICE: Although the buzzer will stop when the engine is started and the remote control lever is moved to the forward or reverse position, do not use the outboard motor. Otherwise, serious engine damage could occur.** [ECM02391]

EMU33502

Treatment of submerged motor

If the outboard motor is submerged, immediately take it to a Yamaha dealer. Otherwise some corrosion may begin almost immedi-

Trouble Recovery

ately. **NOTICE:** Do not attempt to run the outboard motor until it has been completely inspected.^[ECM00402]

6X6 switch	27	D	De-activating the engine speed control system	67
A			DEC alert indicator	24
Alcohol and drugs	2		Digital electronic control	22
Alert system	34		Digital electronic control alert	34
All Start/Stop switch panel (optional) ...	27		Digital electronic control requirements	12
Anode(s), inspecting and replacing	83	E	EC Declaration of Conformity (DoC)	5
Anti-fouling paint	16		Electric shock	1
Approval label of emission control certificate	16		Emergency equipment	16
Avoid collisions	3		Emergency, running in an	91
B			Emergency, temporary action in	91
Battery	46		Emission control information	16
Battery, checking (electric start models)	84		Engine data recording	9
Battery, connecting	84		Engine idle speed, inspecting	79
Battery, disconnecting	86		Engine oil	43
Battery requirements	13		Engine oil, changing	79
Boat direction	57		Engine oil, filling	40
Boat horsepower rating	12		Engine oil requirements	15
Boating safety	2		Engine shut-off cord (lanyard)	1, 43
Boating safety publications	4		Engine shut-off cord (lanyard) and clip	28
Breaking in engine	40	F		
C			Filling fuel	46
Carbon monoxide	2		First-time operation	40
CE Marking / UKCA Marking	5		Flushing cooling water passage	70
Center engine switch	26		Flushing device	30, 44
Center engine switch operation	54		Fuel filter	30
Checks after engine warm up	53		Fuel filter, checking	42
Checks after starting engine	52		Fuel leaks, checking for	42
Checks before starting engine	41		Fuel level	41
CL5 Display	31		Fuel requirements	15
Cleaning the outboard motor	71		Fuel system	42
Collisions with floating or submerged objects	3		Fuse, replacing	92
Compliance mark label	6	G		
Components diagram	17		Gasoline	2, 15
Control functions, checking	42		Gasoline exposure and spills	2
Control lever	23		Gear oil, changing	81
Cooling water	52		Greasing	77
Cowling lock lever	29			

INDEX

H		
	Helm Master control system alert.....	34
	Helm Master EX (upgradable).....	22
	Hot parts.....	1
I		
	Identification numbers record.....	5
	Impact damage.....	91
	Installation requirements	12
K		
	Key number	5
L		
	Laws and regulations.....	4
	Low oil pressure alert	35
	Lubrication.....	69
M		
	Main switch	27
	Maintenance chart 1	73
	Maintenance chart 2	75
	Modifications	2
	Mounting height.....	38
	Mounting outboard motor	12
	Mounting the outboard motor	38
N		
	Neutral hold switch.....	25
	Neutral hold switch operation.....	54
O		
	Operating engine	47
	Operating in salt water or other conditions.....	67
	Outboard motor, checking	43
	Outboard motor disposal requirements	16
	Outboard motor equipment.....	28
	Outboard motor (painted surface), checking	71
	Outboard motor safety	1
	Outboard motor serial number	5
	Overheat alert	34
	Overloading	3
P		
	Passenger training	4
	Passengers	2
	People in the water	2
	Periodic maintenance	71
	Personal flotation devices (PFDs).....	2
	Power trim and tilt	1
	Power trim and tilt switch (bottom cowling)	28
	Power trim and tilt switches	23
	Power trim and tilt system, checking ...	45
	Power trim and tilt will not operate.....	93
	Propeller	1
	Propeller (counter rotation models)	14
	Propeller, inspecting	80
	Propeller, installing	81
	Propeller, removing.....	80
	Propeller selection	14
	PTT TotalTilt.....	65
R		
	Read manuals and labels	7
	Replacement parts	71
	Rotating parts	1
S		
	Sending fuel.....	47
	Severe operating conditions.....	72
	Shallow water	66
	Shifting.....	53
	Shifting (checks after engine warm up).....	53
	Single lever switch	26
	Single lever switch operation.....	55
	Spark plug, inspecting.....	79
	Specifications	11
	Speed control switch.....	24
	Starting engine.....	47
	Start-in-gear protection	14
	Start/Stop switch panel	27
	Station selector switch	25

Steer-by-wire system will not operate	93
Stop switches	53
Stopping boat	56
Stopping engine	59
Storing outboard motor	69
Submerged outboard motor	95

T

Tilt limiter	29
Tilt support lever	29
Tilting up and down	61
Top cowling, installing	44
Top cowling, removing	41
Transporting and storing outboard motor	69
Trimming outboard motor	59
Troubleshooting	88

W

Warming up engine	52
Warning labels	7
Water separator alert	36
Water separator-alert is activated after leaving port	94
Weather	4
Wiring and connectors, inspecting	79

Y

Yamalube	79
----------------	----



Printed in Japan
December 2022-0.1 × 1 CR